

HE
18.5
.A54
no.
DOT-
NHTSA-
86-6

Department
Transportation

National Highway
Traffic Safety

Administration

DOT-HS-807-158
DOT-TSC-NHTSA-86-6
Final Report

December 1987



Analysis of Head Response to Torso Acceleration Vol. II - Description of Data Retrieval, Analysis and Display Software

C.H. Spenny

Transportation Systems Center
Cambridge, MA 02142

Prepared for

National Highway Traffic Safety Administration
Research and Development
Washington, DC 20590

NOTICE

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for its contents or use thereof.

NOTICE

The United States Government does not endorse products of manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the object of this report.

1. Report No. DOT-HS-807-158		2. Government Accession No.		3. Recipient's Catalog No.	
4. Title and Subtitle Analysis of Head Response to Torso Acceleration, Vol. II - Description of Data Retrieval, Analysis and Display Software				5. Report Date December 1987	
				6. Performing Organization Code DTS-44	
				8. Performing Organization Report No. DOT-TSC-NHTSA-86-6	
7. Author(s) C.H. Spenny*				10. Work Unit No. (TRAIS) HS476/R4434	
9. Performing Organization Name and Address U.S. Department of Transportation Research and Special Programs Administration Transportation Systems Center Cambridge, MA 02142				11. Contract or Grant No.	
				13. Type of Report and Period Covered Final Report December 1982 - July 1986	
12. Sponsoring Agency Name and Address U.S. Department of Transportation National Highway Traffic Safety Administration Research and Development Washington, DC 20590				14. Sponsoring Agency Code NRD-13	
15. Supplementary Notes *Department of Aeronautics & Astronautics Air Force Institute of Technology Wright-Patterson Air Force Base, Ohio 45433					
16. Abstract Performance requirements are developed which define the kinematic and kinetic response of the head for a seated subject exposed to frontal, lateral or oblique impact. Response is expressed in terms of variables which are readily measured in an anthropomorphic dummy and which are useful in injury prediction. The performance requirements are based on volunteer tests conducted by the U.S. Department of Navy, Naval Biodynamics Laboratory (NBDL) in which a four-point restraint system and a singular type of impact profile are employed. Other NBDL volunteer tests and volunteer and cadaver tests conducted by Wayne State University are used to evaluate the effects of variation in impact profile, type of restraint system and level of muscle activity.					
17. Key Words Automotive Safety, Biomechanics, Human Impact Response, Anthropomorphic Dummies			18. Distribution Statement DOCUMENT IS AVAILABLE TO THE PUBLIC THROUGH THE NATIONAL TECHNICAL INFORMATION SERVICE, SPRINGFIELD, VIRGINIA 22161		
19. Security Classif. (of this report) Unclassified		20. Security Classif. (of this page) Unclassified		21. No. of Pages 160	
				22. Price	


PREFACE

It was necessary to analyze a large amount of human response data in order to establish quantitative measures that evaluate fidelity of head response in an anthropomorphic dummy. To facilitate this work, software was developed to automate the data processing on the VAX computer of the National Highway Traffic Safety Administration. This volume is a guide to the use of that software.

The software was developed under the direction of Dr. C. H. Spenny formerly of the Transportation Systems Center (TSC), by Messrs. J. Burstein, D. A. Gordon, T. Peters and R. Stevens of the Systems Development Corporation, an on-site ADP contractor at TSC.

METRIC CONVERSION FACTORS

Approximate Conversions to Metric Measures				Approximate Conversions from Metric Measures			
Symbol	When You Know	Multiply by	To Find	Symbol	When You Know	Multiply by	To Find
LENGTH				LENGTH			
in	inches	2.5	centimeters	mm	millimeters	0.04	inches
ft	feet	30	centimeters	cm	centimeters	0.4	inches
yd	yards	0.9	meters	m	meters	3.3	feet
mi	miles	1.6	kilometers	km	kilometers	1.1	yards
AREA				AREA			
in ²	square inches	6.5	square centimeters	cm ²	square centimeters	0.16	square inches
ft ²	square feet	0.09	square meters	m ²	square meters	1.2	square yards
yd ²	square yards	0.8	square meters	km ²	square kilometers	0.4	square miles
mi ²	square miles	2.6	square kilometers	ha	hectares (10,000 m ²)	2.5	acres
MASS (weight)				MASS (weight)			
oz	ounces	28	grams	g	grams	0.035	ounces
lb	pounds (2000 lb)	0.45	kilograms	kg	kilograms	2.2	pounds
		0.9	tonnes	t	tonnes (1000 kg)	1.1	short tons
VOLUME				VOLUME			
cup	teaspoons	5	milliliters	ml	milliliters	0.03	fluid ounces
Tbsp	tablespoons	15	milliliters	l	liters	2.1	pints
fl oz	fluid ounces	30	milliliters	l	liters	1.06	quarts
c	cups	0.24	liters	l	liters	0.26	gallons
pt	pints	0.47	liters	m ³	cubic meters	36	cubic feet
qt	quarts	0.96	liters	m ³	cubic meters	1.3	cubic yards
gal	gallons	3.8	liters				
ft ³	cubic feet	0.03	cubic meters				
yd ³	cubic yards	0.76	cubic meters				
TEMPERATURE (exact)				TEMPERATURE (exact)			
°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C	Celsius temperature	9/5 (then add 32)	Fahrenheit temperature



1 in. = 2.54 cm (exactly). For other exact conversions and more detail tables see NBS Misc. Publ. 286, Units of Weight and Measures. Price \$2.26 SD Catalog No. C13 10 286.

CONTENTS

<u>SECTION</u>	<u>PAGE</u>
1. INTRODUCTION	1-1
2. PROGRAM FOR DATA RETRIEVAL AND DISPLAY (DRD)	2-1
2.1 Description	2-1
2.2 Use of the DRD Program	2-2
2.2.1 CLEAR Command	2-2
2.2.2 EXTRACT Command	2-3
2.2.3 DIRECTORY Command	2-3
2.2.4 FILE Command	2-6
2.2.5 GET Command	2-6
2.2.6 END Command	2-7
2.2.7 ADD Command	2-7
2.2.8 SUBTRACT Command	2-7
2.2.9 VMAGNITUDE Command	2-7
2.2.10 DIVIDE Command	2-8
2.2.11 CONSTANT Command	2-8
2.2.12 NORMALIZE Command	2-8
2.2.13 STANDEV Command	2-9
2.2.14 DSPLAY Command	2-9
3. PROGRAM FOR CALCULATION OF HEAD KINEMATIC AND LOAD RESPONSE (HEAD)	3-1
3.1 Description	3-1
3.2 Use of the HEAD Program	3-1
4. PROGRAM FOR CALCULATION OF NECK KINEMATIC AND LOAD RESPONSE (NECK)	4-1
4.1 Description	4-1
4.2 Use of the NECK Program	4-1
APPENDIX A: DEFINITION OF VARIABLES CONTAINED IN THE NBDL DATABASE	A-1
APPENDIX B: DEFINITION OF CALCULATED VARIABLES BY HEAD AND NECK PROGRAMS	B-1
APPENDIX C: FORTRAN CODING OF THE DATA RETRIEVAL ANALYSIS AND DISPLAY SOFTWARE	C-1

LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
1-1.	Block Diagram Representation of the Data Retrieval, Analysis and Display Software	1-2
2-1.	Example of Multi-curve Plotting Capability	2-12

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
2-1.	Listing of Test Run Numbers Recognized by the DRD Program	2-4
3-1.	Input Variables for the HEAD Program	3-2
3-2.	Subject Specific Data Stored Within the HEAD Program	3-3
3-3.	Output Variables for the HEAD Program	3-4
4-1.	Input Variables for the NECK Program	4-2
4-2.	Subject Specific Data Stored Within the NECK Program	4-3
4-3.	Output Variables for the NECK Program	4-4

1. INTRODUCTION

The data retrieval, analysis and display software described in this volume consists of a general purpose data manipulation program, the Data Retrieval and Display (DRD) program, and a pair of specialized analysis programs, HEAD and NECK.

The DRD program is user friendly and is designed to quickly and efficiently retrieve and graphically display data on head and neck response. As currently programmed it can be used with the test data from the Naval Biodynamics Laboratory, Wayne State University (WSU), and the University of Michigan Transportation Research Institute (UMTRI) that is tabulated in this volume. This data base consists of 380 tests.

HEAD and NECK are specialized programs written for use at the Transportation Systems Center in analysis of head and neck response. The response variables that are calculated by these programs are integrated with the test data and displayed using the DRD program.

Figure 1-1 is a block diagram representation of the software. All software is written in Fortran for operation on a VAX/VMS computer. The Fortran coding is included as Appendix C of this volume.




FIGURE 1-1. BLOCK DIAGRAM REPRESENTATION OF THE DATA RETRIEVAL, ANALYSIS AND DISPLAY SOFTWARE

2. PROGRAMS FOR DATA RETRIEVAL AND DISPLAY (DRD)

2.1 DESCRIPTION

The user may retrieve any of the variables (records) from the run files that reside in disk storage. These variables are selected by specifying the run number and variable name for each variable requested. The variables that may be retrieved are those listed in Appendix A of this volume. The total number of test variables is 92.

To reduce disk storage requirements, the run files are written in binary format and each run includes only 66 of the test variables. The data that is not present consists of; (1) linear velocity data derived from photography, and (2) linear velocity and displacement data as derived from sensor (accelerometer) measurements. When the user requests one of the variables not present, it is reconstructed by differentiating photographic displacement or integrating sensor acceleration, as appropriate. This operation is transparent to the user and reproduces the test results to six significant figures.

Each run file consists of a series of records, the first being a header record which contains the run number, subject number and other parameters describing the overall test. The header record is followed by the 66 records of stored variables. Each sensor (accelerometer) record has the same format, consisting of 598 fields of test data. All NBDL sensor measurements were taken at .0005 sec timesteps, thus allowing the storage of response data for just under 0.3 sec. Sensor data is not available for the Wayne State and UMTRI data.

Each photographic record within a run is identical in format and size. However, the number of fields varies from run to run and is determined by the number of frames digitized. In addition, the time step varies between runs as determined by camera speed. One of the photographic records is the variable, TIME, whose field entries are the times of occurrence of film frames which were digitized.

Data records requested by the user, up to a maximum of 100, are extracted into a scratch file. The scratch file is binary and becomes the source file for use by other portions of the DRD program and by HEAD and NECK. DRD capabilities,

in addition to data extraction, include: (1) filing and retrieving scratch files, (2) creation of new variables by performing basic mathematical operations on one or more variables in the scratch file, and (3) graphic display. Use of the DRD capabilities is described in Section 2.2 which follows.

It should be noted that the graphic display module recognizes sensor and photographic variables and correctly plots them versus time, even on the same graph. However, there are no program checks to prevent the creation of illogical new variables. In particular, the user is cautioned against combining (and cross plotting) photographic and sensor variables.

2.2 USE OF THE DRD PROGRAM

To use the DRD program issue the VAX/VMS DCL command;

```
$ RUN TSCPROG.SRC.PROGS.NECK.ANALYSIS XTRAC
```

The program will issue a prompt (XTR>) and expect the user to type in one of the following commands;

CLEAR	END	NORMALIZE
EXTRACT	ADD	STANDEV
DIRECTORY	SUBTRACT	DSPLAY
FILE	VMAGNITUDE	
GET	DIVIDE	

The first three characters of each command must be entered. The remaining characters are optional. The following sections describe the syntax of each of these commands.

2.2.1 CLEAR Command

This command sets the number of entries in the directory to zero. The scratch file is thus cleared and contains no data records. This command should be used before a new scratch file is made up, or to clear the file in case errors are made during data extraction.

The use of the optional 'n' with this command sets the number of entries in the directory to the integer value 'n', allowing the user better control over the extracted data file. The default value when 'n' is not specified is 100. The user can extract variables, produce new variables (seen in the following sections) and overwrite these variables if results are unsatisfactory.

```
XTR> CLEAR      or
XTR> CLEAR 20
```

2.2.2 EXTRACT Command

This command is used to extract records from the original binary format files. These records are then written to a random access file named SCRTCH.DAT. Individual tests are identified by run number and individual variables are identified by variable name. The keyword 'ALL' may be used in place of a variable name to extract all variables of any given run. Run numbers corresponding to the tests of Volume I, Appendix A, are repeated in Table 2-1 for convenience. A listing of variables is given in Appendix A of this volume.

```
XTR> EXTRACT RUN LX1916 VAR VNXSOP or
XTR> EXTRACT RUN LX1916 ALL
```

Up to 100 variables may be extracted and may reside in the scratch file at any one time. Note that extracting 'ALL' variables places 92 variables in the scratch file, leaving room for only eight more.

2.2.3 DIRECTORY Command

This command causes a listing of the scratch file to be output to the user's terminal. This listing shows which records are contained in the scratch file. The listing for each record includes the variable numbers, variable name, run number,

TABLE 2-1. LISTING OF TEST RUN NUMBERS
RECOGNIZED BY THE DRD PROGRAM

NBDL Frontal Test Runs

LX3524	LX3525	LX3530	LX3531	LX3536	LX3537
LX3544	LX3548	LX3550	LX3558	LX3573	LX3578
LX3583	LX3616	LX3779	LX3780	LX3782	LX3783
LX3785	LX3786	LX3788	LX3789	LX3791	LX3793
LX3794	LX3796	LX3797	LX3798	LX3800	LX3801
LX3803	LX3804	LX3805	LX3807	LX3808	LX3809
LX3812	LX3814	LX3815	LX3817	LX3818	LX3819
LX3821	LX3822	LX3823	LX3824	LX3833	LX3837
LX3839	LX3840	LX3841	LX3842	LX3851	LX3852
LX3854	LX3856	LX3857	LX3858	LX3869	LX3870
LX3871	LX3872	LX3875	LX3876	LX3878	LX3880
LX3882	LX3883	LX3885	LX3886	LX3887	LX3889
LX3890	LX3893	LX3894	LX3895	LX3898	LX3900
LX3901	LX3903	LX3904	LX3906	LX3908	LX3909
LX3913	LX3914	LX3916	LX3918	LX3920	LX3921
LX3924	LX3926	LX3927	LX3928	LX3939	LX3940
LX3941	LX3942	LX3944	LX3945	LX3946	LX3948
LX3949	LX3950	LX3951	LX3953	LX3954	LX3955
LX3957	LX3958	LX3959	LX3961	LX3962	LX3963
LX3965	LX3968	LX3969	LX3970	LX3972	LX3982
LX3983	LX3985	LX3986	LX3987	LX3989	LX3990
LX3991	LX3993	LX3994	LX3995	LX3997	LX3998
LX3999					

NBDL Lateral Test Runs

LX1454	LX1456	LX1457	LX1458	LX1468	LX1470
LX1471	LX1474	LX1475	LX1484	LX1487	LX1501
LX1503	LX1504	LX1505	LX1507	LX1509	LX1510
LX1512	LX1513	LX1524	LX1525	LX1526	LX1528
LX1785	LX1793	LX1831	LX1860	LX1874	LX1916
LX1960	LX1998	LX2010	LX2013	LX2027	LX2032
LX2056	LX2060	LX2072	LX2090	LX2102	LX2124
LX2137	LX2148	LX2151	LX2182	LX2282	LX2294
LX2298	LX2302	LX2313	LX2326	LX2338	LX2341
LX2355	LX4050	LX4052	LX4053	LX4054	LX4055
LX4057	LX4058	LX4059	LX4060	LX4068	LX4069
LX4070	LX4071	LX4073	LX4074	LX4075	LX4076
LX4078	LX4079	LX4080	LX4081	LX4083	LX4084
LX4085	LX4088	LX4089	LX4090	LX4092	LX4093
LX4094	LX4095	LX4097	LX4098	LX4099	LX4100
LX4104	LX4107	LX4109	LX4110	LX4111	LX4112
LX4114	LX4115	LX4116	LX4118	LX4119	LX4120
LX4123	LX4124	LX4125	LX4126	LX4128	LX4129
LX4130	LX4131	LX4133	LX4134	LX4135	LX4137
LX4138	LX4139	LX4140	LX4142	LX4143	LX4144
LX4145	LX4147	LX4148	LX4149	LX4151	LX4153
LX4155					

NBDL Oblique Test Runs

LX2763	LX2770	LX2772	LX2784	LX2786	LX2799
LX2801	LX2813	LX2815	LX2827	LX2829	LX2843
LX2872	LX2876	LX2916	LX2955	LX2973	LX2979
LX2982	LX2985	LX2988	LX3049	LX3053	LX3061
LX3065	LX3077	LX3085	LX3089	LX3093	LX3097
LX3100	LX3102	LX3106	LX3122	LX3129	LX3133
LX3145	LX3148	LX3153	LX3158	LX3417	LX4159
LX4161	LX4162	LX4163	LX4164	LX4166	LX4167
LX4168	LX4170	LX4171	LX4172	LX4234	LX4235
LX4236	LX4237	LX4238	LX4240	LX4241	LX4242
LX4243	LX4244	LX4246	LX4247	LX4248	LX4249
LX4251	LX4259	LX4260	LX4261	LX4263	LX4264
LX4265	LX4266	LX4268	LX4269	LX4270	LX4271
LX4276	LX4277	LX4280	LX4281	LX4282	LX4284
LX4286	LX4287	LX4288	LX4290	LX4291	LX4292
LX4293	LX4295	LX4296	LX4297	LX4298	LX4301
LX4302	LX4303	LX4305	LX4306	LX4307	LX4309
LX4310	LX4313	LX4314	LX4316		

WSU Frontal Test Runs

DOT307	DOT308	DOT309	DOT310	DOT314	DOT331
DOT332	DOT333	DOT343	DOT345	DOT453	DOT454
DOT455					

UMTRI Frontal Test Runs

T76008

minimum value, maximum value, and number of data points for that record. This listing contains only those records which are part of the scratch file at the time the DIRECTORY command is given. If the scratch file contains no records, the message "EMPTY" is sent to the terminal and the user is prompted for the next command.

2.2.4 FILE Command

This command is used to place the contents of the scratch file in a permanent disk file specified by the given filename. The file is written in scratch file format, making it possible to store and reuse the data at another time.

If the permanent disk file does not exist, it is created, the contents of the scratch file are placed in it, and the scratch file is deleted.

If the permanent disk file does exist, the contents of it are written to a file with the same name and a version number one higher than that which already exists. The filename must be specified in single quotes using VAX/VMS filenames convention.

```
XTR> FILE 'NEWDAT.DAT' results in the prompt;  
Variable #'s or ALL  1,3,18,25  or  
Variable #'s or ALL  ALL
```

2.2.5 GET Command

The GET command gets files that were filed using the FILE command. Filenames must include the user default directory and must be enclosed in single quotes. The file specified must be in scratch file format e.g, if the NEWDAT.DAT file in the above example is created in directory [CURTS.TEST] the GET command looks like:

```
XTR> GET '[CURTS.TEST] NEWDAT.DAT'
```


2.2.6 END Command

The END command ends operation of the program. Control is returned to DCL (Digital Command Level) of the VMS operating system.

```
XTR> END
```

2.2.7 ADD Command

This command adds the values of the fields of the data record specified by the first variable name to those of the second variable name and sets the results in a new record which is given the name specified by the third variable name parameter. This name must be enclosed in single quotes. The data records used to produce the new variable must already reside in the scratch file. The new variable is then written out as a new record on the scratch file.

```
XTR> ADD RUN LX1960 VAR AAXXOS AAYXOS 'XPLUSY'
```

2.2.8 SUBTRACT Command

This is the same as the ADD command except that the values of the record selected by the second variable name are instead subtracted from the record specified by the first variable name.

```
XTR> SUBTRACT RUN LX1960 VAR AAXXOS AAYXOS 'XMNUSY'
```

2.2.9 VMAGNITUDE Command

This command computes the vector magnitude of a vector specified by the first three variable name fields following the VARIABLE command. These fields specify the names of the x, y, and z components of a three dimensional vector. These variables must already be contained in the scratch file. They are used to compute the vector magnitude, v, according to:

$$V = \sqrt{x^2 + y^2 + z^2}$$

where the magnitude "v" is specified by the fourth variable name parameter. (Note that this parameter is a new variable name which is not one of the names on the list in Table 2-1. Also, since this name may contain from one to six characters, it is enclosed by single quotes in order to aid the extraction module in its syntax analysis.) A vector magnitude is computed and stored in the scratch file.

```
XTR> VMAGNITUDE RUN LX1960 VAR AAXXOS AAYXOS AAZXOS 'AAVMAG'
```

2.2.10 DIVIDE Command

This command divides by a constant the values of the fields of the data record specified by the first variable name to produce a new record in the scratch file, which is specified by the second variable name. The new name must be enclosed in single quotes. The data records for the first variable must already reside in the scratch file.

```
XTR> DIV RUN LX1960 VAR AAXOS -.396 'SCALED'
```

2.2.11 CONSTANT Command

This command adds a constant to the values of the fields of the data record specified by the first variable name to produce a new record in the scratch file, which is specified by the second variable name. The new name must be enclosed in single quotes. The data records for the first variable must already reside in the scratch file.

```
XTR> CON RUN LX1960 VAR AAXXOS +.200 'BIAS'
```

2.2.12 NORMALIZE Command

This command divides the values of each field of the data record specified by the first variable name by the value in the first field to produce a new record in the scratch field, which is specified by a second variable name. The new name must be enclosed in single quotes. The data records for the first variable name must already reside in the scratch file.

```
XTR> NOR RUN LX1960 VAR AAXOS 'NORAA X'
```

2.2.13 STANDEV Command

The STANDEV command calculates mean, mean plus standard deviation, and mean minus standard deviation and standard deviation at each timestep for a given variable. The scratch file is searched for each occurrence of the specified variable and each occurrence is used in the calculation of mean and standard deviation at each timestep. The three new variables are named according to the following convention;

MOXXXX
MPXXXX
MMXXXX
SDXXXX

where XXXX stands for the first three letters of the given variable plus either a P or an S, depending on whether it is a photo or sensor variable. MO stands for mean, MP stands for mean plus standard deviation, MM stands for mean minus standard deviation and SD stands for standard deviation

XTR> STANDEV VAXXOS

This command would create the four new variables MOVAXS, MPVAXS, MMVAXS and SDVAXS.

2.2.14 DSPLAY Command

The DSPLAY command places the user in the display module of the DRD program. This module issues a different prompt, 'DSP '. Once in this module, the user chooses from the following commands;

PLOT
XTRAC

DIRECTORY
END

DSPLAY
COPY

A PLOT command is entered for each curve to be plotted on a display page. Multiple plots may be selected for the same display. Up to 20 PLOT commands may be entered. When all of the plots have been requested a DSPLAY command is entered and the display is output to the graphics terminal. Entering a COPY command rather than a DSPLAY command causes output to be displayed on the graphics screen and then generates a copy of a hardcopy unit.

2.2.14.1 PLOT Command - Each plot command selects two variables to be used as the x and y values of a curve to be plotted two dimensionally on a graphics device such as a Tektronix 4010, 4114, or 4115. The first variable name is used as the x coordinate, the second variable name as the y coordinate. All variables selected must already be in the scratch file before plot commands are entered. Time is (of course) a valid variable name for both photographic and sensor data. When plotting sensor variables, time is calculated when necessary. When plotting photographic variables, the time variable must already be in the scratch file.

The user may choose from several line formats. Solid lines, solid lines with markers, or dashed lines are the available options. Marker value is an optional argument for this command, it must be integer and may be between -5 and 8. Markers come in eight flavors (for example: squares, circles, or triangles) and are denoted by the integers 1 through 8. Dashed lines come in five types, denoted by the integers -5 through -1. If no marker value is specified, the default is 0, the solid line.

The user may also optionally specify the number of points to be plotted. This is useful when plotting photographic data vs. sensor data when the number of points varies or when the user is interested in viewing a smaller segment of data. The marker argument must be included (it may be a 0) when using the points feature. Otherwise, the point value will be interpreted as a marker value.

DSP > PLOT RUN LX1916 TIME AAXXOS	will give a plot of time vs. aaxxos with a solid line (the default).
-----------------------------------	--

DSP > PLOT RUN LX3958 TIME ANXXOS 1	will give a plot with circles used as markers.
-------------------------------------	---

DSP > PLOT RUN LX3958 TIME VNXXOS 1 250 will give the first 250 points of this plot with circles as markers.

DSP > PLOT RUN LX3958 TIME VNXSOP -2 will produce the plot with a dashed line (no markers).

2.2.14.2 DSPLAY Command - The DSPLAY command is used to mark the end of the plot specifications and causes generation of the plot on the current graphics device. All plot commands issued since the most recent other DSPLAY command will be plotted on a single graph. The axes will be scaled to accommodate all variables being plotted. They will be labelled with the dimensions of the first pair of variables to be plotted. Figure 2-1 shows the multiple plots resulting from the sample plot commands in section 2.2.14.1.

DSP > DSPLAY

2.2.14.3 COPY Command - The COPY command also marks the end of plot specifications and causes generation of the plot on the graphics screen. Additionally, COPY causes a hard-copy device (a Tektronix printer) to copy the screen when plotting has finished.

DSP > COPY

2.2.14.4 DIRECTORY Command - The DIRECTORY command is the same as was described in 2.2.3.

2.2.14.5 XTRAC Command - The XTRAC command returns the user to the extraction module when the current plotting has been finished so that additional data files may be processed.

DSP > XTRAC

2.2.14.6 END Command - The directory command is the same as was described in 2.2.6.




FIGURE 2-1. EXAMPLE OF MULTICURVE PLOTTING CAPABILITY

3. PROGRAM FOR CALCULATION OF HEAD KINEMATIC AND LOAD RESPONSE (HEAD)

3.1 DESCRIPTION

The kinematic and load response of the head, as described in Volume I by equations (2), (3), (5), (6), (24), (25) and (26) are calculated by the HEAD program. This program is designed for use in conjunction with data retrieved by the DRD. Table 3-1 lists the NBDL defined variables which HEAD reads from a DRD scratch file.⁽¹⁾

The input variables are a combination of photographic and accelerometer derived variables as indicated by the final letter of the Fortran name-P for photo and S for accelerometer (sensor). Calculations are made by HEAD at the times at which photo data is digitized. A subroutine within HEAD interpolates sensor data, using the two nearest points in time to produce acceleration and velocity data at the photo time points.

Subject specific data as indicated in Table 3-2 is coded into HEAD and called as required to match the test subject whose data has been read from the scratch file.

Table 3-3 lists the output variables which are calculated and attached to the DRD scratch file which ran HEAD. Note six variables are also stored in a separate file for use by NECK, indicating that the latter program can be run only in conjunction with HEAD. The block diagram of Figure 1-1 indicates how HEAD interfaces with the DRD package and with NECK.

3.2 USE OF THE HEAD PROGRAM

The variables of Table 3-1 must be present in the scratch file of the DRD. When a variable name appears more than once in the scratch file, the first is selected for use by HEAD.

⁽¹⁾ Neck variables ANXXOS and VNXXOS are included as input to HEAD in order to enter them in the database at the photo timesteps. They are not required for head computations.

TABLE 3-1. INPUT VARIABLES FOR THE HEAD PROGRAM

<u>FORTTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERAL DEFINITION</u> ⁽¹⁾
AAXXOS, AAYXOS, AAZXOS	a_{Ax}, a_{Ay}, a_{Az}	Linear acceleration of the head anatomical origin
ANXXOS	—	Linear acceleration of the T1 anatomical origin
PHAOXP, PHBO2P, PHCO3P	$\theta_{Hx}, \theta_{Hy}, \theta_{Hz}$	Euler angle description of head rotation
PNAOXP, PNBO2P, PNCO3P	$\theta_{Nx}, \theta_{Ny}, \theta_{Nz}$	Euler angle description of T1 vertebral rotation
QHAOXS, QHBOXS, QHCOXS	$\alpha_x, \alpha_y, \alpha_z$	Angular acceleration of the head
RHAOXS, RHBOXS, RHCOXS	$\omega_x, \omega_y, \omega_z$	Angular velocity of the head
TIME	—	Time at which photo data is digitized
VNXXOS	—	Linear velocity of the T1 anatomical origin

(1) The input variables are fully defined in Appendix A.

TABLE 3-2. SUBJECT SPECIFIC DATA STORED WITHIN THE HEAD PROGRAM

<u>FORTTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERALIZED DESCRIPTION</u>
IX, IY, IZ	I_{xx}, I_{yy}, I_{zz}	Centroidal mass moment of inertia coefficients of the instrumented head about the X, Y, and Z axis, respectively, of the head anatomical coordinate system
MH	M_H	Mass of the instrumented head
PXY, PXZ PYX, PYZ PZX, PZY	I_{xy}, I_{xz}, I_{yz}	Centroidal mass product of inertia coefficients of the instrumented head
RGOX, RGOY, RGOZ	$r_{G/Ox}, r_{G/Oy}, r_{G/Oz}$	Position of the head center-of-gravity relative to the occipital condylar point (head anatomical components).

TABLE 3-3. OUTPUT VARIABLES FOR THE HEAD PROGRAM

<u>FORTTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERALIZED DEFINITION</u> ⁽¹⁾
AGXP, AGYP, AGZP	a_{Gx}, a_{Gy}, a_{Gz}	Linear acceleration of the head center-of-gravity
ANXOP	—	Linear acceleration of the T1 anatomical origin
FOXLP, FOYLP, FOZLP/ TOXLP, TOZLP, TOZLP	—	Laboratory coordinate system components of force/torque applied to the head by the neck ⁽²⁾
FOXP, FOYP, FOZP	F_{Ox}, F_{Oy}, F_{Oz}	Head anatomical coordinate system components of force/torque applied to the head by the neck
TOXP, TOYP, TOZP	T_{Ox}, T_{Oy}, T_{Oz}	
FOXTP, FOYTP, FOZTP TOXTP, TOYTP, TOZTP	—	To anatomical coordinate system components of force/torque applied to the head by the neck
THTIXP, THTYP	ϕ_x, ϕ_y	Angular orientation of the head relative to the torso.

(1) The output variables are fully defined in Appendix B.

(2) Variables which are stored for use by program NECK.

4. PROGRAM FOR CALCULATION OF NECK KINEMATIC AND LOAD RESPONSE (NECK)

4.1 DESCRIPTION

The kinematic and load response of the neck, as described in Volume I by equations (1), (2), (3), (9), (11), (14), (22) and (23) are calculated by the NECK program. The program is designed for use in conjunction with the DRD and HEAD programs as noted in the previous section. Table 4-1 lists the NBDL defined variables which NECK reads from a DRD scratch file and from HEAD.* All input variables are photo-derived so there is no need for interpolation of sensor data as in HEAD.

Subject specific data as indicated in Table 4-2 is coded into NECK and is called as required to match the test subject whose data has been read from the scratch file. Parameters ARP, BR and DNZMN are used to correct the data for observed error in the vertical mounted position of the T1 instrumentation as described in Section 5.1. This data correction is made in NECK thereby preserving the original database for use by other researchers. Provision has not been made for display of the corrected variable, DNZSOP, since it was not required for presentation of study results.

Table 4-3 lists the variables which are calculated and attached to the DRD scratch file which was used to run NECK. Figure 1-1 is a block diagram which indicates how NECK interfaces with DRD and HEAD.

4.2. USE OF THE NECK PROGRAM

The variable of Table 4-1 must be present in the scratch file of the DRD. When a variable name appears more than once in the scratch file, the first is selected for use by NECK.

*Reduced versions of HEAD and NECK, that require only photo-derived variables were used to process data from Wayne State University and the University of Michigan. In the reduced programs, there is no input to NECK required from HEAD.

TABLE 4-1. INPUT VARIABLES FOR THE NECK PROGRAM

<u>FORTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERALIZED DEFINITION</u> ⁽¹⁾
FROM DRD SCRATCH FILE:		
DAXSOP, DAY SOP, DAZSOP	r_A	Displacement of the head relative to the sled
DNXSOP, DNYSOP, DNZSOP	r_T	Displacement of the T1 vertebral body relative to the sled
PHAOXP, PHBO2P, PHCO3P	$\theta_{Hx}, \theta_{Hy}, \theta_{Hz}$	Euler angle description of head rotation
PNAOXP, PNBO2P, PNCO3P	$\theta_{Nx}, \theta_{Ny}, \theta_{Nz}$	Euler angle description of T1 vertebral rotation
TIME	—	Time at which photo data is digitized
FROM HEAD PROGRAM:		
FOXLP, FOYLP, FOZLP TOXLP, TOYLP, TOZLP applied to the head by the neck.	—	Laboratory coordinate system components of force/torque

(1) The input variables are fully defined in Appendix A.

TABLE 4-2. SUBJECT SPECIFIC DATA STORED WITHIN THE NECK PROGRAM

<u>FORTTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERALIZED DEFINITION</u>
ARP, BR, DNZMN	$a^*, \frac{\mu_{11}}{(\sigma_R)^2},$ (DNZSOP)M	a, b, r_{Tz} Least squares fit parameters for correcting T1 vertical position DNZSOP
RGAX, RGAZ	$r_{G/Ax}, r_{G/Az}$	Position of the head center-of- gravity relative to the head anatomical origin (head anatomical components)

$$^*a = (DNZSOP)_M + \frac{\mu_{11}}{(\sigma_R)^2} (RATIP)_M$$

TABLE 4-3. OUTPUT VARIABLES FOR THE NECK PROGRAM

<u>FORTRAN SYMBOL</u>	<u>ANALYSIS SYMBOL (VOLUME I)</u>	<u>GENERALIZED DEFINITIONS</u> ⁽¹⁾
PSI	ψ_c	Externally observed head twist relative to the torso
RATIP	$r_{O/T} - r_{O/A}$	Distance from the T1 vertebral to the head anatomical origin
ROTIP	$r_{O/T} - r_{O/C}$	Distance from the T1 vertebral to the occipital condylar point ("Neck chord length")
TENTXP, TENTYP	θ_x, θ_y	Angular orientation of the neck chord vector relative to the torso
TETHNP	ψ_I	Internally measured head twist about the head z-axis
TIXLP, TIYLP, TIZLP	components of the torque	Laboratory coordinate system applied to the neck by the torso
TIXTP, TIYTP, TIZTP	—	To coordinate system components of the torque applied to the neck by the torso

(1) The output variables are fully defined in Appendix B.

APPENDIX A

DEFINITION OF VARIABLES CONTAINED IN THE NBDL DATABASE

(REPRODUCED FROM REF. 4)


AAXXOS	The component of linear acceleration of the head anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
AAAYXOS	The component of linear acceleration of the head anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
AAZXOS	The component of linear acceleration of the head anatomical origin along the Z axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
QHAOXs	Angular acceleration of the head about the X axis of head anatomical coordinate system as derived from mouth mount accelerometer data.
QHBOXs	Angular acceleration of the head about the Y axis of the head anatomical coordinate system as derived from mouth mount accelerometer data.
QHCOXS	Angular acceleration of the head about the Z axis of the head anatomical coordinate system as derived from mouth mount accelerometer data.
VAXXOS	The component of linear velocity of the head anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
VAXSOS	The component of linear velocity of the head anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
VAYXOS	The component of linear velocity of the head anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
VAYSOS	The component of linear velocity of the head anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
VAZXOS	The component of linear velocity of the head anatomical origin along the Z axis of the laboratory coordinate system with respect to fixed laboratory coordinate system as derived from mouth mount accelerometer data.

VAZSOS	The component of linear velocity of the head anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
RHAOS	Angular velocity of the head about the X axis of the head anatomical coordinate system as derived from mouth mount accelerometer data.
RHBOXS	Angular velocity of the head about the Y axis of the head anatomical coordinate system as derived from mouth mount accelerometer data.
RHCOXS	Angular velocity of the head about the Z axis of the anatomical coordinate system as derived from mouth mount accelerometer data.
DAXXOS	The component of linear displacement of the head anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
DAXSOS	The component of linear displacement of the head anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
DAYXOS	The component of linear displacement of the head anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
DAYSOS	The component of linear displacement of the head anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
DAZXOS	The component of linear displacement of the head anatomical origin along the Z axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from mouth mount accelerometer data.
DAZSOS	The component of linear displacement of the head anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.

PHAOXS	Angle of rotation of the head about the X axis of the head anatomical coordinate system as derived from mouth mount acceleromter data. Head anatomical coordinate system is initially aligned with the laboratory coordinate system.	}	EULER ANGLES
PHBO2S	Same as PHAOXS except about the carried Y axis.		
PHCO3S	Same as PHAOXS except about the carried Z axis.		
4HOO1S 4HOO2S 4HOO3S 4HOO4S	Quaternions - The four variables which define the angular orientation of the head anatomical coordinate system relative to the laboratory coordinate system as derived from mouth mount accelerometer.		
ANXXOS	The component of linear acceleration of T_1 anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory		
ANYXOS	The component of linear acceleration of the T_1 anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.		
ANZXOS	The component of linear acceleration of the T_1 anatomical origin along the Z axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.		
QNAOXS	Angular acceleration of T_1 (first Thoracic vertebral body) about the Y axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.		
QNBOXS	Angular acceleration of T_1 (first Thoracic vertebral body) about the Y axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.		
QNCOSX	Angular acceleration of T_1 (first Thoracic vertebral body) about the Z axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.		
VNXXOS	The component of linear velocity of the T_1 anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.		
VNXSOS	The component of linear velocity of the T_1 anatomical origin along the X axis of the sled coordinate system with respect to sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.		

VNYXOS	The component of linear velocity of the T_1 anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.
VNYSOS	The component linear velocity of the T_1 anatomical origin along the Y axis of sled coordinate system with respect to sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
VNZXOS	The component of linear velocity of the T_1 anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.
VNZSOS	The component of linear velocity of the T_1 anatomical origin along the Z axis of sled coordinate system with respect to sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
RNAOXs	Angular velocity of T_1 (first Thoracic vertebral body) about the X axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.
RNBOXs	Angular velocity of T_1 (first Thoracic vertebral body) about the Y axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.
RNCOXS	Angular velocity of T_1 (first Thoracic vertebral body) about the Z axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data.
DNXXOS	The component of linear displacement of the T_1 anatomical origin along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.
DNXSOS	The component of linear displacement of the T_1 anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
DNYXOS	The component of linear displacement of the T_1 anatomical origin along the Y axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.

DNYSOS	The component of linear displacement of the T_1 anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
DNZXOS	The component of linear displacement of the T_1 anatomical origin along the Z axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from T_1 mount accelerometer data.	
DNZSOS	The component of linear displacement of the T_1 anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from accelerometer data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
PNAOXS	Angle of rotation of T_1 (first Thoracic vertebral body) about the X axis of the T_1 anatomical coordinate system as derived from T_1 mount accelerometer data. The T_1 anatomical coordinate system is initially aligned with the laboratory coordinate system.	} EULER ANGLES
PNBO2S	Same as PNAOXS except about the carried Y axis.	
PNCO3S	Same as PNB02S except about the carried Z axis.	
4NOO1S	Quaternions - the four variables which define the angular orientation of the T_1 anatomical coordinate system relative to the laboratory coordinate system as derived from T_1 mount accelerometer data.	
ACXXOS	Linear acceleration of the sled along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as measured by sled mounted accelerometer.	
VCXXOS	Linear velocity of the sled along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from sled mounted accelerometer data.	
DCXXOS	Linear displacement of the sled along the X axis of the laboratory coordinate system with respect to the fixed laboratory coordinate system as derived from sled mounted accelerometer data.	
VAXSOP	The component of linear velocity of the head anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	

VAYSOP	The component of linear velocity of the head anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
VAXSOP	The component of linear velocity of the head anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
RHAOXP	Angular velocity of the head about the X axis of the head anatomical coordinate system as derived from mouth mount photo target data.	
RHBOXP	Angular velocity of the head about the Y axis of the head anatomical coordinate system as derived from mouth mount photo target data.	
RHCOXP	Angular velocity of the head about the Z axis of the head anatomical coordinate system as derived from mouth mount photo target data.	
DAXSOP	The component of linear displacement of the head anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
DAYSOP	The component of linear displacement of the head anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
DAZSOP	The component of linear displacement of the head anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from mouth mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.	
PHAOXP	Angle of rotation of the head about the X axis of the head anatomical coordinate system as derived from mouth mount photo target data. Head anatomical coordinate system is initially aligned with the laboratory coordinate system	 EULER ANGLES
PHBO2P	Same as PHAOXP except about the carried Y axis.	
PHCO3P	Same as PHBO2P except about the carried Z axis.	

4HOO1P	Quaternions - The four variables which define the angular orientation of the head anatomical coordinate system relative to the laboratory system as derived from mouth mount photo target data.
4HOO2P	
4HOO3P	
4HOO4P	
VNXSOP	The component of linear velocity of the T_1 anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
VNYSOP	The component of linear velocity of the T_1 anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
VNZSOP	The component of linear velocity of the T_1 anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with the laboratory coordinate system and translates with the sled.
RNAOXP	Angular velocity of T_1 (first Thoracic vertebral body) about the X axis of the T_1 anatomical coordinate system as derived from T_1 mount photo target data.
RNBOXP	Angular velocity of T_1 (first Thoracic vertebral body) about the Y axis of the T_1 anatomical coordinate system as derived from T_1 mount photo target data.
RNCOXP	Angular velocity of T_1 (first Thoracic vertebral body) about the Z axis of the T_1 anatomical coordinate system as derived from T_1 mount photo target data.
DNXSOP	The component of linear displacement of the T_1 anatomical origin along the X axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with laboratory coordinate system and translates with the sled.
DNYSOP	The component of linear displacement of the T_1 anatomical origin along the Y axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with laboratory coordinate system and translates with the sled.
DNZSOP	The component of linear displacement of the T_1 anatomical origin along the Z axis of the sled coordinate system with respect to the sled coordinate system as derived from T_1 mount photo target data. The sled coordinate system is aligned with laboratory coordinate system and translates with the sled.

PNAOXP	Angle of rotation of T_1 (first Thoracic vertebral body) about the X axis of the T_1 anatomical coordinate system as derived from T_1 mount photo target data. The T_1 anatomical coordinate system is initially aligned with the laboratory coordinate system.
PNBO2P	Same as PNAOXP except about the carried Y axis.
PNCO3P	Same as PNBO2P except about the carried Z axis.
4NOO1P 4NOO2P 4NOO3P 4NOO4P	Quaternions - The four variables which define the angular orientation of the T_1 anatomical coordinate system relative to the laboratory coordinate system as derived from T_1 mount photo target data.
TIME	Time at which exposure occurred for film frames that were digitized to produce photo variables.

} EULER ANGLES

The unit of all variables are consistent with

Linear measure - meters
Angular measure - radians
Time measure - seconds

APPENDIX B

DEFINITION OF CALCULATED VARIABLES BY THE HEAD AND NECK PROGRAMS

FORTRAN
SYMBOL

DEFINITION

AGXP	The linear acceleration of the head center of gravity along the x-axis of the head anatomical coordinate system with respect to the fixed laboratory coordinate system.
AGYP	The linear acceleration of the head center of gravity along the y-axis of the head anatomical coordinate system with respect to the fixed laboratory coordinate system.
AGZP	The linear acceleration of the head center of gravity along the z-axis of the head anatomical coordinate system with respect to the fixed laboratory coordinate system.
FOXLP	The force applied by the neck to the head parallel to the laboratory x-axis and passing through the occipital condylar point.
FOYLP	The force applied by the neck to the head parallel to the laboratory y-axis and passing through the occipital condylar point.
FOZLP	The force applied by the neck to the head parallel to the laboratory z-axis and passing through the occipital condylar point.
FOXP	The force applied by the neck to the head at the occipital condylar point parallel to the x-axis of the head anatomical coordinate system.
FOYP	The force applied by the neck to the head at the occipital condylar point parallel to the y-axis of the head anatomical coordinate system.
FOZP	The force applied by the neck to the head at the occipital condylar point parallel to the z-axis of the head anatomical coordinate system.
FOXTP	The force applied by the neck to the head parallel to the x-axis of the T_0 coordinate system and passing through the occipital condylar point.
FOYTP	The force applied by the neck to the head along the y-axis of the T_0 coordinate system and passing through the occipital condylar point.
FOZTP	The force applied by the neck to the head along the z-axis of the T_0 coordinate system and passing through the occipital condylar point.
PSI	The angle between the y-axis of the T_0 coordinate system and the projection of the y-axis of the head anatomical coordinate system onto the x-y plane of the T_0 coordinate system.

FORTRAN
SYMBOL

DEFINITION

RATIP	The distance from the head anatomical origin to the T anatomical origin as derived from photographic data.
ROTIP	The distance from the occipital condylar to the T anatomical origin.
TENTYP	The angle between the z-axis of the T_0 coordinate system and the projection of the neck chord vector onto the x-z plane of the T_0 coordinate system.
TENTXP	The angle between the neck chord vector and the x-z plane of the T_0 coordinate system.
TETHNP	The angle between the y-axis of the head anatomical coordinate system and the projection of the y-axis of the T_0 coordinate system onto the y-y plane of the head anatomical coordinate systems.
THTIYP	The angle between the z-axis of the T_0 coordinate system and the projection of the z-axis of the head anatomical coordinate system onto the x-z plane of the T_0 coordinate system.
THTIXP	The angle between the z-axis of the head anatomical coordinate system and the x-z plane of the T_0 coordinate system.
TOXLP	The moment applied by the neck to the head about an axis parallel to the laboratory x-axis.
TOYLP	The moment applied by the neck to the head about an axis parallel to the laboratory y-axis.
TOZLP	The moment applied by the neck to the head about an axis parallel to the laboratory z-axis.
TOXP	The moment applied by the neck to the head axis that is parallel to the x-axis of the head anatomical coordinate system.
TOYP	The moment applied by the neck to the head axis that is parallel to the y-axis of the head anatomical coordinate system.
TOZP	The moment applied by the neck to the head axis that is parallel to the z-axis of the head anatomical coordinate system.
TOXTP	The moment applied by the neck to the head about an axis parallel to the z-axis of the T_0 coordinate system.
TOYTP	The moment applied by the neck to the head about an axis parallel to the y-axis of the T_0 coordinate system.
TOZTP	The moment applied by the neck to the head about an axis parallel to the z-axis of the T_0 coordinate system.
TIXTP	The moment applied by the torso to the neck about an axis parallel to the x-axis of the T_0 coordinate system.

FORTTRAN
SYMBOL

DEFINITION

T1YTP	The moment applied by the torso to the neck about an axis parallel to the y-axis of the T_0 coordinate system.
T1ZTP	The moment applied by the torso to the neck about an axis parallel to the z-axis of the T_0 coordinate system.

APPENDIX C

FORTRAN CODING OF THE DATA RETRIEVAL ANALYSIS AND DISPLAY SOFTWARE

The programs contained in this appendix are listed below. The general purpose programs listed are available on the NHTSA VAX in two locations; TSCPROGLIB and ASGPROGLIB.

COMP
XTRAC
XTRBLK
ACCDIS
DSPLAY
EXTRCT
DCIFER
DIRECT
STANDEV
STDCAL

SMEAN
MATH
MNMX
CURD
LABLE
SYMBOL
TITLE
DSP-WPAGE
DSP-OVERLAY
NCKNEW (NECK)
TRQPHOR (HEAD)

SUBROUTINE COMP

```

0001      *      SUBROUTINE COMP
0002      *      INCLUDE module for NCKPHO. FOR & TRQPHO. FOR
0003      *
0004      REAL DAXSOP(600), DAYSOP(600), DAZSOP(600), DNXSOP(600),
0005      &     DNYSOP(600), DNZSOP(600), PHAOXP(600), PHB02P(600), PHC03P(600),
0006      &     PNAOXP(600), PNB02P(600), PNC03P(600), TARRY(600), dcxsop(600)
0007      *
0008      COMMON /INDATA/ DAXSOP, DAYSOP, DAZSOP, DNXSOP, DNYSOP, DNZSOP,
0009      &     PHAOXP, PHB02P, PHC03P, PNAOXP, PNB02P, PNC03P, TARRY, DCXSOP
0010      *

```


SUBROUTINE XTRAC

```

        PROGRAM XTRAC
* XTRAC:
*      This is the VAX version of the DEC-10 Neck Data Analysis
*      Package originally written for Curt Spenny.
*
*      VAX conversion and enhancement by Doug Gordon
*      Tweaking, repairs, and further enhancement by
*      R. Stevens
*      SDC
*
*      Parameters for DCIFER.FOR

        BYTE UNITS2(100)
        INTEGER*2 NUMB2(100)
        INTEGER INDX83(41),INDX93(44),INDX96(1),NUM,SUB,RECNUM,
&      NMTMP(3),VARTMP,INDX44(4),INDX49(2),
&      INDX60(2),INDX64(6),INDX65(5),INDX67(5),WRDTMP
        REAL A(801),B(801),C(801),MAX2(100),MIN2(100),SINIT
        CHARACTER*6 NAME2(100),RUN2(100)
        CHARACTER*5 LISTH(9)
        CHARACTER NEWNAM*40
        character dname*132
        character filnam*30,varnam*6

        INCLUDE 'XTRBLK/LIST'
        include 'dsppltblk.for/list'

        DATA LIST/'EXT','UMA','ADD','SUB','DIR','END','CLE',
&      'FIL','CON','DIV','NOR','GET','DSP','STA'/
        DATA LIST2/'RUN','SUB'/
        DATA LIST3/'ALL'/
        DATA LIST4/'VAR'/

*      RUN NUMBERS

*      RUN NUMBERS

! Start of lateral test runs
        DATA LISTR/'LX1785','LX1793','LX1831','LX1860','LX1874',
&      'LX1916','LX1960','LX1998','LX2010','LX2013','LX2027',
&      'LX2032','LX2056','LX2060','LX2072','LX2090','LX2102',
&      'LX2124','LX2137','LX2148','LX2151','LX2182','LX2282',
&      'LX2294','LX2298','LX2302','LX2313','LX2326','LX2338',
&      'LX2341','LX2355',
&      'LX1454','LX1456','LX1457',
&      'LX1458','LX1468','LX1470','LX1475','LX1484','LX1487',
&      'LX1501','LX1503','LX1504','LX1505','LX1507','LX1509',
&      'LX1510','LX1512','LX1513','LX1524','LX1525','LX1526',
&      'LX1528','LX1471','LX1474',
! new nbd1 lateral test runs
&      'LX4050','LX4052','LX4053','LX4054','LX4055','LX4057',
&      'LX4058','LX4059','LX4060','LX4068','LX4069','LX4070',
&      'LX4071','LX4073','LX4074','LX4075','LX4076','LX4078',
&      'LX4079','LX4080','LX4081','LX4083','LX4084','LX4085',
&      'LX4088','LX4089','LX4090','LX4092','LX4093','LX4094',

```

```

& 'LX4095', 'LX4097', 'LX4098', 'LX4099', 'LX4100', 'LX4104',
& 'LX4107', 'LX4109', 'LX4110', 'LX4111', 'LX4115', 'LX4112',
& 'LX4114', 'LX4116', 'LX4118', 'LX4119', 'LX4120', 'LX4123',
& 'LX4124', 'LX4125', 'LX4126', 'LX4128', 'LX4129', 'LX4130',
& 'LX4131', 'LX4133', 'LX4134', 'LX4135', 'LX4137', 'LX4138',
& 'LX4139', 'LX4140', 'LX4142', 'LX4143', 'LX4144', 'LX4145',
& 'LX4147', 'LX4148', 'LX4149', 'LX4151', 'LX4153', 'LX4155',
! Start of oblique test runs
& 'LX2763', 'LX2770', 'LX2772', 'LX2784',
& 'LX2786', 'LX2799', 'LX2801', 'LX2813', 'LX2815', 'LX2827',
& 'LX2829', 'LX2843', 'LX2872', 'LX2876', 'LX2916', 'LX2955',
& 'LX2973', 'LX2979', 'LX2982', 'LX2985', 'LX2988', 'LX3049',
& 'LX3053', 'LX3061', 'LX3065', 'LX3077', 'LX3085', 'LX3089',
& 'LX3093', 'LX3097', 'LX3100', 'LX3102', 'LX3106', 'LX3122',
& 'LX3129', 'LX3133', 'LX3145', 'LX3148', 'LX3153', 'LX3158',
& 'LX3417',
! new nbd1 oblique test runs
& 'LX4159', 'LX4161', 'LX4162', 'LX4163', 'LX4164', 'LX4166',
& 'LX4167', 'LX4168', 'LX4170', 'LX4171', 'LX4172', 'LX4234',
& 'LX4235', 'LX4236', 'LX4237', 'LX4238', 'LX4240', 'LX4241',
& 'LX4242', 'LX4243', 'LX4244', 'LX4246', 'LX4247', 'LX4248',
& 'LX4249', 'LX4251', 'LX4259', 'LX4260', 'LX4261', 'LX4263',
& 'LX4264', 'LX4265', 'LX4266', 'LX4268', 'LX4269', 'LX4270',
& 'LX4271', 'LX4276', 'LX4277', 'LX4280', 'LX4303', 'LX4281',
& 'LX4282', 'LX4284', 'LX4286', 'LX4287', 'LX4288', 'LX4290',
& 'LX4291', 'LX4292', 'LX4293', 'LX4295', 'LX4296', 'LX4297',
& 'LX4298', 'LX4301', 'LX4302', 'LX4305', 'LX4306', 'LX4307',
& 'LX4309', 'LX4310', 'LX4313', 'LX4314', 'LX4316',
! Start of frontal test runs
& 'LX3524', 'LX3525', 'LX3530', 'LX3531', 'LX3536',
& 'LX3537', 'LX3544', 'LX3548', 'LX3550', 'LX3558', 'LX3573',
& 'LX3578', 'LX3583', 'LX3616', 'DOT307', 'DOT308', 'DOT309',
& 'DOT310', 'DOT314', 'DOT331', 'DOT332', 'DOT333', 'DOT343',
& 'DOT345',
! new nbd1 frontal test runs
& 'LX3801', 'LX3809', 'LX3824', 'LX3779', 'LX3780', 'LX3782',
& 'LX3783', 'LX3785', 'LX3786', 'LX3788', 'LX3789', 'LX3791',
& 'LX3793', 'LX3794', 'LX3796', 'LX3797', 'LX3798', 'LX3800',
& 'LX3803', 'LX3804', 'LX3805', 'LX3807', 'LX3808', 'LX3812',
& 'LX3814', 'LX3815', 'LX3817', 'LX3818', 'LX3819', 'LX3823',
& 'LX3821', 'LX3822', 'LX3851', 'LX3852', 'LX3833', 'LX3837',
& 'LX3839', 'LX3840', 'LX3841', 'LX3842', 'LX3872', 'LX3901',
& 'LX3918', 'LX3854', 'LX3856', 'LX3880', 'LX3890', 'LX3857',
& 'LX3858', 'LX3869', 'LX3870', 'LX3871', 'LX3875', 'LX3876',
& 'LX3878', 'LX3882', 'LX3883', 'LX3885', 'LX3886', 'LX3887',
& 'LX3889', 'LX3924', 'LX3893', 'LX3894', 'LX3895', 'LX3898',
& 'LX3903', 'LX3900', 'LX3904', 'LX3906', 'LX3908', 'LX3909',
& 'LX3913', 'LX3914', 'LX3916', 'LX3920', 'LX3921', 'LX3926',
& 'LX3927', 'LX3928', 'LX3942', 'LX3953', 'LX3962', 'LX3958',
& 'LX3939', 'LX3940', 'LX3941', 'LX3944', 'LX3945', 'LX3972',
& 'LX3982', 'LX3946', 'LX3948', 'LX3949', 'LX3950', 'LX3951',
& 'LX3954', 'LX3955', 'LX3957', 'LX3959', 'LX3961', 'LX3963',
& 'LX3965', 'LX3968', 'LX3969', 'LX3970', 'LX3983', 'LX3985',
& 'LX3986', 'LX3987', 'LX3989', 'LX3990', 'LX3991', 'LX3993',
& 'LX3994', 'LX3995', 'LX3997', 'LX3998', 'LX3999',

```



```

! new wsu data
& 'DOT453','DOT454','T76008','DOT455'/

* Subject Numbers
DATA LISTH/'H0083','H0093','H0096','H0044',
& 'H0049','H0060','H0064','H0065','H0067'/

* Variable Names
DATA LISTQ/'TIME','AAXXOS','AAYXOS','AAZXOS','QHA0XS',
& 'QHBOXS','QHCOXS','VAXXOS','VAXSOS','VAYXOS','VAYSOS',
& 'VAZXOS','VAZSOS','RHA0XS','RHBOXS','RHCOXS','DAXXOS',
& 'DAXSOS','DAYXOS','DAYSOS','DAZXOS','DAZSOS','PHA0XS',
& 'PHB02S','PHC03S','FH001S','FH002S','FH003S','FH004S',
& 'ANXXOS','ANYXOS','ANZXOS','QNA0XS','QNBOXS','QNC0XS',
& 'UNXXOS','UNXSOS','UNYXOS','UNYSOS','UNZXOS','UNZSOS',
& 'RNA0XS','RNBOXS','RNC0XS','DNXXOS','DNXSOS','DNYXOS',
& 'DNYSOS','DNZXOS','DNZSOS','FNA0XS','FNB02S','FNC03S',
& 'FN001S','FN002S','FN003S','FN004S','ACXXOS','VCXXOS',
& 'DCXXOS','VAXSOP','VAYSOP','VAZSOP','RHA0XP','RHBOXP',
& 'RHCOXP','DAXSOP','DAYSOP','DAZSOP','PHA0XP','PHB02P',
& 'PHC03P','FH001P','FH002P','FH003P','FH004P','UNXSOP',
& 'UNYSOP','UNZSOP','RNA0XP','RNBOXP','RNC0XP','DNXSOP',
& 'DNYSOP','DNZSOP','FNA0XP','FNB02P','FNC03P','DCXSOP',
& 'FN002P','FN003P','FN004P'/

* Subject Data
* Subject 83
DATA INDX83/1,2,3,4,7,8,10,11,14,16,17,18,19,20,26,30,32,
& 34,36,38,40,42,44,48,49,50,51,54,56,57,58,60,62,63,67,68,
& 70,73,75,77,79/

* Subject 93
DATA INDX93/5,6,9,12,13,15,21,22,23,24,27,28,29,31,33,35,
& 37,39,41,43,45,46,47,52,53,55,59,61,64,65,66,69,71,72,74,
& 76,78,80,81,82,83,84,85,86/

* Subject 96
DATA INDX96/25/

* Subject 44
DATA INDX44/90,98,103,108/

* Subject 49
DATA INDX49/92,110/

* Subject 64
DATA INDX64/88,109,96,100,104,105/

* Subject 60
DATA INDX60/91,93/

* Subject 65
DATA INDX65/87,95,99,102,107/

* Subject 67
DATA INDX67/89,94,97,101,106/

* Array to indicate how to obtain data
* =0 Data is on file
* =1 Integrate once
* =2 Integrate twice
DATA CREAT/7*0,1,0,1,0,1,4*0,2,1,2,1,2,1,13*0,1,0,1,0,1,4*0,
& 2,1,2,1,2,1,8*0,1,2,3*1,13*0,3*1,13*0/

* Gives variable number stored on file used to create values
DATA ORIG/1,20,21,22,23,24,25,20,11,21,12,22,13,14,16,18,20,

```



```

&      11,21,12,22,13,5,7,9,26,28,30,32,52,53,54,55,56,57,52,43,
&      53,44,54,45,46,48,50,52,43,53,44,54,45,37,39,41,58,50,62,
&      64,66,66,66,2,3,4,15,17,19,2,3,4,6,8,10,27,29,31,33,34,35,
&      36,47,49,51,34,35,36,38,40,42,59,61,63,65/
*      Unit types for DISPLAY labels
      DATA UNITYP/4,3*3,3*7,6*2,3*8,6*1,3*5,4*9,3*3,3*7,6*2,3*8,
&      6*1,3*5,4*9,3,2,1,3*2,3*8,3*1,3*5,4*9,3*2,3*8,3*1,3*5,4*9/
*      Flags for 0=Sensor 1=Photo
      DATA PHOTO/60*0,32*1/

***
***      START OF EXECUTABLE CODE
***

      KSTAT=LIB$INIT_TIMER()
      in_flags = 0
      call plot_questions(in_flags, dsplay$out_flags)
      WRITE(6,1000)
1000    FORMAT(/23X,'Spenny Neck Data Analysis Package',/)
      CALL OUTPUT_DATE_TIME(78)
      PRINT *
      SUB=0
      ICNT=0
      IFPLAC=0
      ISUB=0
      RECNUM=0
      IBLANK=0
      OPEN(UNIT=1,FILE='SCRTCH',STATUS='UNKNOWN',ACCESS='DIRECT',
&      MAXREC=MREC,RECL=RECL,ORGANIZATION='RELATIVE',ERR=05)
      READ(1,REC=1,ERR=10) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
      CLOSE(UNIT=1)
10      NEXTRD=1
      WRITE(6,1010)
1010    FORMAT(1X,'XTR> ',*)
      IOPT1=0
      CALL DCIFER(3,14,LIST)
      IF(WHAT.EQ.1) THEN
          GOTO 10
      ELSE IF(WHAT.NE.5) THEN
          WRITE(6,1020)
1020    FORMAT(1X,'Sorry - Cannot identify this command',/1X,
&      'Commands are:  EXTRACT  ADD  SUBTRACT  VMAGNITUDE',/1X,
&      ',  CONSTANT  NORMALIZE  DIVIDE  DISPLAY',/1X,
&      'DIRECTORY  CLEAR  FILE  END',/1X,
&      'GET'/)
          WRITE(6,1030)
1030    FORMAT(1X,'Please re-enter complete line'/)
          GOTO 10
      ENDIF
      OPEN(UNIT=1,FILE='SCRTCH',STATUS='UNKNOWN',ACCESS='DIRECT',
&      MAXREC=MREC,RECL=RECL,ORGANIZATION='RELATIVE',ERR=05)
      NEXTRD=0
      GOTO(110,120,120,120,170,190,20,30,130,130,130,
&      140,180,181),WRDNUM
      WRITE(6,1040)
1040    FORMAT(/1X'[Internal Confusion...]'/)

```

```

        STOP  (Please Call a Programmer...)'

*      'CLEAR' Command

20      NEXTRD=0
        CALL DCIFER(3,1,DUM)
        IF(WHAT.NE.2) NVAR=0
        IF(WHAT.EQ.2) NVAR=IVAL
        WRITE(1,REC=1) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
        CLOSE(UNIT=1)
        GOTO 10

*      'FILE' Command:
30      READ(1,REC=1) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
        CALL DCIFER(3,1,DUMMY)
        IF(WHAT.NE.7) GOTO 100
        NEWNAM=IMAGE(FCHAR:LCHAR)
        OPEN(UNIT=20,FILE=NEWNAM,STATUS='UNKNOWN',ACCESS='DIRECT',
&          MAXREC=MREC,RECL=RECLN,ORGANIZATION='RELATIVE',ERR=100)
        WRITE(6,1050)
1050     FORMAT(1X,'Variable #s or ALL> ',%)
        NEXTRD=1
        CALL DCIFER(3,1,LIST3)
        print *, 'what=',what
        IF(WHAT.EQ.5) THEN
            GOTO 80
        ELSE IF(WHAT.EQ.2) THEN
            NEXTRD=0
            GOTO 40
        ELSE
            WRITE(6,1060)
1060     FORMAT(1X,'Variables must be input by directory number',/,
&          1X,' or ALL - FILE command ignored.'//)
            GOTO 70
        ENDIF
40      READ(20,REC=1,ERR=50) NUMVAR,NAME2,RUN2,MAX2,MIN2,UNITS2,NUMB2
        GOTO 60
50      NUMVAR=0
60      IF(IVAL.GT.NVAR) THEN
            WRITE(6,1070) IVAL
1070     FORMAT(1X,'Variable number ',I2,' exceeds number of ',
&          'variables extracted - Check directory.',/1X,
&          'Copy stopped at previous variable.'//)
            GOTO 70
        ENDIF
        KOUNT=NUMVAR+1
        if(kount.gt.99)then
            write(6,1071)kount
1071     format(1x,'Variable number ',i3,'exceeds maximum number'//
&          1x,'that can be filed (100).')
&          1x,'Copy stopped at previous variable.')
            goto 70
        endif
        RUN2(KOUNT)=RUN(IVAL)
        NAME2(KOUNT)=NAME(IVAL)

```

```

MAX2(KOUNT)=MAX(IVAL)
MIN2(KOUNT)=MIN(IVAL)
UNITS2(KOUNT)=UNITS(IVAL)
NUMB2(KOUNT)=NUMB(IVAL)
READ(UNIT=1,REC=IVAL+1) (E(II),II=1,NUMB(IVAL))
WRITE(20,REC=kount+1) (E(II),II=1,NUMB(IVAL))
NUMVAR=NUMVAR+1
ISAVQ=IVAL
CALL DCIFER(3,1,DUMMY)
IF(WHAT.EQ.1) THEN
    GOTO 70
ELSE IF(WHAT.EQ.2) THEN
    GOTO 60
ELSE
    WRITE(6,1080) ISAVQ
1080    FORMAT(1X,'Illegal characters found in variable ',
    &        'specification line - Last variable transferred',/1X,
    &        'was ',I2//)
    ENDIF
70    WRITE(20,REC=1) NUMVAR,NAME2,RUN2,MAX2,MIN2,UNITS2,NUMB2
    CLOSE(UNIT=20)
    CLOSE(UNIT=1)
    GOTO 10

*    ALL variables selected on FILE
*    Append to NEWNAM
80    NUMVAR=0
    READ(20,REC=1,ERR=90) NUMVAR,NAME2,RUN2,MAX2,MIN2,UNITS2,NUMB2
90    IF(NUMVAR+NVAR.GT.100) THEN
    WRITE(6,1090)
1090    FORMAT(/1X,'Appending to the specified file will create ',
    &        'more than 100 variables.'/1X,'FILE command aborted - ',
    &        'Please choose another file...'/)
    WRITE(6,1030)
    GOTO 10
    ENDIF
    DO II=1,NVAR
        KOUNT=II+NUMVAR
        RUN2(KOUNT)=RUN(II)
        NAME2(KOUNT)=NAME(II)
        MAX2(KOUNT)=MAX(II)
        MIN2(KOUNT)=MIN(II)
        UNITS2(KOUNT)=UNITS(II)
        NUMB2(KOUNT)=NUMB(II)
        READ(UNIT=1,REC=II+1) (E(N),N=1,NUMB(II))
        WRITE(20,REC=kount+1) (E(N),N=1,NUMB(II))
    END DO
    N=NVAR+NUMVAR
    WRITE(20,REC=1) N,NAME2,RUN2,MAX2,MIN2,UNITS2,NUMB2
    CLOSE(UNIT=20)
    CLOSE(UNIT=1)
    GOTO 10

100    WRITE(6,1100)
1100    FORMAT(/1X,'An error has occurred in the file specification',

```

```

      & /1X,'Please specify the file in quotes using VAX conventions'
      GOTO 10

*
*   EXTRACT command:
110   CALL EXTRACT
      GOTO 10

*
*   First three MATH commands
*
120   ICMD=WRDNUM-5                      ! changed 1 to 5
      NEXTRD=0
      CALL MATH(ICMD)
      GOTO 10

*
*   Last three MATH commands
*
130   ICMD=WRDNUM-5
      CALL MATH(ICMD)
      GOTO 10

*
*   The 'GET' command - read a SCRTCH format file into SCRTCH.DAT
*
140   CALL DCIFER(9,1,DUMMY)
      IF(WHAT.NE.7) THEN
          WRITE(6,1100)
          WRITE(6,1030)
          GOTO 10
      ENDIF
      NEWNAM=IMAGE(FCHAR:LCHAR)
      OPEN(UNIT=21,FILE=NEWNAM,STATUS='OLD',ACCESS='DIRECT',
      &     MAXREC=MREC,RECL=RECL,ORGANIZATION='RELATIVE',ERR=150,
      &     readonly,defaultfile='xtrac$db:.dat')
      GOTO 160
150   WRITE(6,1110) NEWNAM(1:LLEN(NEWNAM))
1110  FORMAT(/1X,'The file ',A,' does not exist or is not in SCRTCH
      & ' format. GET command ignored.')
      GOTO 10

*
*   The file exists, so delete the current SCRTCH.DAT, and then
*   copy the new file in.
*
160   CLOSE(UNIT=1,DISP='DELETE')
      OPEN(UNIT=1,FILE='SCRTCH',STATUS='NEW',ACCESS='DIRECT',
      &     MAXREC=MREC,RECL=RECL,ORGANIZATION='RELATIVE')
      READ(21,REC=1) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
      WRITE(1,REC=1) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
      DO JNK=2,NVAR+1
          READ(UNIT=21,REC=JNK)(E(II),II=1,NUMB(JNK-1))
          WRITE(1,REC=JNK)(E(II),II=1,NUMB(JNK-1))
      END DO
      CLOSE(UNIT=21)
      WRITE(6,1120) NEWNAM(1:LLEN(NEWNAM))
1120  FORMAT(/1X,A,' successfully copied'/)
      GOTO 10

*

```



```

*      'DIR' command
*
170    CALL DIRECT
      GOTO 10
*
*      DSPLAY subsystem - see documentation in DSPLAY.FOR
*
180    CALL DSPLAY
      GOTO 10
*
*      'STA'
*
181    filnam='scrтч.dat'
      image=image(ic:lchar)
      call baway(image)
      varnam=image(1:llen(image))
      call standev(filnam,varnam)
      goto 10
*
*
05     call getdir(dname)
      write(6,1125)dname(1:llen(dname))
1125   format(1x,'Error opening scrтч file in directory :',a/
&       1x,'Cannot continue execution.')
190    WRITE(6,1130)
1130   FORMAT(/1X,'End of execution - XTRAC'/)
      CALL LIB$SHOW_TIMER(,1)          ! Elapsed time
      CALL LIB$SHOW_TIMER(,2)          ! CPU time
      CALL LIB$SHOW_TIMER(,5)          ! Page faults
      END

```


SUBROUTINE XTRBLK

```

SUBROUTINE XTRBLK
0001      BYTE UNITS(100), PHOTO(92)
0002      INTEGER*2 NUMB(100)
0003      INTEGER CREAT(92), ORIG(92), UNITYP(92), RECLN, MREC, NVAR, WHAT,
0004      &      FCHAR, WRDNUM, IVAL
0005      REAL MAX(100), MIN(100), E(598), TARRAY(598)
0006      CHARACTER*6 NAME(100), RUN(100), LISTR(380), LISTQ(92)
0007      CHARACTER*3 LIST(14), LIST2(2), LIST3, LIST4
0008      CHARACTER*10 XRUN, ID, TEST, IMAGE*80
0009
0010      COMMON /INPUT/  IMAGE, NEXTRD, IC, FCHAR, LCHAR, WHAT, LSTPOS,
0011      &      WRDNUM, IVAL, VALUE
0012      COMMON /HEADER/ NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
0013      COMMON /INPEXT/ TARRAY, E
0014      COMMON /PHOTON/ PHOTO
0015      COMMON /DICTIO/ LISTR, LISTQ, LIST, LIST2, LIST3, LIST4
0016      COMMON /VARATT/ CREAT, ORIG, UNITYP
0017
0018      PARAMETER (MREC=101)
0019      PARAMETER (RECLN=598)
0020

```


SUBROUTINE ACCDIS

```

0001
0002 *****
0003 *****
0004 SUBROUTINE ACCDIS(SINIT, B, A, VINIT, IOPT1, PHOTO, NUM, TARRAY)
0005 * ACCDIS: Douglas A. Gordon
0006 * Arcon Corporation
0007 *
0008 * Calculate velocities and displacements from
0009 * accelerations (sensor data) or velocities from
0010 * displacements (photographic data)
0011 *
0012 * - A(i) is input (accelerations or displacements)
0013 * V(i) is requested output in REAL*8 format
0014 * B(i) is requested output returned as REAL*4
0015 * TARRAY(i) is variable time step array for photo data
0016 * SINIT is initial displacement @ time T=0
0017 * VINIT is initial velocity @ time T=0
0018 * IOPT1 = 1, calculate velocities
0019 * = 2, calculate displacements
0020 * PHOTO = 1, for photographic data (variable time step)
0021 *
0022 BYTE PHOTO
0023 REAL A(NUM), B(NUM), TARRAY(NUM)
0024 REAL*8 DELT, V(801), S(801), q, q1
0025
0026 K=NUM-1
0027 IF(PHOTO.EQ.1) GOTO 3
0028 DELT=0.0005/2.
0029 IF(IOPT1.EQ.2) GOTO 2
0030 *
0031 * Calculate velocities from accelerations. (sensor)
0032 *
0033 V(1)=DBLE(VINIT)
0034
0035 DO I=1,K
0036 V(I+1)=V(I)+DELT*DBLE((A(I)+A(I+1)))
0037 END DO
0038 GOTO 5
0039 *
0040 * Calculate displacements from accelerations (sensor)
0041 *
0042 2 V(1)=DBLE(SINIT)
0043 S(1)=DBLE(VINIT)
0044 DO I=1,K
0045 II=I+1
0046 Q=DELT*DBLE((A(I)+A(II)))
0047 S(II)=S(I)+Q
0048 Q1=DELT*(S(I)+S(II))
0049 V(II)=V(I)+Q1
0050 END DO
0051 GOTO 5
0052 *
0053 * Calculate velocities from displacements with variable time
0054 * step (photo)
0055 *
0056 3 V(1)=VINIT
0057 DO I=1,K

```

```

0058         DELT=TARRAY(I+1)-TARRAY(I)
0059         V(I+1)=(A(I+1)-A(I))/DELT
0060     END DO
0061     *
0062     *     Copy REAL*8 array V into REAL*4 array B for return to main
0063     *     program
0064     *
0065     5     DO I=1,NUM
0066         B(I)=V(I)
0067     END DO
0068     RETURN
0069     END

```


SUBROUTINE DSPLAY

```

*****
*****
SUBROUTINE DSPLAY
* DSP: Douglas A. Gordon
* Arcon Corporation
*
* Plotting module of the Spenny Neck Analysis Package.
* Currently supported with the TEKTRONIX TCS package, the
* original used DISSPLA, and will never be converted to
* that in the future. There is no 3-D plotting under TCS.
*
integer*4 dsplay$num_cmds
parameter (dsplay$num_cmds = 11)

byte already_lasered/.false./, plotted_something, delete_it,
& copy_it
INTEGER*4 READ1,READ2,XTMPLB,YTMPLB,ZTMPLB,I3READ(4),RECLN,
& RECNM,PLST(20,4),PLST3(20,5),N3PNT(3),NPLOT,N3PLOT,KPLOT,
& BAUDQ, points(20), out_flags, tt_lun, submit_laser_file
REAL XMAX2,XMAX3,XMIN2,XMIN3,YMIN2,YMIN3,YMAX2,YMAX3,ZMAX3,
& ZMIN3,ARRAY1(598),ARRAY2(598),ARRAY3(598),-xplt(598,20),
& yplt(598,20)
CHARACTER TTL*30,dans*1, laser_file*252
CHARACTER*3 LISTD(dsplay$num_cmds),LISTD1,LISTD2
CHARACTER*10 RNTMP,XLABEL,YLABEL,ZLABEL,DUMMY,NAMTMP,
& LABEL(0:9),rntmps(20)
byte quit

INCLUDE 'XTRBLK/LIST'
include 'pltdef.for/list'
include 'dsppltblk.for/list'

*
DATA LISTD/'DIR','PLO','PL3','DIS','END','XTR','COP','XSC',
& 'YSC','LAS','FIG'//
DATA DUMMY//
DATA LISTD1/'RUN'//
DATA LISTD2/'TIM'//
DATA LABEL/' ','METERS','M/SEC','M/SEC*SEC','TIME','RADIAN',
& 'NEWTON-M','RAD/SEC*2','RADIANT/SEC','NEWTONS'//
*** START OF EXECUTABLE CODE
out_flags = plt$m_box + plt$m_xline + plt$m_yline + plt$m_nosym
delete_it = .true.
copy_it = .false.

* The scratch file is opened and the dictionary information
* is read from the first record.
* NVAR = number of variables
* NAME,
* RUN = arrays of 100 6 character fields, var names & runs
* MAX,
* MIN = arrays of 100 reals, min or max for each NAME
* UNITS = array of 100 bytes containing #'s 1-7
* NUMB = array of number of points for the NAME list
OPEN(UNIT=1,FILE='SCRATCH',STATUS='OLD',ACCESS='DIRECT',
& MAXREC=MREC,RECL=RECLN,ORGANIZATION='RELATIVE',
& IOSTAT=IOS)

```

```

      READ(1,REC=1,IOSTAT=IOS) NVAR,NAME,RUN,MAX,MIN,UNITS,
&      NUMB
      MARK=0
      NPLOT=0
      IVARN=0
      IWORD=0
      RECNM=0
      N3PLOT=0
      KPLOT=0
      quit=.false.
*
10      NEXTRD=1                                ! read new card, next field!
      WRITE(6,1000)
1000     FORMAT(1X,'DSP> ',%)
      CALL DCIFER(3,dsplay$num_cmds,LISTD)
      NEXTRD=0                                ! read same card, next field!
      IF(WHAT.EQ.5)
&      GOTO(20,30,240,250,690,680,251,3000,3010,3050,3030),WRDNUM

      IF(WHAT.EQ.1) GOTO 10                    ! if end of card!
      WRITE(6,1010)                           ! otherwise...!
      WRITE(6,1020)
1010     FORMAT(1X,'Sorry - cannot identify this command',/
&      1x,'Commands are:  PLOT    PL3D    DIRECTORY DISPLAY',/
&      1x,'                  XTRAC   COPY    XSCALE   YSCALE',/
&      1x,'                  LASER   FIGURE  END'/)
1020     FORMAT(1X,'Please re-enter complete line',/,1x)
      GOTO 10
*****
*** 'DIRECTORY'
*
20      CALL DIRECT
      GOTO 10
*****
*** 'PLOT'
*
30      CALL DCIFER(3,1,LISTD1)                ! look for RUN following PLOT!
      IF(WHAT.NE.5) then
          rntmp=dummy
          ic=lstpos
      else
          CALL DCIFER(6,NVAR,RUN)              ! check for valid run in dic.!
          if(what.eq.5) then
              rntmp=run(wrdnum)
          else
              WRITE(6,1030)
              WRITE(6,1020)
1030      FORMAT(/1X,'Run number must follow the identifier RUN'/)
              goto 10
          endif
      endif
*
60      call dcifer(3,1,listd2)
      if(what.eq.5) then                        ! first var is time
          read1=999

```

```

call dcifer(3,1,listd2)
if(what.eq.5)then                                ! second var is time
  read2=999
  goto 110
else                                              ! second var not time
  ic=lstpos
  do j=1,nvar
    if(run(j).eq.rntmp)then                      ! if same run #
      namtmp=name(j)
      call dcifer(6,1,namtmp)                   ! check for right var
      if(what.eq.5)goto 100                     ! right var
      ic=lstpos                                 ! keep looking
    endif
  enddo
  write(6,1040)                                ! 2nd not in scrctch
  write(6,1050)
  write(6,1020)
  goto 10
endif
else                                              ! first var not time
  ic=lstpos
  do i=1,nvar
    if(run(i).eq.rntmp)then                      ! check for right run
      namtmp=name(i)
      call dcifer(6,1,namtmp)                   ! check for right var
      if(what.eq.5)then                         ! if right var
        read1=i
        call dcifer(3,1,listd2)                ! second var time ?
        if(what.eq.5)then                       ! it is time
          read2=999
          goto 110
        else                                    ! it isn't time
          ic=lstpos
          do j=1,nvar                          ! look for var in scrctch
            if(run(j).eq.rntmp)then
              namtmp=name(j)
              call dcifer(6,1,namtmp)
              if(what.eq.5) goto 100
            endif
          enddo
          write(6,1040)
          write(6,1050)
          write(6,1020)
          goto 10
        endif
      endif
      ic=lstpos
    endif
  enddo
  write(6,1040)
  write(6,1050)
  write(6,1020)
  goto 10
endif

```



```

endif
1040 format(/1x,'Input processing shows a run/variable mismatch'//)
1050 format(1x,'For run/variable info use the DIRECTORY command'//)
*
100 READ2=J
*
110 IF(READ1.NE.READ2) GOTO 120
WRITE(6,1060)
WRITE(6,1020)
1060 FORMAT(/1x,'There really is no sense in plotting the same
& variables')
GOTO 10
*
120 CALL DCIFER(3,1,DUMMY)
if(what.ne.2.and.what.ne.1)then ! non-integer marker
write(6,1069)
1069 format(1x,'An integer is required for marker value (0-8)'
&/1x,'Please try again...',//)
goto 10
else IF(WHAT.EQ.2.AND.IVAL.LE.8)then ! a proper marker value
goto 130
else if(what.eq.2.and.ival.gt.8)then ! marker values only to 8
WRITE(6,1070)
1070 FORMAT(1x,'Marker values are in the range of 0-8 (integer)'
& /1x,'Please try again...',//)
goto 10
else ! value blank, use 0
IVAL=0
endif
*
130 MARKER=IVAL
IF(NPLOT.LE.0) GOTO 140
*
* This section is commented out to allow plotting of
* different variables.
*
140 NPNT1=0
NPNT2=0
150 IF(READ1.NE.999) NPNT1=NUMB(READ1)
IF(READ2.NE.999) NPNT2=NUMB(READ2)
IF(READ1.NE.999.AND.READ2.NE.999) GOTO 190
*
* ARRIVED HERE BECAUSE ONE VARIABLE IS 'TIME'
*
IF(NPNT1.NE.598.AND.NPNT2.NE.598) GOTO 160
NPNT1=598
NPNT2=598
GOTO 190
*
160 DO 170 IJ=1,NVAR
IF((NAME(IJ).EQ.'TIME'.AND.RUN(IJ).EQ.RNTMP).or.
& (rntmp.eq.dummy)) GOTO 180
170 CONTINUE
WRITE(6,1100)
GOTO 10

```

```

*
180  IF(READ1.EQ.999) read1=IJ
    IF(READ2.EQ.999) READ2=IJ
    GOTO 150
*
*      CHECK  FOR  BOUNDED PLOT
*
190  CALL DCIFER(3,1,DUM)
    IF(WHAT.EQ.1) GOTO 210
    IF(WHAT.NE.2) GOTO 200
    NPNT1=IVAL
    READ(1,REC=READ1+1)ARRAY1
    CALL MNMX(ARRAY1,MIN,MAX,READ1,NPNT1)
    NPNT2=IVAL -
    READ(1,REC=READ2+1)ARRAY1
    CALL MNMX(ARRAY1,MIN,MAX,READ2,NPNT2)
    WRITE(1,REC=1)NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
    GOTO 210
*
200  WRITE(6,1080)
1080  FORMAT(1X,'Unrecognized user input following plot symbol',
    &' ignored')
*
210  IF(NPNT1.EQ.NPNT2) GOTO 220
    WRITE(6,1090)
1090  FORMAT(1X,'A mismatch between the number of points '
    &',' to be plotted has been discovered.'/,
    &' the PLOT command will be ignored !',/)
    GOTO 10
*
220  NPNT=NPNT1
    NPLOT=NPLOT+1
    rntmps(npplot)=rntmp
    PLST(NPLOT,1)=READ1
    PLST(NPLOT,2)=READ2
    PLST(NPLOT,3)=MARKER
    PLST(NPLOT,4)=NPNT
230  GOTO 10
1100  format(1x,'TIME variable for photographic data is not in the',/
    &' SCRATCH file directory',/'PLOT request is ignored',/)
*****
***  'DISPLAY'
*
250  IF(NPLOT.EQ.0) GOTO 640
    IF(PLST(1,1).EQ.999) THEN
        dsplay$xmin = 0.0
        dsplay$xmax = 0.3
        dsplay$incx = 3
        out_flags = out_flags + plt$m_xscale
    ENDIF
    IF(PLST(1,2).EQ.999) THEN
        dsplay$ymin = 0.0
        dsplay$ymax = 0.3
        dsplay$incy = 3
        out_flags = out_flags + plt$m_yscale

```

ENDIF

*
*
*

Start the plot

TTL(21:30)=' '

ITLEN=20

IF(PLST(1,1).EQ.999) THEN

TTL(1:10)='TIME'

ELSE

TTL(1:10)=NAME(PLST(1,1))

ENDIF

IF(PLST(1,2).EQ.999) THEN

TTL(11:20)='TIME'

ELSE

TTL(11:20)=NAME(PLST(1,2))

ENDIF

IF(NPLOT.EQ.1) THEN

ITLEN=30

IF(PLST(1,1).NE.999) THEN

TTL(21:30)=RUN(PLST(1,1))

ELSEIF(PLST(1,2).NE.999) THEN

TTL(21:30)=RUN(PLST(1,2))

ELSE

ITLEN=20

ENDIF

ENDIF

260 IF(PLST(1,1).EQ.999) THEN

XTMPLB=4

ELSE

XTMPLB=UNITS(PLST(1,1))

ENDIF

IF(PLST(1,2).EQ.999) THEN

YTMPLB=4

ELSE

YTMPLB=UNITS(PLST(1,2))

ENDIF

XLABEL=LABEL(XTMPLB)

YLABEL=LABEL(YTMPLB)

YPOS=9.2

quit=.false.

DO IQ=1,NPLOT

IF(PLST(IQ,1).EQ.999) GOTO 270

RECNM=PLST(IQ,1)+1

READ(1,REC=RECNM)ARRAY1

GOTO 290

270 ARRAY1(1)=0.0

TIME=.0005

DO IK=2,598

ARRAY1(IK)=ARRAY1(IK-1)+TIME

end do

```

290     IF(PLST(IQ,2).EQ.999) GOTO 300
        RECNM=PLST(IQ,2)+1
        READ(1,REC=RECNM)ARRAY2
        GOTO 320

300     ARRAY2(1)=0.0
        TIME=.0005
        DO IS=2,598
            ARRAY2(IS)=ARRAY2(IS-1)+TIME
        end do
320     call lib$move3(2392, array1, xplt(1,iq))
        call lib$move3(2392, array2, yplt(1,iq))
        points(iq) = plst(iq,4)
    end do

    if(already_lasered) then
        ttl = ' '
        xlabel = ' '
        ylabel = ' '
    else
        if((dsplay$out_flags .and. plt$m_vt240) .ne. 0)
&         call vt200_set_mode(4)
    endif

    call dsp_overlay(xplt, yplt, points, nplot, 598, 0, ttl,
&     xlabel, ylabel, out_flags)

    do iq = 1, nplot
        if(plst(iq,1).eq.999)then
            call lable(rntmps(iq),'TIME ',name(plst(iq,2)),
&             quit,plst(iq,3))
        else if(plst(iq,2).eq.999)then
            call lable(rntmps(iq),name(plst(iq,1)),'TIME ',
&             quit,plst(iq,3))
        else
&             call lable(rntmps(iq),name(plst(iq,1)),
&             name(plst(iq,2)),quit,plst(iq,3))
        endif

        close(unit=87) ...
    end do
    quit=.true.
    if(read1 .eq. 999) read1 = 1
    if(read2 .eq. 999) read2 = 1
    call lable(rntmp,name(read1),name(read2),quit)
    if(.not. already_lasered) then
        if(copy_it) then
            call hdcopy
        else
            call plhold
        endif
        call newpag
        if((dsplay$out_flags .and. plt$m_vt240) .ne. 0) then
            call vt200_set_mode(5)
        endif
    end if

```



```

endif
  plotted_something = .true.
  out_flags = plt$m_box + plt$m_xline + plt$m_yline + plt$m_nosym
  copy_it = .false.
  GOTO 660
*****
*** 'XSCALE'
*
  3000   its_x = .true.
        goto 3020
*****
*** 'YSCALE'
*
  3010   its_x = .false.
  3020   call dcifer(3,1,dummy)           ! min axis value
        if(what .eq. 3) then
          qtmp1 = value
        else
          goto 4000
        endif

        call dcifer(3,1,dummy)           ! max axis value
        if(what .eq. 3) then
          qtmp2 = value
        else
          goto 4000
        endif

        call dcifer(3,1,dummy)           ! num tic marks
        if(what .eq. 2) then
          iqtmp = ival
        else
          goto 4000
        endif

        if(its_x) then
          dsplay$xmin = qtmp1
          dsplay$xmax = qtmp2
          dsplay$incx = iqtmp
          out_flags = out_flags + plt$m_xscale
        else
          dsplay$ymin = qtmp1
          dsplay$ymax = qtmp2
          dsplay$incy = iqtmp
          out_flags = out_flags + plt$m_yscale
        endif
        goto 10
  4000   write(6,4010)
  4010   format(1x,'Format for XSCALE & YSCALE is: '//
    &      1x,'COMMAND <min-value> <max-value> <tic-marks>')
        write(6,1020)
        goto 10
*****
*** 'FIGURE'
*

```

```

3030    call dcifer(32,1,dummy)
      if(what .eq. 7) then
        display$figure = image(fchar:lchar)
      else
        write(6,3040)
3040    format(1x,'Figure title must be enclosed in single quotes')
        write(6,1020)
      endif
      goto 10
*****
*** 'LASER'
*
3050    if(already_lasered) then
      write(6,3060)
3060    format(1x,'The laser command has already been issued')
      goto 10
    endif
    already_lasered = .true.
    out_flags = out_flags + plt$m_laser
    call setup_laser_file(' ', laser_file)
    write(6,3070) laser_file(1:llen(laser_file))
3070    format(1x,'Output plot file is ',a)
    plotted_something = .false.
    goto 10
*****
*** 'copy'
*
251    copy_it = .true.
      goto 250
*
640    write(6,1120)
1120    format(/1x,'Nothing to plot ! ')
      nplot=0
      goto 10
*
660    NPLOT=0
      N3PLOT=0
      KPLOT=KPLOT+1
      IF(KPLOT.GE.2) KPLOT=0
      GOTO 10
*****
*** 'PL3D'
*
240    print *
      print *, '3-D plotting not currently supported'
      print *
      goto 10

670    WRITE(6,1130)
1130    FORMAT(/1X,'Error OPENing or REAding SCRTCH -')
      CALL IOSMSG(IOS)
680    WRITE(6,1140)
1140    FORMAT(/1X,'Returning to XTRAC'/)
      RETURN
690    if(already_lasered) then

```

```

        if(plotted_something) then
            istat = submit_laser_file('SYS$MANAGER:TEKTRONIX.LIS',
&            laser_file, delete_it)
        else
            inquire(file='tt',number=tt_lun)
            close(unit=tt_lun,disp='delete')
        endif
    endif
    WRITE(6,1150)
1150  FORMAT(/1X,'End of execution - XTRAC/DSPRAY'/)
    CALL LIB$SHOW_TIMER()
    call sys$exit(%val(1))
    END

```


SUBROUTINE EXTRCT

SUBROUTINE EXTRCT

* EXTRCT: Douglas A. Gordon
* Arcon Corporation
*

* The EXTRACT command for XTRAC.FOR. This is the data read
* routine for the Spenny Neck Analysis package. The .EXT files
* are binary files containing 66 of the original 92 variables.
* Missing variables are obtained through integration or
* differentiation of existing variables.
*

REAL A(598)
CHARACTER FILENM*10

INCLUDE 'XTRBLK/LIST'

*
* Check next word
*

NEXTRD=0
CALL DCIFER(3,2,LIST2)
IF(WHAT.NE.5) THEN
WRITE(6,1000)
1000 FORMAT(1X,'The word RUN or SUB must follow EXTRACT'/)
WRITE(6,1010)
1010 FORMAT(1X,'Please re-enter complete line')
RETURN
ENDIF

* word was run or sub - check to see if next word is ALL
NWORD=WRDNUM
CALL DCIFER(3,1,LIST3)
IF(WHAT.EQ.5) THEN
IRUN=999
ISUB=0
GOTO 30
ENDIF
IC=LSTPOS
IF(NWORD.EQ.2) GOTO 10
CALL DCIFER(6,380,LISTR) !Check for correct run #
IF(WHAT.NE.5) THEN
WRITE(6,1020)
1020 FORMAT(1X,'The run number is not valid')
WRITE(6,1010)
RETURN
ENDIF
IFPLAC=WRDNUM
GOTO 20

* check subject numbers
10 CALL DCIFER(6,9,LISTH)
IF(WHAT.NE.5) THEN
WRITE(6,1030)
1030 FORMAT(1X,'The subject number is invalid')
WRITE(6,1010)


```

        CALL ACCDIS(SINIT,A,E,VINIT,IOPT1,PHOTO(IUNM),NUM,TARRAY)
        DO ITX=1,NUM
            E(ITX)=A(ITX)
        END DO
    ENDIF
    OPEN(UNIT=1,FILE='SCRATCH',STATUS='UNKNOWN',ACCESS='DIRECT',
    & RECL=RECLEN,ORGANIZATION='RELATIVE',ERR=80,IOSTAT=JXS,
    & MAXREC=MREC)
    NVAR=NVAR+1
    if(nvar.gt.100)then
        write(6,1065)name(nvar-1)
1065    format(1x,'Attempt to EXTRACT more than 100 variables -',
    & /1x,'EXTRACT stopped at variable ',a/)
        nvar=nvar-1
        return
    endif
    NAME(NVAR)=LISTQ(IUNM)
    RUN(NVAR)=LISTR(IFPLAC)
    CALL MNMX(E,MIN,MAX,NVAR,NUM)
    UNITS(NVAR)=UNITYP(IUNM)
    NUMB(NVAR)=NUM
    WRITE(1,REC=1) NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
    IREC=NVAR+1
    WRITE(1,REC=IREC) (E(II),II=1,NUMB(NVAR))
    IF(IRUN.EQ.999.AND.IFPLAC.NE.92) GOTO 60
    RETURN
70    OPEN(UNIT=1,FILE='SCRATCH',STATUS='UNKNOWN',ACCESS='DIRECT',
    & RECL=RECLEN,ORGANIZATION='RELATIVE',ERR=80,IOSTAT=JXS,
    & MAXREC=MREC)
    PRINT *
    DO IDD=1,92
        RECNUM=ORIG(IDD)*2-1
        IF(ORIG(IDD).NE.1) THEN
            DO IEX=1,RECNUM-1
                READ(20)
            END DO
        ENDIF
        READ(20) NUM,XRUN,ID,TEST,SINIT,VINIT
!    print 3000,idd,num,xrun,id,test,sinit,vinit
3000    format(1x,i2,')',i6,1x,3a10,2g)
        NUM=MIN0(NUM,598)
        READ(20) (E(II),II=1,NUM)
        WRITE(6,1060) '*'
1060    FORMAT(1H+,A1,$)
        REWIND 20
        IF(CREAT(IDD).NE.0) THEN
            IOPT1=CREAT(IDD)
!    print *,'Calculating variable ',listq(idd)
            CALL ACCDIS(SINIT,A,E,VINIT,IOPT1,PHOTO(IDD),NUM,TARRAY)
            DO IXZ=1,NUM
                E(IXZ)=A(IXZ)
            END DO
        ENDIF
        NVAR=NVAR+1
        IF(NVAR.GT.100) THEN

```

```

1070      WRITE(6,1070) name(nvar-1)
      &      FORMAT(/1X,'Attempt to EXTRACT more than 100 variables -',
      &      /1X,'EXTRACT stopped at variable ',a/)
      RETURN
    ENDIF
    NAME(NVAR)=LISTQ(IDD)
    RUN(NVAR)=LISTR(IFPLAC)
    CALL MNMX(E,MIN,MAX,NVAR,NUM)
    UNITS(NVAR)=UNITYP(IDD)
    NUMB(NVAR)=NUM
    WRITE(1,REC=1)NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
    IREC=NVAR+1
    WRITE(1,REC=IREC) (E(I),I=1,NUMB(NVAR))
    END DO
    IF(IFPLAC.NE.110.AND.IRUN.EQ.999) GOTO 60
    RETURN
80    print *, 'OPEN ERROR'
    call iosmsg(jxs)
    return
90    PRINT *, 'No select by subject now...'
    RETURN
    END

```


SUBROUTINE DCIFER

```

0001          SUBROUTINE DCIFER(NCLST,NDICT,LIST)
0002      *      DCIFER:                                     Douglas A. Gordon
0003      *                                                    Arcon Corporation
0004      *
0005      *      Adapted for the VAX from the similar package on the TSC
0006      *      DEC-10.  Original author(s) unknown.
0007      *
0008      *      This is the command parser for the NECK DATA ANALYSIS
0009      *      PACKAGE originally written for C. Spenny.  See XTRAC.
0010      *
0011      *      FUNCTIONS & SUBROUTINES CALLED:
0012
0013          CMPRES          External Library
0014          CTB             External Library
0015      *      L*1          ISDIG          External Library
0016      *      I*4          LLEN           External Library
0017      *      STRINP       External Library
0018      *      I*4          TOINT          External Library
0019      *      R*4          TOREAL2        External Library
0020      *      TTB          External Library
0021      *
0022      *      BYTE IFDP,ISDIG
0023      *      INTEGER WHAT,FCHAR,WRDNUM,IVAL,LLEN,TOINT,GET_STRING
0024      *      CHARACTER*(*) LIST(NDICT)
0025      *      CHARACTER WORD*10,IMAGE*80,SQUOTE*1,DELIM*3
0026      *
0027      *      In common block INPUT:
0028      *      IMAGE      = 80 character command "card"
0029      *      NEXTRD     = 0, Read next field on this card
0030      *                  1, Read new card, first field
0031      *                  2, Reread first field on same card
0032      *      IC         = Pointer to current card column
0033      *      FCHAR      = Location of first char in string
0034      *      LCHAR      = Location of last char in string
0035      *      WHAT       = 1, End of card
0036      *                  2, Integer (returned in IVAL)
0037      *                  3, Real number (returned in VALUE)
0038      *                  4, Word, not in dictionary
0039      *                  5, Word, in dictionary
0040      *                  6, End-of-file condition
0041      *                  7, Character string
0042      *                  8, Illegal char in numeric field
0043      *      LSTPOS     = Beginning location of last field read
0044      *      WRDNUM      = Index of word found in dictionary list
0045      *      IVAL        = Integer value if WHAT=2
0046      *      VALUE       = Real value if WHAT=3
0047      *
0048      *      COMMON /INPUT/ IMAGE,NEXTRD,IC,FCHAR,LCHAR,WHAT,LSTPOS,
0049      *      &      WRDNUM,IVAL,VALUE
0050
0051      *      VALUE=0.
0052      *      IVAL=0
0053      *      WRDNUM=0
0054      *      LASTC=LLEN(IMAGE)
0055      *      SQUOTE=' '
0056      *      DELIM=' , ' !<space>,<comma>,<tab>
0057

```

```

0058      IF(NEXTRD.EQ.0) THEN
0059      !      PRINT *, 'IC: ', IC, ' LC: ', LASTC
0060      !      print*, image(ic:lastc)
0061      IF(IC.LE.LASTC) GOTO 10
0062      WHAT=1
0063      RETURN
0064      ELSE IF(NEXTRD.EQ.1) THEN
0065      !      CALL STRINP(IMAGE, LASTC)
0066      LASTC=GET_STRING(IMAGE)
0067      IF(LASTC.EQ.0) THEN
0068      WHAT=1
0069      RETURN
0070      ELSE IF(LASTC.EQ.-2) THEN
0071      WHAT=6
0072      RETURN
0073      ENDIF
0074      !      print*, image(1:lastc)
0075      CALL CTB(IMAGE)      ! change commas to spaces
0076      CALL TTB(IMAGE)      ! change <tab>s to spaces
0077      CALL CMPRES(IMAGE)   ! convert multiple spaces to one space
0078      LASTC=LLEN(IMAGE)    ! (possibly) new length of string
0079      !      print*, image(1:lastc)
0080      IC=1
0081      ELSE IF(NEXTRD.EQ.2) THEN
0082      IC=1
0083      ENDIF
0084
0085      10  IF(INDEX(DELM, IMAGE(IC:IC)).NE.0) THEN
0086      IC=IC+1
0087      GOTO 10
0088      ENDIF
0089      !      PRINT *, 'AFTER 10$ IC: ', IC, ' LASTC: ', LASTC
0090      IF(IC.GT.LASTC) THEN
0091      WHAT=1
0092      RETURN
0093      ENDIF
0094      IF(IMAGE(IC:IC).EQ.SQUOTE) THEN
0095      WHAT=7
0096      LSTPOS=IC
0097      FCHAR=IC+1
0098      LCHAR=INDEX(IMAGE(FCHAR:), SQUOTE)
0099      IF(LCHAR.NE.0) GOTO 20
0100      WRITE(6, 1000) IMAGE(1:LLEN(IMAGE))
0101      1000  FORMAT(1X, 'End of Record within string (DCIFER): ', 1X, A)
0102      WHAT=1
0103      RETURN
0104      20  IC=LCHAR+1
0105      LCHAR=LCHAR+FCHAR-2
0106      RETURN
0107      ELSE IF(ISDIG(IMAGE(IC:IC)).OR.
0108      &      (INDEX('+-', IMAGE(IC:IC)).NE.0)) THEN
0109      IFDP=.FALSE.
0110      DO IB=IC, LASTC
0111      IF(INDEX('0123456789+-.', IMAGE(IB:IB)).EQ.0) GOTO 30
0112      IFDP=(IFDP.OR.(IMAGE(IB:IB).EQ.'.'))
0113      END DO
0114      IB=LASTC+1

```

```

0115      30      IEND=IB-1
0116          IF(IFDP) THEN
0117              WHAT=3.
0118      !      print *,image(ic:iend)
0119          VALUE=TOREAL2(IMAGE(IC:IEND))
0120          IF(VALUE.EQ.-9999999.) GOTO 60
0121          ELSE
0122              WHAT=2
0123      !      print *, 'DCIFER: IC:',ic,' IEND:',iend
0124          IVAL=TOINT(IMAGE(IC:IEND))
0125          IF(IVAL.EQ.-2147483648) GOTO 60
0126          ENDIF
0127          IC=IEND+1
0128          RETURN
0129      ELSE
0130          LSTPOS=IC
0131          DO ID=IC, LASTC
0132              IF(INDEX(DELM, IMAGE(ID:ID)).NE.0) GOTO 40
0133          END DO
0134          ID=LASTC
0135      40      WORD=IMAGE(IC:ID)
0136      !      PRINT *, 'At 50$, WORD=',word
0137          DO IE=1,NDICT
0138              IF(WORD(1:NCLST).EQ.LIST(IE)) THEN
0139                  WRDNUM=IE
0140                  WHAT=5
0141                  GOTO 50
0142              ENDIF
0143          END DO
0144          WHAT=4
0145      ENDIF
0146      50      IC=ID+1
0147          RETURN
0148      60      WRITE(6,1010)
0149      1010     FORMAT(1X,'Error in numeric field (DCIFER)')
0150          END--

```


SUBROUTINE DIRECT

```

0001 *****
0002 *****
0003 SUBROUTINE DIRECT
0004 * DIRECT:
0005 * Directory of SCRTCH.DAT for XTRAC and DSPLAY
0006 *
0007 INCLUDE 'XTRBLK/LIST'
0008
0009 READ(1,REC=1,ERR=10) NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
0010 IF(NVAR.EQ.0) GOTO 10
0011 DO I=1,NVAR
0012 WRITE(6,1000) I, RUN(I), NAME(I), MIN(I), MAX(I), NUMB(I)
0013 1000 FORMAT(1X, I3, ' ', 2X, 2A10, 2(2X, G), I5)
0014 END DO
0015 RETURN
0016 10 WRITE(6,1010)
0017 1010 FORMAT(/1X, 'Empty'/)
0018 RETURN
0019 END

```

SUBROUTINE STANDEV

```

0001 *****
0002      subroutine standev(filnam,varnam)
0003      *
0004      *
0005      *
0006      *
0007      *
0008      *
0009      *
0010      *
0011      *
0012      *
0013      *
0014      *
0015      *
0016      *
0017      *
0018      *
0019      *
0020      *
0021      *
0022      *
0023      *
0024      *
0025      *
0026      *
0027      *
0028      *
0029      *
0030      *
0031      *
0032      *
0033      *
0034      *
0035      *
0036      *
0037      *
0038      *
0039      *
0040      *
0041      *
0042      *
0043      *
0044      *
0045      *
0046      *
0047      *
0048      *
0049      *
0050      *
0051      *
0052      *
0053      *
0054      *
0055      *
0056      *
0057      *

      R. Stevens
      12/18/84
      SDC

      standev is called by xtrac as part of the
      STA command for the Spenny Neck Analysis
      package. standev opens the scratch file and finds all
      occurrences of the passed varnam and saves the
      corresponding record number in recnumr. standev then calls
      stdcal to get values for the mean and standard deviation
      at each timestep for the set of varnam. two variables are
      then calculated, sigup; mean plus st. dev. at each timestep,
      and siglo; mean minus st.dev. at each timestep. The scratch
      file is then rewritten.

      real mean(600),sigup(600),siglo(600),stdev(600)
      character filnam*30,varnam*6
      integer varcount,recnumr(100)
      include 'xtrblk/list'

      open(unit=1,file=filnam,status='old',access='direct',
      & organization='relative',iostat=ios,err=100)

      read(1,rec=1,iostat=ios,err=110)nvar,name,run,max,
      & min,units,numb

      j=0
      minpts=600
      varcount=0
      do i=1,nvar
         if(name(i).eq.varnam)then
            varcount=varcount+1
            j=j+1
            recnumr(j)=i+1
            if(numb(i).lt.minpts) minpts=numb(i)
         endif
      enddo

      if(varcount.eq.0)then
         ! make sure we have enough vars
         write(6,2001)varnam
         format(1x,'The variable ',a,' is not in the scratch file.')
         write(6,2010)
         format(1x,'Please try again...')
         return
      elseif(varcount.eq.1)then
         write(6,2002)varnam
         format(1x,'Variable ',a,' occurs only once in the scratch
         & file. '//1x,'STAing it wont prove anything.')
         write(6,2010)
         return
      endif

      call stdcal(recnumr,minpts,varcount,filnam,stdev,mean)

      do i=1,minpts
         sigup(i)=mean(i) + stdev(i)
         siglo(i)=mean(i) - stdev(i)
      enddo

```

```

0058      *
0059      meanrec=nvar+2          ! prepare info for scrтч file
0060      siguprec=nvar+3
0061      siglorec=nvar+4
0062      nvar1=nvar+1
0063      nvar2=nvar+2
0064      nvar3=nvar+3
0065      numb(nvar1)=minpts
0066      numb(nvar2)=minpts
0067      numb(nvar3)=minpts
0068      run(nvar1)='          '
0069      run(nvar2)='          '
0070      run(nvar3)='          '
0071      units(nvar1)=0
0072      units(nvar2)=0
0073      units(nvar3)=0
0074      call mnmx(mean,min,max,nvar1,minpts)
0075      call mnmx(sigup,min,max,nvar2,minpts)
0076      call mnmx(siglo,min,max,nvar3,minpts)
0077      name(nvar1)='MO'//varnam(1:3)//varnam(6:6)
0078      name(nvar2)='MP'//varnam(1:3)//varnam(6:6)
0079      name(nvar3)='MM'//varnam(1:3)//varnam(6:6)
0080      nvar=nvar + 3
0081
0082      ! fix scrтч file
0082      write(1,rec=1) nvar,name,run,max,min,units,numb
0083      write(1,rec=meanrec) (mean(i),i=1,numb(nvar1))
0084      write(1,rec=siguprec) (sigup(i),i=1,numb(nvar2))
0085      write(1,rec=siglorec) (siglo(i),i=1,numb(nvar3))
0086      *
0087      close(unit=1)
0088      *
0089      return
0090      100 continue
0091      print *, 'open error'
0092      return
0093      110 continue
0094      print *, 'read error'
0095      return
0096      end
0097

```


SUBROUTINE STDCAL

```

0001 *****
0002      subroutine stdcal(recnumr,minpts,varcnt,filnam,stdev,mean)
0003      *
0004      *      stdcal is called by standev as part of the      R. Stevens
0005      *      STA command of the Spenny Neck Analysis      12/18/84
0006      *      package. stdcal allocates virtual memory      SDC
0007      *      and then loads desired arrays (rec nums for desired arrays
0008      *      are passed in recnumr) into one large array in virtual
0009      *      memory. this array is passed to smean, which does the
0010      *      calculations.
0011      *
0012      character filnam*30
0013      integer minpts,varcnt,recnumr(varcnt),addr1,addr2
0014      real stdev(minpts),array(600),mean(minpts).
0015      *
0016      nbytes=minpts*varcnt*4      ! size of total vm
0017      nqw=nbytes/8
0018      if(mod(nbytes,8).ne.0)nqw=nqw+1
0019      nvb=nqw*8
0020      *
0021      kstat=lib$get_vm(nvb,addr1)      ! allocate vm
0022      if(.not.kstat) call lib$stop(%val(kstat))
0023      *
0024      nbytes2=minpts*4      ! size of each array
0025      addr2=addr1
0026      *
0027      do i=1,varcnt      ! read in arrays
0028          read(1,rec=recnumr(i),iostat=ios,err=100)
0029          &      (array(j),j=1,minpts)
0030          call lib$movc3(minpts*4,array(1),%val(addr2))
0031          addr2=addr2+nbytes2
0032      enddo
0033      *
0034      call smean(%val(addr1),minpts,varcnt,stdev,mean)
0035      *
0036      kstat=lib$free_vm(nvb,addr1)
0037      if(.not.kstat) call lib$signal(%val(kstat))
0038      *
0039      return
0040      100      continue
0041      write(6,101)
0042      101      format(1x,'READ ERROR in module STDCAL, call va programmer.')
0043      return
0044      end

```

SUBROUTINE SMEAN

```

subroutine smean(x,npts,nvars,sdev,mean)
*
* smean calculates the mean and
* standard deviation for the STA
* command of the Spenny Neck Analysis
* Package. nvars arrays, each npts long ~are packed
* into x by subroutine stdcal. The mean and std. dev.
* are calculated for the set of arrays at each timestep.
*
real x(npts*nvars),sdev(npts),mean(npts)
*
*
do i=1,npts                                !calc mean
    kount=i
    xbar=0.0
    do j=1,nvars
        xbar=xbar + x(kount) ! sum values
        kount=kount + npts
    enddo
    mean(i)=xbar/nvars
enddo
*
do i=1,npts                                ! calc std. dev.
    kount=i
    sum=0.0
    do j=1,nvars
        sum=sum+(x(kount)-mean(i))**2
        kount=kount+npts
    enddo
    sdev(i)=sqrt(sum/(nvars-1))
enddo
*
return
end

```


SUBROUTINE MATH

```

0001 *****
0002 *****
0003 SUBROUTINE MATH(ICMD)
0004 * MATH:
0005 * Performs the 'VMA', 'ADD', 'SUB', 'CON', 'DIV',
0006 * and 'NOR' commands for XTRAC
0007 *
0008 BYTE OK
0009 INTEGER KEEP(3), SIGLEN, WKEEP(3)
0010 REAL A(3, 598)
0011 CHARACTER RSAVE*6, VSAVE*6, DUMMY*6, NEWVAR*6
0012
0013 INCLUDE 'XTRBLK/LIST'
0014 *
0015 * Read in the dictionary
0016 *
0017 READ(1, REC=1, ERR=2010) NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
0018 ! do i=1, nvar
0019 ! print *, name(i)
0020 ! enddo
0021 *
0022 * Keyword RUN
0023 *
0024 CALL DCIFER(3, 1, LIST2)
0025 IF(WHAT.NE. 5) THEN
0026 WRITE(6, 2000)
0027 2000 FORMAT(1X, 'The word RUN must follow the command'//)
0028 WRITE(6, 1010)
0029 RETURN
0030 ENDIF
0031 *
0032 * Run number
0033 *
0034 CALL DCIFER(6, 380, LISTR)
0035 IF(WHAT.NE. 5) THEN
0036 WRITE(6, 1000)
0037 1000 FORMAT(1X, 'No such Run Number'//)
0038 WRITE(6, 1010)
0039 1010 FORMAT(1X, 'Please re-enter complete line'//)
0040 RETURN
0041 ENDIF
0042 ! print *, 'wrddnum=', wrddnum
0043 RSAVE=LISTR(WRDNUM)
0044 ! print *, 'rsave=', rsave
0045 *
0046 * Keyword VAR
0047 *
0048 CALL DCIFER(3, 1, 'VAR')
0049 IF(WHAT.NE. 5) THEN
0050 WRITE(6, 1020)
0051 1020 FORMAT(1X, 'Keyword VAR is missing'//)
0052 WRITE(6, 1010)
0053 RETURN
0054 ENDIF
0055 *
0056 * Variable name(s)
0057 *

```

```

0058      IF(ICMD.GT.3) THEN
0059          IVEND=1
0060      ELSE IF(ICMD.EQ.1) THEN
0061          IVEND=3
0062      ELSE
0063          IVEND=2
0064      ENDIF
0065      DO IVKNT=1, IVEND
0066          CALL DCIFER(6,NVAR,NAME)
0067          IF(WHAT.NE.5) THEN
0068              print *, 'what =', what
0069              WRITE(6,1030)
0070      1030          FORMAT(1X, 'No such variable'//)
0071              WRITE(6,1010)
0072              RETURN
0073          ENDIF
0074          VSAVE=NAME(WRDNUM)
0075          print *, 'vsave=', vsave
0076          DO IA=1, NVAR
0077              IF(RUN(IA).EQ.RSAVE.AND.NAME(IA).EQ.VSAVE) GOTO 10
0078          END DO
0079          WRITE(6,1040) RSAVE, VSAVE
0080      1040          FORMAT(1X, 'Run ', A, ' variable ', A, ' has not been EXtracted'//)
0081              WRITE(6,1010)
0082              RETURN
0083      10          KEEP(IVKNT)=IA+1
0084              WKEEP(IVKNT)=NUMB(IA)
0085          END DO
0086          IF(ICMD.EQ.6) GOTO 20
0087          IF(ICMD.GT.3) THEN
0088              CALL DCIFER(6,1,DUMMY)
0089              IF(WHAT.NE.3) THEN
0090                  WRITE(6,1050)
0091      1050          FORMAT(1X, 'Real constant is missing'//)
0092                  WRITE(6,1010)
0093                  RETURN
0094              ENDIF
0095              RCONST=VALUE
0096              IF(RCONST.EQ.0.0.AND.ICMD.EQ.5) THEN
0097                  WRITE(6,1060)
0098      1060          FORMAT(1X, 'Real constant is zero - DIVIDE ignored'//)
0099                  RETURN
0100              ENDIF
0101          ELSE
0102              OK=.TRUE.
0103              DO IZ=1, IVEND-1
0104                  OK=(WKEEP(IZ).EQ.WKEEP(IZ+1)).AND.OK
0105              END DO
0106              IF(.NOT.OK) THEN
0107                  WRITE(6,1070)
0108      1070          FORMAT(1X, 'It is not possible to combine sensor and',
0109      &              ' photo variables in this command.'//)
0110                  WRITE(6,1010)
0111                  RETURN
0112              ENDIF
0113          ENDIF
0114      *

```

```

0115      *      Get 'Use Variable'
0116      *
0117      20      CALL DCIFER(6,1,DUMMY)
0118              IF(WHAT.NE.7) THEN
0119      !          print *, 'What =', what
0120              WRITE(6,1080)
0121      1080      FORMAT(1X, 'The "use variable" must begin with an alphabetic',
0122      &          /1X, 'and be enclosed in single quotes'//)
0123              WRITE(6,1010)
0124      -          RETURN
0125      ENDIF
0126      !          print *, fchar, lchar
0127      NEWVAR=IMAGE(FCHAR:LCHAR)
0128      !          print *, newvar
0129      *
0130      *      Read 'em in
0131      *
0132              JNPTS=NUMB(KEEP(1))-1
0133      !          print *, 'jnpts=', jnpts
0134              DO IB=1, IVEND
0135                  READ(1,REC=KEEP(IB)) (A(IB,II), II=1, JNPTS)
0136              END DO
0137              IF(ICMD.EQ.6) THEN
0138                  RCONST=A(1,1)
0139                  IF(RCONST.EQ.0.0) THEN
0140                      WRITE(6,1090)
0141      1090      FORMAT(1X, 'Initial value zero - NORMALIZE ignored.'//)
0142                      RETURN
0143                  ENDIF
0144              ENDIF
0145              DO 70 IDK=1, JNPTS
0146      !          print *, 'icmd=', icmd
0147              GOTO (30,40,50,60,60), ICMD-1
0148      *      'VMA'
0149              E(IDK)=SQRT(A(1, IDK)**2+A(2, IDK)**2+A(3, IDK)**2)
0150              GOTO 70
0151      *      'ADD'
0152      30      E(IDK)=A(1, IDK)+A(2, IDK)
0153              GOTO 70
0154      *      'SUB'
0155      40      E(IDK)=A(1, IDK)-A(2, IDK)
0156              GOTO 70
0157      *      'CON'
0158      50      E(IDK)=A(1, IDK)+RCONST
0159              GOTO 70
0160      *      'DIV' & 'NOR'
0161      60      E(IDK)=A(1, IDK)/RCONST
0162      70      CONTINUE
0163      *
0164      *      Now write it out
0165      *
0166      NVAR=NVAR+1
0167      RUN(NVAR)=RSAVE
0168      NAME(NVAR)=NEWVAR
0169      UNITS(NVAR)=UNITS(KEEP(1))-1
0170      NUMB(NVAR)=WKEEP(1)
0171      CALL MNMX(E, MIN, MAX, NVAR, JNPTS)

```

```

0172      WRITE(1,REC=1) NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
0173      IQZX=NVAR+1
0174      WRITE(1,REC=IQZX) (E(II), II=1, JNPTS)
0175      RETURN
0176      *
0177      *      Error exit
0178      *
0179      2010      WRITE(6,2020)
0180      2020      FORMAT(1X, 'No Variables EXTRACTed -- command ignored'//)
0181      RETURN
0182      END

```


SUBROUTINE MNMX

```

0001 *****
0002 *****
0003 SUBROUTINE MNMX(ARR, MIN, MAX, NVAR, NUMMER)
0004 * MNMX:
0005 * Find the min & max values of ARR and insert in MIN(NVAR)
0006 * and MAX(NVAR)
0007 *
0008 REAL MIN(100), MAX(100), ARR(801)
0009 QNTMP=99999.
0010 QXTMP=-99999.
0011 DO I=1, NUMMER
0012 IF(ARR(I).LT.QNTMP) QNTMP=ARR(I)
0013 IF(ARR(I).GT.QXTMP) QXTMP=ARR(I)
0014 END DO
0015 print*, 'MNMX: min max nvar'
0016 print *, qntmp, qxtmp, nvar
0017 MIN(NVAR)=QNTMP
0018 MAX(NVAR)=QXTMP
0019 RETURN
0020 END

```

SUBROUTINE CURD

```

0001 *****
0002      subroutine curd(xarr,yarr,npts,isymp)
0003 *   CURD:                                     Rick Stevens
0004 *                                           SDC
0005 *                                           Aug  7,84
0006 *
0007 *   From a routine by Doug Gordon:
0008 *   Routine to simulate the DISSPLA CURVE routine.
0009 *   XARR is x-axis values, YARR is y-axis values. NPTS is
0010 *   number of points to plot. ISYMB is the symbol to use
0011 *   at each point. If ISYMB is > 0, symbols are drawn.
0012 *   If ISYMB = 0, a solid line is drawn. If ISYMB < 0,
0013 *   dashed lines are drawn. Currently, 5 line types
0014 *   are supported.
0015 *
0016      byte outside
0017      real xarr(npts),yarr(npts)
0018      integer jsymb(5)                                ! line types
0019      data jsymb/54,32,312,5434,74/
0020
0021      shgt=0.08                                     ! Symbol height
0022      ksymk=1                                       ! determine frequency of symbols
0023      if(npts.ge.50) ksymk=npts/10
0024      if(npts.ge.1000) ksymk=npts/100
0025      i=0
0026      outside=.true.
0027      call seedw(vxn,vxx,vyn,vyx)                  ! see virtual window
0028
0029      do while(outside)                            ! while inside virtual window
0030          i=i+1
0031          if(i.gt.npts) return
0032          x=xarr(i)
0033          y=yarr(i)
0034          outside=(x.lt.vxn .or. x.gt.vxx .or.      ! Test that point lies
0035      &          y.lt.vyn .or. y.gt.vyx)              ! in virtual window
0036      end do
0037
0038      call movea(xarr(i),yarr(i))
0039      if(isymb.gt.0) call symbol(xarr(i),yarr(i),isymp,shgt)
0040      isk=0
0041      do j=i,npts
0042          if(isymb.gt.0)then                          ! want symbol
0043              call drawa(xarr(j),yarr(j))
0044              if(j.eq.npts) isk=ksymk                ! always put sym on last pt
0045              if(isymb.gt.0.and.isk.ge.ksymk) then
0046                  call symbol(xarr(j),yarr(j),isymp,shgt)
0047                  isk=0                                ! symbol counter
0048              endif
0049          else if(isymb.eq.0)then                      ! want plain old line
0050              call drawa(xarr(j),yarr(j))
0051          else                                          ! want dashed line
0052              k=-isymp
0053              jazz=jsymb(k)
0054              call dasha(xarr(j),yarr(j),jazz)
0055          endif
0056          isk=isk+1
0057      end do

```


0058	call seetw(xm, xx, ym, yx)	! see screen window
0059	call movabs(xm, yx)	! place cursor
0060	call tsend	! dump output buffer
0061	return	
0062	end	

SUBROUTINE LABLE

```

*****
*****.
      subroutine lable(rntmp,read1,read2,quit,lintyp)

      byte quit
      real xarr(2),yarr(2)
      integer kount,ltype(20)
      character*6 plots(20),rntmp
      character read1*6,read2*6
      character str*24
      character*6 r1(20),r2(20)
      data kount/0/

      save kount

      include 'xtrblk.for/list'
      include 'dsppltblk.for/list'

      if(.not.quit)then
         kount=kount+1
         r1(kount)=read1
         r2(kount)=read2
         plots(kount)=rntmp
         ltype(kount)=lintyp
         return
      endif

      call seetw(minx,maxx,miny,maxy)
      nminx=maxx
      nmaxx=1023
      call csize(ihorz,ivert)

      call twindo(nminx,nmaxx,miny,maxy)
      call dwindo(0.,360.,0.,200.)
      yy=200.
      do i=1,kount
         xx=30.
         yy=yy-10.
         call movea(xx,yy)
         str=plots(i)//' //(r1(i)(1:llen(r1(i))))//' vs '//r2(i)
         cxx=xx+(llen(str)*ihorz)
         cyy=yy-(ivert/5)
         xarr(1)=xx
         xarr(2)=cxx
         yarr(1)=cyy
         yarr(2)=cyy
         call tekout(str)
      enddo
      kount=0
      idf1 = llen(display$figure)
      if(idf1 .gt. 0) then
         call movabs(nmaxx-(ihorz*(idf1+5)), miny+2)
         call tekout('Fig. '//display$figure(1:idf1))
         call tsend
      endif

      return
      end

```

SUBROUTINE SYMBOL


```

0001      subroutine symbol(x,y, isym, sizin)
0002      *      SYMBOL:                      Douglas A  Gordon
0003      *                                          Arcon Corporation
0004      *                                          3-APR-1984
0005      *
0006      *      Tektronix routine to generate a symbol at the point
0007      *      (X,Y) [assumes a virtual window was declared].
0008      *      ISYM is the symbol number. SIZIN is the symbol size
0009      *      in inches. Note that all symbols except the triangles are
0010      *      affected by rotation of the plot.
0011      *
0012      *      Modified 10-MAY-1984. Added 3 new symbols
0013      *
0014      call seedw(vxn,vxx,vyn,vyx)
0015      if(x.lt.vxn .or. x.gt.vxx .or.          ! Test that point lies
0016      &      y.lt.vyn .or. y.gt.vyx) return    ! in virtual window
0017      call movea(x,y)      ! move to point in virtual coords
0018      call seeloc(ixa,iya)  ! get the position in screen units
0019      ksiz=kin(sizin)
0020      irad=ksiz/2
0021      rad=float(irad)
0022      sq32=sqrt(3.0)/2.0
0023
0024      goto (10,20,30,40,50,60,70), isym-1      ! default is circle
0025      *
0026      * 1)      Circle centered on (X,Y) radius = IRAD
0027      *
0028      call movrel(irad,0)
0029      do ang= 10.0, 360., 10.0
0030          ixp=ixa+int(rad*sind(ang))
0031          iyp=iya+int(rad*cosd(ang))
0032          call drwabs(ixp,iyp)
0033      end do
0034      goto 1000
0035      *
0036      * 2)      Square centered on (X,Y) , length of side = KSIZ
0037      *
0038      10      call movrel(irad,-irad)
0039      call drwrel(0,ksiz)
0040      call drwrel(-ksiz,0)
0041      call drwrel(0,-ksiz)
0042      call drwrel(ksiz,0)
0043      goto 1000
0044      *
0045      * 3)      Plus sign centered on (X,Y)
0046      *
0047      20      call movrel(-irad,0)
0048      call drwrel(ksiz,0)
0049      call movrel(-irad,-irad)
0050      call drwrel(0,ksiz)
0051      goto 1000
0052      *
0053      * 4)      Equilateral triangle centered on (X,Y), altitude = KSIZ
0054      *
0055      30      call movrel(0,irad)          ! apex of triangle
0056      ixp=ixa-int(rad*sq32)
0057      iyp=iya-irad

```

```

0058      call drwabs(ixp,iyp)
0059      ixp=ixa+int(rad*sq32)
0060      call drwabs(ixp,iyp)
0061      call drwabs(ixa,iya+irad)
0062      goto 1000
0063      *
0064      * 5)      X centered on (X,Y) bounded by square with sides = KSIZ
0065      *
0066      40      call movrel(-irad,irad)
0067      call drwrel(ksiz,-ksiz)
0068      call movrel(-ksiz,0)
0069      call drwrel(ksiz,ksiz)
0070      goto 1000
0071      *
0072      * 6)      Asterisk centered on (X,Y) bounded by square sides = KSIZ
0073      *
0074      50      call movrel(-irad,0)
0075      call drwrel(ksiz,0)
0076      call movrel(-irad,-irad)
0077      call drwrel(0,ksiz)
0078      call movea(x,y)
0079      call movrel(-irad,irad)
0080      call drwrel(ksiz,-ksiz)
0081      call movrel(-ksiz,0)
0082      call drwrel(ksiz,ksiz)
0083      goto 1000
0084      *
0085      * 7)      Upside-down triangle
0086      *
0087      60      call movrel(0,-irad)
0088      ixp=ixa-int(rad*sq32)
0089      iyp=iya+irad
0090      call drwabs(ixp,iyp)
0091      ixp=ixa+(rad+sq32)
0092      call drwabs(ixp,iyp)
0093      call drwabs(ixa,iya-irad)
0094      goto 1000
0095      *
0096      * 8)      Diamond
0097      *
0098      70      call movrel(-irad,0)
0099      call drwrel(irad,irad)
0100      call drwrel(irad,-irad)
0101      call drwrel(-irad,-irad)
0102      call drwrel(-irad,irad)
0103      goto 1000
0104      *
0105      *      Insert additional figures here
0106      *
0107
0108      1000     call movea(x,y)          ! restore original position
0109      return
0110      end

```


SUBROUTINE TITLE

```

0001 *****
0002 *****
0003      subroutine title(ttl,lttl,xlabl,lx,ylabl,ly,dum1,dum2)
0004 *   TITLE:                                     Douglas A. Gordon
0005 *                                                Arcon Corporation
0006 *                                                08-FEB-1984
0007 *
0008 *   Routine to emulate the DISSPLA TITLE routine using
0009 *   tektronix PLOT-10.   DUM1 & DUM2 are the axis
0010 *   lengths in DISSPLA, but aren't needed here
0011 *
0012 *   - Modified 09-MAY-1984 to skip over titles or labels
0013 *     passed with a length of zero or blank strings
0014 *
0015 *   Modified 20-Jul-1984 to use TEKOUT, and to
0016 *   eliminate integer storage arrays for strings.
0017 *
0018      integer ychar
0019      character ttl*(*),xlabl*(*),ylabl*(*)
0020
0021      call seetw(ixn,ixx,iyn,iyx)
0022      lh1=linhgt(2)
0023      lw1=linwdt(0)
0024      if(ttl.eq.' ') lttl=0
0025      if(xlabl.eq.' ') lx=0
0026      if(ylabl.eq.' ') ly=0
0027      if(lttl.gt.0) call centre(ttl)
0028      if(lx.gt.0) call centre(xlabl)
0029      if(ly.gt.0) call centre(ylabl)
0030
0031      if(lttl.gt.0) then
0032          ixpos=ixn+(ixx-ixn-linwdt(len(ttl)))/2
0033          iypos=iyx+(780-iyx)/2
0034          call movabs(ixpos,iypos)
0035          call tekout(ttl)
0036      endif
0037
0038      if(lx.gt.0) then
0039          ixpos=ixn+(ixx-ixn-linwdt(len(xlabl)))/2
0040          call movabs(ixpos,linhgt(1)/2)
0041          call tekout(xlabl)
0042      endif
0043
0044      if(ly.gt.0) then
0045          ilh=linhgt(1)
0046          iypos=iyx-(iyx-iyn-linhgt(len(ylabl)))/2
0047          do i=1,llen(ylabl)
0048              ychar=ichar(ylabl(i:i))
0049              call movabs(lw1,iypos)
0050              call ancho(ychar)
0051              iypos=iypos-ilh
0052          end do
0053      endif
0054
0055      call tsend
0056      return
0057      end

```


SUBROUTINE DSP-WPAGE

subroutine dsp_wpage(xsize,ysize,xlen,ylen)

* WPAGE:

Douglas A. Gordon

Arcon Corporation

08-FEB-1984

*
*
*
*
*
*
*
*

Routine to establish the logical terminal window for
a tektronix terminal. Attempts to somewhat duplicate
the DISPLA PAGE routine. XSIZE is x page length in
inches, YSIZE is the y page length in inches. XLEN is
the x-axis length and YLEN is the y-axis length

parameter(maxx=1024)

parameter(maxy=780)

ixpts=int(xlen/xsize*float(maxx))

iypts=int(ylen/ysize*float(maxy))

ixn=150

! mod by richs!

ixx=ixn+ixpts

iy=(maxy-iypts)/2

iyx=iy+iypts

call twindo(ixn,ixx,iy,iyx)

return

end

SUBROUTINE DSP-OVERLAY

Subroutine Dsp_Overlay(X, Y, Npts, Ncurv, Maxpts, Isym,
 & Ttl, Xlabl, Ylabl, Flags)

*
 * OVERLAY: Douglas A. Gordon
 * Arcon Corporation
 * 16-Apr-1985

* Created from OMNILOT.FOR

* Last Revision Date: Thu 5-Dec-85 14:07

* Abstract:

* Simple overlay plotting routine.

* Calling Sequence:

* CALL OVERLAY(X.rf.ra, Y.rf.ra, NPTS.rl.r, NCURV.rl.r,
 * MAXPTS.rl.r, ISYM.rl.r, TTL.rt.dx, XLABL.rt.dx,
 * YLABL.rt.dx, FLAGS.rl.r)

* Formal Parameters:

* X Two-dimensional array (dimensioned (MAXPTS,NCURV))
 * of X-coordinates for plotting. Passed by
 * reference.
 * Y Two-dimensional array (dimensioned (MAXPTS,NCURV))
 * of Y-coordinates for plotting. Passed by
 * reference.
 * NPTS Array (dimensioned (NCURV)) containing the number
 * of points to plot for the corresponding X and Y
 * arrays. Integer*4. Passed by reference.
 * NCURV Number of curves to plot. Used as the implied
 * dimension of X, Y, and NPTS. Integer*4. Passed
 * by reference.
 * MAXPTS The upper dimension for the number of points in
 * the arrays X and Y. Integer*4. Passed by reference.
 * ISYM The starting symbol value. Ignored if bit 8 of FLAGS
 * set. Set to one if zero or negative and bit 8 clear.
 * Integer*4. Passed by reference.
 * TTL Title for plot. Passed length character
 * string. Passed by descriptor.
 * XLABL Label for X-axis. Passed length character
 * string. Passed by descriptor.
 * YLABL Label for Y-axis. Passed length character
 * string. Passed by descriptor.
 * FLAGS Plot customization flags. Integer*4. The
 * following bits are defined:

Bit	Meaning if set	Value
0	Draw box axes	1
1	Draw line at Y=0.0 (virtual)	2
2	Draw line at X=0.0 (virtual)	4

*	3	Draw a point grid on the plot	8
*	4	Auto Hardcopy plot	16
*	5	Invoke VT240/241 for duration	
*		of plot - exit to VT100 mode	32
*	6	X-axis scale from common	64
*	7	Y-axis scale from common	128
*	8	Suppress symbols	256
*	9	Dashed lines (not currently	
*		supported)	512
*	10	Used by the legend software	1024
*	11	Rotate auto-hardcopy (VT240 with	
*		V2.1 firmware or later)	2048
*	12	Draw a scatter plot rather than	
*		a curve	4096
*	13	Laser printer support	8192
*	14	Enable message trapping	16384
*	15-31	Undefined (must be zero)	

* Implicit Inputs:

* None.

* Implicit Outputs:

* Plot to the terminal.

* Side Effects:

* Plays with the emulations settings on VT240 series terminals.

* Functions & Subroutines Called:

*		AXES1	TSC Plot Library
*	I*4	BAUDQ	TSC Plot Library
*	I*4	GET_ARRAY	TSC General Library
*		HARD_COPY	TSC Plot Library
*		HARD_COPY_FF	TSC Plot Library
*		INITT	TEKTRONIX Terminal Control System
*		LIB\$SIGNAL	VAX Run Time Library
*	I*4	LLEN	TSC General Library (MACRO32)
*		MTITLE	TSC Plot Library
*		NEWPAGE	TEKTRONIX Terminal Control System
*		N_CURVE	TSC Plot Library
*		N_SPLATTER	TSC Plot Library
*	I*4	PARSE_BIT_FLAGS	TSC General Library (MACRO32)
*		PLHOLD	TSC Plot Library
*	I*4	PUTMSG	TSC General Library (MACRO32)
*		QUIET_PLOT	TSC Plot Library
*		SCAL	TSC Plot Library
*		VT200_SET_MODE	TSC General Library
*		WPAGE	TSC Plot Library

* Revision History:

* Some revision history removed on conversion.


```

*
* Modified 10-Jun-1985 to support additional functionality in VT240's
* with firmware upgrade.
* Modified 11-Jun-1985. Moved the rotate code since VT240 doesn't
* recognize escape sequences in Tek emulation.
* Modified 28-Jun-1985. Changed AXES_MASK to pass additional bits.
* Modified 9-Jul-1985 to support new hardcopy software.
* Modified 23-Jul-1985. Added call to RECOLOR.
* Modified 10-Sep-1985 to return VT240's to VT240 7-bit controls
* rather than VT100 emulation (VMS V4.1 upgrade)
* Modified 19-Sep-1985 to allow scatter plots.
* Modified 15-Nov-1985 to include a stab in the dark to support the
* laser printer.
*

byte first/.true./, autohc, vt240, bit_values(0:31), manualx,
& manually, no_sym, rotate, scatter, laser
integer*4 ncurv, npts(ncurv), flags, max_bit, status, axes_flags,
& axes_mask/'0000003F'X/, lt1, lx, ly, jsym, maxpts
integer*4 parse_bit_flags, baudq, llen, get_array, putmsg
real x(maxpts,ncurv), y(maxpts,ncurv), xmin, xmax, ymin, ymax, tmp(2)
character*(*) ttl, xlabel, ylabel, esc*1/27/

include 'pltdef.for/list'
include 'pltmsgdef.for/list' ! 40 lines
include 'dsppltblk.for/list' ! 5 lines

parameter (max_bit = plt$max_bit)

equivalence (bit_values(plt$v_autohc), autohc)
equivalence (bit_values(plt$v_vt240), vt240)
equivalence (bit_values(plt$v_xscale), manualx)
equivalence (bit_values(plt$v_yscale), manually)
equivalence (bit_values(plt$v_nosym), no_sym)
equivalence (bit_values(plt$v_rotate), rotate)
equivalence (bit_values(plt$v_scatter), scatter)
equivalence (bit_values(plt$v_laser), laser)

*
* Test for reasonable input
*

do i = 1, ncurv
  if(npts(i) .lt. 0) then
    status = putmsg(%val(plt$_negnumpts), %val(1), %val(i))
    if(.not. status) call lib$signal(%val(status))
    return
  endif
end do

*
* Parse the option bits
*

status = parse_bit_flags(4, flags, max_bit, bit_values)
if(.not. status) call lib$signal(%val(unexperr), %val(1),
& 'OVERLAY', %val(status))
axes_flags = flags .and. axes_mask

*
* Get the axes ranges, and, if manual scaling specified,

```

```

*      offer the user the scaling choice.
*
xmin = x(1,1)
xmax = x(1,1)
ymin = y(1,1)
ymax = y(1,1)
do n = 1, ncurv
  do m = 1, npts(n)
    if(x(m,n) .lt. xmin) xmin = x(m,n)
    if(x(m,n) .gt. xmax) xmax = x(m,n)
    if(y(m,n) .lt. ymin) ymin = y(m,n)
    if(y(m,n) .gt. ymax) ymax = y(m,n)
  end do
end do

if(manualx) then                                ! manual scaling X
  sxmin = dsplay$xmin
  sxmax = dsplay$xmax
  incx = dsplay$incx
else
  call scal(xmin, xmax, sxmin, sxmax, incx)
endif

if(manualy) then                                ! manual scaling Y
  symin = dsplay$ymin
  symax = dsplay$ymax
  incy = dsplay$incy
else
  call scal(ymin, ymax, symin, symax, incy)
endif
if(incx .eq. 0 .or. incy .eq. 0) goto 50

if(.not. laser) then
  call quiet_plot('on')                        ! set terminal /NOBROADCAST
  if(vt240 .and. autohc) then
    if(rotate) then
      status = lib$put_screen(esc // '['?47h')
    else
      status = lib$put_screen(esc // '['?47l')
    endif
    if(.not. status) call lib$signal(%val(plt$_unexperr), %val(1),
    &      'OVERLAY', %val(status))
  endif
  if(vt240) call vt200_set_mode(4)              ! TEK emulation
endif
if(first) then
  call initt(baudq()/10)                        ! In chars/sec
  first = .false.
elseif(laser) then
  call ff_laser_plot
else
  call newpag                                  ! clear screen
endif

call dsp_wpage(16., 14., 8., 8.)                ! Physical window

```

```

call axes1(sxmin,sxmax,incx,symin,symax,incy,axes_flags)
lttl = llen(ttl)
lx = llen(xlabl)
ly = llen(ylabl)
call mtitle(ttl, lttl, xlabl, lx, ylabl, ly)
jsym = 0
call n_curve(x, y, npts, ncurv, maxpts, jsym)
if(.not. laser) then
  if(autohc) then
    call hard_copy          ! Hardcopy
  endif

  if(vt240) then
    call vt200_set_mode(5)  ! Back to VT240
    if(autohc) call hard_copy_ff ! ff printer if necessary
    call recolor            ! change vt240 color back
  endif
  if(rotate) then
    status = lib$put_screen(esc // '[?471')
    if(.not. status) call lib$signal(%val(plt$_unexperr), %val(1),
&    'OVERLAY', %val(status))
  endif
endif
if(.not. laser) call quiet_plot('off')

50 return
end

```

SUBROUTINE NCKNEW (NECK)


```

C      NCKNEW.FOR
C      7/12/83. J.B. MATRIX 'F' IS CORRECTED/12 CHANGES.
C
C
C      VRBLS()=LIST OF VARIABLES' NAMES
C      FILNM=FILE NAME
C      NAMTMP()=RUN NUMBER
C      NP()=NUMBER OF POINTS OF OBSERVATIONS
C      NERROR=AN ERROR INDICATOR
C      RECNM()=THE RECORD NUBER IN SCRATCH FILE SCRATCH.DAT
C      TYPE()=ERROR TYPE
C      RECLN=LENGTH OF A RECORD (NUMBER OF WORDS)
C      DATA RECLN/801/=RECORD LENGTH
C      NVAR=NUMBER OF VARIABLES
C      NAME(NVAR)=THE VARIABLE'S NAME
C      RUN(NVAR)=RUN NUMBER.
C      MAX(NVAR)=THE MAXIMUM OF THAT VARIABLE
C      MIN(NVAR)=THE MINIMUM OF THAT VARIABLE
C      UNITS(NVAR)=A UNIT OF MEASUREMENT
C      NUMB(NVAR)=NUMBER OF POINTS OF OBSERVATIONS
C      NUM=NP(MAX INDEX)=NUMBER OF POINTS OF OBSERVATIONS
C
C      BYTE UNITS(100)
C      INTEGER*2 NUMB(100)
C      INTEGER RECLN,MREC,NP(13),NERROR,RECNM(13),TYPE(2)
C      REAL DAXSOP(600),DAYSOP(600),DAZSOP(600),DNXSOP(600),
&      DNYSOP(600),DNZSOP(600),PHAOXP(600),PHB02P(600),PHC03P(600),
&      PNAOXP(600),PNB02P(600),PNC03P(600),TARRY(600),MAX(100),
&      MIN(100)
C      CHARACTER*6 NAME(100),RUN(100),VRBLS(13),FILNM,NAMTMP
C
C      COMMON /INDATA/ DAXSOP,DAYSOP,DAZSOP,DNXSOP,DNYSOP,DNZSOP,
&      PHAOXP,PHB02P,PHC03P,PNAOXP,PNB02P,PNC03P,TARRY
C
C      PARAMETER (MREC=101)
C      PARAMETER (RECLN=598)
C
C      DATA VRBLS/'DAXSOP','DAYSOP','DAZSOP','DNXSOP','DNYSOP',
&      'DNZSOP','PHAOXP','PHB02P','PHC03P','PNAOXP','PNB02P',
&      'PNC03P','TIME'/
C
C      DATA TYPE/'OPEN','READ'/
C
C
C      STEP 1: OPEN INPUT FILE
C
C      OPEN(UNIT=1,FILE='SCRATCH',STATUS='OLD',RECL=RECLN,ERR=999,
&      FORM='UNFORMATTED',ORGANIZATION='RELATIVE',IOSTAT=IOS,
&      ACCESS='DIRECT')
C
C
C      STEP 2: READ IN DIRECTORY
C

```



```
READ(1,REC=1)NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
```

```
STEP 3: TEST FOR EXISTANCE OF VARIABLES
```

```
DO 1 I=1,13  
DO 2 N=1,NVAR  
IF(NAME(N).NE.VRBL5(I))GO TO 3  
NP(I)=NUMB(N)  
RECNM(I)=N+1  
GO TO 1
```

```
3 IF(N.EQ.NVAR)GO TO 900  
2 CONTINUE  
1 CONTINUE
```

```
STEP 4: READ APPROPRIATE RECORD
```

```
READ(1,REC=RECNM(1))(DAXSOP(K),K=1,NP(1))  
READ(1,REC=RECNM(2))(DAYSOP(K),K=1,NP(2))  
READ(1,REC=RECNM(3))(DAZSOP(K),K=1,NP(3))  
READ(1,REC=RECNM(4))(DNXSOP(K),K=1,NP(4))  
READ(1,REC=RECNM(5))(DNYSOP(K),K=1,NP(5))  
READ(1,REC=RECNM(6))(DNZSOP(K),K=1,NP(6))  
READ(1,REC=RECNM(7))(PHAOXP(K),K=1,NP(7))  
READ(1,REC=RECNM(8))(PHB02P(K),K=1,NP(8))  
READ(1,REC=RECNM(9))(PHC03P(K),K=1,NP(9))  
READ(1,REC=RECNM(10))(PNA0XP(K),K=1,NP(10))  
READ(1,REC=RECNM(11))(PNB02P(K),K=1,NP(11))  
READ(1,REC=RECNM(12))(PNC03P(K),K=1,NP(12))  
READ(1,REC=RECNM(13))(TARRY(K),K=1,NP(13))
```

```
10 CONTINUE  
NERROR=0  
NUM=NP(13)
```

```
NAMTMP=RUN(RECNM(1)-1)  
CALL NECKTP(NUM,NERROR,NAMTMP)
```

```
IF(NERROR.NE.0)GO TO 999  
GO TO 1000
```

```
ERROR MESSAGES
```

```
900 WRITE(6,901)VRBL5(I)  
901 FORMAT(1X,'VARIABLE',1X,A10,1X,'IS NOT IN THE INPUT FILE',/,
```

```

+          1X,'YOU ARE ABOUT TO BE RETURNED TO MONITOR LEVEL TO ',/,
+          1X,'TRY AND RECTIFY THE PROBLEM',///)
C
C
C
      GO TO 1000
C
C
C
999  WRITE(6,902)TYPE(NERROR)
C
902  FORMAT(1X,A5,'ERROR ENCOUNTERED'//,
+        1X,'PROGRAM HALT',///)
C
1000 CONTINUE
C
      CLOSE(UNIT=1)
      END
*****
*****
      SUBROUTINE NECKTP(NUM,NERROR,RUNTMP)
      4TH EDITION OF 2/22/83
C
C
C      FILE:  NECKTP4.FOR
C
C      COMPUTATION OF NECK STRETCH T1 TO OCCIPITAL CONDYLES
C              FROM PHOTOGRAPHIC DATA
C
C      GLOSSARY
C
C      PROGRAM CONSTANTS
C
C      RGAX = THE COMPONENT OF LINEAR POSITION OF THE
C              HEAD CENTER OF GRAVITY ALONG THE X-AXIS
C              OF THE HEAD ANATOMICAL COORDINATE SYSTEM.
C      RGAZ = SAME AS ABOVE EXCEPT FOR THE Z-AXIS.
C      RGOX = THE COMPONENT OF LINEAR POSITION OF THE
C              HEAD CENTER OF GRAVITY ALONG THE X-AXIS OF THE
C              HEAD ANATOMICAL COORD. SYSTEM MEASURED FROM
C              THE OUTSIDE CONDYLES.
C      RGOZ = SAME AS ABOVE EXCEPT FOR THE Z-AXIS.
C
C      PROGRAM VARIABLES (ARRAYS)
C
C      DAXSOP = X-COMPONENT OF DISPLACEMENT OF HEAD A.O.
C              (THE SLED COORDINATE SYETEM) FROM
C              PHOTOGRAPHIC DATA
C      DAYSOP = SAME AS ABOVE EXCEPT FOR THE Y-COMPONENT
C      DAZSOP = SAME AS ABOVE EXCEPT FOR THE Z-COMPONENT
C      DNXSOP = X-COMPONENT OF DISPLACEMENT OF THE T1
C              A.O. (THE SLED COORDINATE SYSTEM) FROM
C              PHOTOGRAPHIC DATA
C      DNYSOP = SAME AS ABOVE EXCEPT FOR THE Y-COMPONENT
C      DNZSOP = SAME AS ABOVE EXCEPT FOR THE Z-COMPONENT
C      PHAOXP = HEAD ROTATION ABOUT X AXIS (THE ANATOMIC

```

COORD. SYSTEM) FROM PHOTOGRAPHIC DATA
 PHB02P = SAME AS ABOVE EXCEPT FOR THE Y-COMPONENT
 PHC03P = SAME AS ABOVE EXCEPT FOR THE Z-COMPONENT
 PNA0XP = ANGLE OF ROTATION OF T1 ABOUT X AXIS OF THE T1
 ANATOMICAL COORD. SYSTEM AS DERIVED FROM
 PHOTOGRAPHIC DATA
 PNB02P = SAME AS ABOVE EXCEPT ABOUT THE CARRIED Y AXIS
 PNC03P = SAME AS ABOVE EXCEPT ABOUT THE CARRIED Z AXIS
 TOXLP/TOYLP/TOZLP=OUTPUT VARIABLES GENERATED BY
 PROGRAM TRQPHO.FOR ;
 THE COMPONENT OF THE MOMENT APPLIED BY THE
 NECK TO THE HEAD ABOUT AN AXIS PARALLEL
 TO THE LABORATORY X/Y/Z-AXIS AND PASSING
 THROUGH THE ORIGIN OF THE OCCIPITAL COORD.
 SYSTEM.
 FOXLP/FOYLP/FOZLP= OUTPUT VARIABLES FROM PROGRAM
 TRQPHO.FOR:
 THE COMPONENT OF FORCE APPLIED BY THE NECK
 TO THE HEAD PARALLEL TO THE LABORATORY
 X/Y/Z-AXIS AND PASSING THROUGH THE ORIGIN
 OF THE OCCIPITAL COORD. SYSTEM.

OUTPUT VARIABLES

RATIXP = X-COMPONENT OF POSITION OF THE HEAD ANATOMICAL
 ORIGIN WITH RESPECT TO THE T1 ANATOMICAL ORIGIN
 (THE LABORATORY COORD. SYSTEM) FROM PHOTOGRAPHIC
 DATA
 RATIYP = SAME AS ABOVE EXCEPT FOR THE Y-COMPONENT
 RATIZP = SAME AS ABOVE EXCEPT FOR THE Z-COMPONENT
 ROTIXP = X-COMPONENT OF POSITION OF THE OCCIPITAL
 CONDYLE WITH RESPECT TO THE T1 ANATOMIC
 ORIGIN (THE LABORATORY COORD. SYSTEM) FROM
 PHOTOGRAPHIC DATA
 ROTIYP = SAME AS ABOVE EXCEPT FOR THE Y-COMPONENT
 ROTIZP = SAME AS ABOVE EXCEPT FOR THE Z-COMPONENT
 RATIP = THE DISTANCE FROM THE HEAD ANATOMICAL
 ORIGIN TO THE T1 ANATOMICAL ORIGIN
 FROM PHOTOGRAPHIC DATA
 ROTIP = THE DISTANCE FROM THE OCCIPITAL
 CONDYLE TO THE T1 ANATOMICAL ORIGIN
 FROM PHOTOGRAPHIC DATA
 TENTYP = THE ANGLE OF ROTATION OF A PLANE FORMED BY THE
 Y AXIS OF THE T1 ANATOMICAL COORD. SYSTEM AND
 THE VECTOR JOINING T1 WITH THE
 OCCIPITAL CONDYLE WITH RESPECT TO THE PLANE FORMED
 BY THE Y AND Z AXES OF THE T1 ANATOMICAL COORD.
 SYSTEM AS DERIVED FROM PHOTOGRAPHIC DATA
 TENTXP = THE ANGLE OF ROTATION OF A PLANE FORMED BY THE
 X AXIS OF THE T1 ANATOMICAL COORD. SYSTEM AND THE
 VECTOR JOINING T1 WITH RESPECT TO THE PLANE FORMED
 BY THE X AND Z AXES OF THE T1 ANATOMICAL COORD.
 SYSTEM AS DERIVED FROM PHOTOGRAPHIC DATA
 TETHNC=THE ANGLE OF ROTATION OF A PLANE FORMED BY THE
 X-AXIS OF THE HEAD ANATOMICAL ORIGIN AND


```

C      THE Z-AXIS OF THE NECK CHORD LINE COORDINATE SYSTEM
C      WITH RESPECT TO THE PLANE FORMED BY THE X-
C      AND Z-AXES OF THE NECK LINE COORDINATE SYSTEM
C      TOXOP = THE COMPONENT OF TORQUE APPLIED BY THE NECK TO THE
C      HEAD AT THE OCCIPITAL CONDYLES ALONG THE X-AXIS
C      OF THE NECK CHORD COORDINATE SYSTEM
C      TOYOP = THE COMPONENT OF TORQUE APPLIED BY THE NECK
C      TO THE HEAD AT THE OCCIPITAL CONDYLES ALONG THE-
C      AXIS OF THE NECK CHORD COORDINATE SYSTEM
C      TOZOP = THE COMPONENT OF TORQUE APPLIED BY THE NECK TO
C      THE HEAD AT THE OCCIPITAL CONDYLES ALONG THE Z-AXIS
C      OF THE NECK CHORD COORDINATE SYSTEM
C      FOXOP = THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD AT THE OCCIPITAL CONDYLES ALONG THE X-AXIS
C      OF THE NECK CHORD COORDINATE SYSTEM
C      FOYOP = THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD AT THE OCCIPITAL CONDYLES ALONG THE Y-AXIS
C      OF THE NECK CHORD COORDINATE SYSTEM
C      FOZOP = THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD AT THE OCCIPITAL CONDYLES ALONG THE Z-AXIS
C      OF THE NECK CHORD COORD. SYSTEM
C      T1XLP= THE COMPONENT OF TORQUE APPLIED BY THE TORSO TO THE NECK
C      AT THE T1 VERTEBRA ALONG THE X-AXIS OF THE LABORATORY
C      COORDINATE SYSTEM.
C      T1YLP= THE COMPONENT OF TORQUE APPLIED BY THE TORSO TO THE NECK
C      AT THE T1 VERTEBRA ALONG THE Y-AXIS OF THE LABORATORY
C      COORDINATE SYSTEM.
C      T1ZLP= THE COMPONENT OF TORQUE APPLIED BY THE TORSO TO THE NECK
C      AT THE T1 VERTEBRA ALONG THE Z-AXIS OF THE LABORATORY
C      COORDINATE SYSTEM.
C
C      REAL TOXLP(600),TOYLP(600),TOZLP(600),FOXLP(600),FOYLP(600),
&      FOZLP(600),TOXOP(600),TOYOP(600),TOZOP(600),FOXOP(600),
&      FOYOP(600),FOZOP(600),TETHNP(600),PSI(600),RATIXP(600),
&      RATIYP(600),RATIZP(600),ROTIXP(600),ROTIYP(600),ROTIZP(600),
&      RATIP(600),ROTIP(600),TENTYP(600),TENTXP(600),T1XLP(600),
&      T1YLP(600),T1ZLP(600),T1XTP(600),T1YTP(600),T1ZTP(600)
C      CHARACTER*6 NAMTMP(24),RUNTMP
C      INTEGER NERROR
C      INCLUDE 'COMP.FOR'
C
C      TRANSFER OF DATA FROM TRQPHO.FOR PROGRAM
C
C      DATA NAMTMP/'RATIXP','RATIYP','RATIZP','ROTIXP','ROTIYP',
&      'ROTIZP','RATIP','ROTIP','TENTYP','TENTXP','TETHNP',
&      'PSI','TOXOP','TOYOP','TOZOP','FOXOP','FOYOP','FOZOP',
&      'T1XLP','T1YLP','T1ZLP','T1XTP','T1YTP','T1ZTP'//
C      SUBJECT NUMBER SELECTION
1700  CONTINUE
      READ(5,*)NJCT
      WRITE(6,1755)NJCT
1755  FORMAT(5X,'SUBJECT NUMBER=',I5)
      IF(NJCT.EQ.1)GO TO 1001
      IF(NJCT.EQ.44)GOTO 1044

```

```

IF(NJCT.EQ.64)GOTO 1064
IF(NJCT.EQ.65)GOTO 1065
IF(NJCT.EQ.67)GOTO 1067
IF(NJCT.EQ.83)GO TO 1083
IF(NJCT.EQ.93)GO TO 1093
IF(NJCT.EQ.96)GO TO 1096
IF(NJCT.EQ.118)GO TO 1118
IF(NJCT.EQ.120)GO TO 1120
IF(NJCT.EQ.127)GO TO 1127
IF(NJCT.EQ.130)GO TO 1130
IF(NJCT.EQ.131)GO TO 1131
IF(NJCT.EQ.132)GO TO 1132
IF(NJCT.EQ.133)GO TO 1133
IF(NJCT.EQ.134)GO TO 1134
IF(NJCT.EQ.135)GO TO 1135
IF(NJCT.EQ.136)GO TO 1136
IF(NJCT.EQ.138)GO TO 1138
IF(NJCT.EQ.139)GO TO 1139
IF(NJCT.EQ.140)GO TO 1140
IF(NJCT.EQ.141)GO TO 1141
IF(NJCT.EQ.142)GO TO 1142
1701 CONTINUE
WRITE(6,1702)
1702 FORMAT(1X,'INCORRECT SUBJECT NUMBER')
STOP
1001 CONTINUE
RGAX=0.012
RGAZ=0.029
RGOX=0.0234
RGOZ=0.055
ARP=0.0
BR=0.0
DNZMN=0.0
XCR=0.0
YCR=0.
ZCR=0.0
GO TO 999
C
1044 CONTINUE
C
RGAX=0.012
RGAZ=0.029
RGOX=0.023
RGOZ=0.055
ARP=1.160
BR=-0.492
DNZMN=1.091
XCR=0.0
YCR=0.0
ZCR=0.0
GO TO 999
C
1064 CONTINUE
C
RGAX=0.012

```



```

      RGAX=0.012
      RGZ=0.029
      RGOX=0.023
      RGOZ=0.055
      ARP=1.146
      BR=-0.294
      DNZMN=1.091
      XCR=0.
      YCR=0.0
      ZCR=0.0
      GO TO 999
1065  CONTINUE
C
      RGAX=0.012
      RGZ=0.029
      RGOX=0.023
      RGOZ=0.055
      ARP=1.154
      BR=-0.410
      DNZMN=1.095
      XCR=0.
      YCR=0.0
      ZCR=0.0
      GO TO 999
1067  CONTINUE
C
      RGAX=0.012
      RGZ=0.029
      RGOX=0.023
      RGOZ=0.055
      ARP=1.059
      BR=-0.0719
      DNZMN=1.047
      XCR=0.0
      YCR=0.0
      ZCR=0.0
      GO TO 999
C
1083  CONTINUE
C
      RGAX=0.012
      RGZ=0.029
      RGOX=0.023
      RGOZ=0.055
      ARP=1.272224
      BR=-1.31925
      DNZMN=1.128304
      XCR=0.0
      YCR=0.0
      ZCR=0.0
      GO TO 999
C
1093  CONTINUE
      RGAX=0.012
      RGZ=0.029
      RGOX=0.023

```

RGQZ=0.055
ARP=1.239763
BR=-0.941244
DNZMN=1.098385
XCR=0.0
YCR=0.
ZCR=0.
GO TO 999

C

1096 CONTINUE
RGAX=0.012
RGAZ=0.029
RGOX=0.023
RGOZ=0.055
GO TO 999

1118 CONTINUE
RGAX=.012
RGAZ=.029
RGOX=.023
RGOZ=.055
ARP=1.472471
BR=-.537460
DNZMN=1.380167
XCR=0.
YCR=0.
ZCR=0.
GO TO 999

1120 CONTINUE
RGAX=.012
RGAZ=.029
RGOX=.023
RGOZ=.055
ARP=1.554568
BR=-1.00074
DNZMN=1.383071
XCR=0.
YCR=0.
ZCR=0.
GO TO 999

1127 CONTINUE
RGAX=.012
RGAZ=.029
RGOX=.023
RGOZ=.055
ARP=1.541470
BR=-.976451
DNZMN=1.382870
XCR=0.
YCR=0.
ZCR=0.
GO TO 999

1130 CONTINUE
RGAX=.012
RGAZ=.029
RGOX=.023

```

      RGQZ=.055
      ARP=1.665381
      BR=-1.48895
      DNZMN=1.396958
      XCR=0.
      YCR=0.
      ZCR=0.
      GO TO 999
1131  CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGQZ=.055
      ARP=1.520460
      BR=-0.753537
      DNZMN=1.402846
      XCR=0.
      YCR=0.
      ZCR=0.
      GO TO 999
1132  CONTINUE
      RGAX=.012
      RGAZ=0.029
      RGOX=.023
      RGQZ=.055
      ARP=1.523568
      BR=-0.927588
      DNZMN=1.392558
      XCR=0.
      YCR=0.
      ZCR=0.
      GO TO 999
1133  CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGQZ=.055
      ARP=1.513768
      BR=-0.751378
      DNZMN=1.389440
      XCR=0.
      YCR=0.
      ZCR=0.
      GO TO 999
1134  CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGQZ=.055
      ARP=1.543767
      BR=-0.862095
      DNZMN=1.40791
      XCR=0.
      YCR=0.
      ZCR=0.

```

```

1135  GO TO 999
      CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGOZ=.055
      ARP=1.552383
      BR=-0.962941
      DNZMN=1.408047
      XCR=0.
      YCR=0.
      ZCR=0.
1136  GO TO 999
      CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGOZ=.055
      ARP=1.413834
      BR=-0.130286
      DNZMN=1.391344
      XCR=0.
      YCR=0.
      ZCR=0.
1138  GO TO 999
      CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGOZ=.055
      ARP=1.493554
      BR=-0.626753
      DNZMN=1.384522
      XCR=0.
      YCR=0.
      ZCR=0.
1139  GO TO 999
      CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGOZ=.055
      ARP=1.537098
      BR=-0.821211
      DNZMN=1.401846
      XCR=0.
      YCR=0.
      ZCR=0.
1140  GO TO 999
      CONTINUE
      RGAX=.012
      RGAZ=.029
      RGOX=.023
      RGOZ=.055
      ARP=1.515952

```

```

BR=-0.732621
DNZMN=1.388380
XCR=0.
YCR=0.
ZCR=0.
GO TO 999
1141 CONTINUE
RGAX=0.012
RGAZ=.029
RGOX=.023
RGOZ=.055
ARP=1.542182
BR=-0.785473
DNZMN=1.403853
XCR=0.
YCR=0.
ZCR=0.
GO TO 999
1142 CONTINUE
RGAX=.012
RGAZ=.029
RGOX=.023
RGOZ=.055
ARP=1.558605
BR=-0.987192
DNZMN=1.399655
XCR=0.
YCR=0.
ZCR=0.
GO TO 999
C
1725 CONTINUE
999 CONTINUE
DELT=0.0005
! TPMAX=TARRY(NUM)
! TSMAX=DELT*598
! IF(TPMAX.LE.TSMAX)GO TO 55
! print *, 'here I am'
DO 11 K=1,NUM
K1=K
TAR=TARRY(K1)
IF(TAR.LE.TSMAX)GO TO 11
KC=K
KMAX=KC-1
GO TO 22
C
11 CONTINUE
22 CONTINUE
C
! print *, 'kmax=', kmax
NUM=KMAX
C OPEN INPUT FILENNN.DAT
C
OPEN(UNIT=10,FILE='NNN',ACCESS='SEQUENTIAL',STATUS='OLD')
DO 1212 K=1,NUM

```



```

      J=K
      READ(10,1220)TOXLP(J),TOYLP(J),TOZLP(J),
+      FOXLP(J),FOYLP(J),FOZLP(J)
C      write(6,1220)toxlp(j)
1220      FORMAT(6(E13.7))
1212      CONTINUE
      CLOSE(UNIT=10)
C
55      CONTINUE
C      EQUATIONS (2)
C      *****

      ROAXA=RGAX-RGOX
      ROAZA=RGAZ-RGOZ
C
C      MATRIX P
C
      TET1X0=PNA0XP(1)
      TET1Y0=PNB02P(1)
      TET1Z0=PNC03P(1)
C
      P11=COS(TET1Z0)*COS(TET1Y0)
           P211=COS(TET1X0)*SIN(TET1Z0)
           P212=COS(TET1Z0)*SIN(TET1Y0)*SIN(TET1X0)
      P21=P211+P212
           P311=SIN(TET1Z0)*SIN(TET1X0)
           P312=-COS(TET1Z0)*SIN(TET1Y0)*COS(TET1X0)
      P31=P311+P312
C
      P12=-SIN(TET1Z0)*COS(TET1Y0)
           P221=COS(TET1Z0)*COS(TET1X0)
           P222=-SIN(TET1Z0)*SIN(TET1Y0)*SIN(TET1X0)
      P22=P221+P222
           P321=COS(TET1Z0)*SIN(TET1X0)
           P322=SIN(TET1Z0)*SIN(TET1Y0)*COS(TET1X0)
      P32=P321+P322
C
      P13=SIN(TET1Y0)
      P23=-COS(TET1Y0)*SIN(TET1X0)
      P33=COS(TET1Y0)*COS(TET1X0)
C
      I=0
10      CONTINUE
      I=I+1
      IF(I.EQ.NUM)GO TO 100
      TETAX=PHA0XP(I)
      TETAY=PHB02P(I)
      TETAZ=PHC03P(I)
C
C      EQUATIONS (3) -- TRANSFORMATION OF OCCIPITAL
C      CONDYLE LOCATION RELATIVE TO ANATOMICAL ORIGIN IN
C      THE ANATOMICAL COORDINATE SYSTEM TO COMPONENTS IN
C      IN THE LABORATORY COORD. SYST.
C      *****
           A11=ROAXA*COS(TETAZ)*COS(TETAY)

```

```

      A12=ROAZA*SIN(TETAY)
ROAXP=A11+A12
      A21=ROAXA*COS(TETAX)*SIN(TETAZ)
      A22=ROAXA*COS(TETAZ)*SIN(TETAY)*SIN(TETAX)
      A23=-ROAZA*COS(TETAY)*SIN(TETAX)
ROAYP=A21+A22+A23
      A31=ROAXA*SIN(TETAZ)*SIN(TETAX)
      A32=-ROAXA*COS(TETAZ)*SIN(TETAY)*COS(TETAX)
      A33=ROAZA*COS(TETAY)*COS(TETAX)
ROAZP=A31+A32+A33
C
      RAXP=DAXSOP(I)
      RAYP=DAYSOP(I)
      RAZP=DAZSOP(I)
      RTIXP=DNXSOP(I)
      RTIYP=DNYSOP(I)
RTIZP=DNZSOP(I)
C
C
C
EQUATIONS (6)
*****

B1=RAXP-RTIXP
B2=RAYP-RTIYP
B3=RAZP-RTIZP
RATIXP(I)=B1
RATIYP(I)=B2
RATIZP(I)=B3
RATIP(I)=SQRT(B1**2+B2**2+B3**2)
IF(I.GT.1)GO TO 200
YP=ARP+BR*RATIP(1)
DL2=YP-DNZMN
200 CONTINUE
B1P=B1+XCR
B2P=B2+YCR
B3P=B3+DL2+ZCR
RATIP(I)=SQRT(B1P**2+B2P**2+B3P**2)
C
C
C
EQUATIONS (7)

C1=B1P+ROAXP
C2=B2P+ROAYP
C3=B3P+ROAZP
ROTIXP(I)=C1
ROTIYP(I)=C2
ROTIZP(I)=C3
ROTIP(I)=SQRT(C1**2+C2**2+C3**2)
1899 CONTINUE ! TEMPORARY TO 1901
IF(ROTIP(I).LT.0.25)GO TO 1901
RATIP(I)=0.
! ROTIP(I)=0.
WRITE(6,1900)
1900 FORMAT(1X,'MISSING PHOTO DATA?')
1901 CONTINUE
C
EQUATIONS (9)
*****
C

```

```

C      TETA1X=PNA0XP(I)
      TETA1Y=PNB02P(I)
      TETA1Z=PNC03P(I)
      PSI(I)=1.5708-PHC03P(I)

C
C      MATRIX D

      D11=COS(TETA1Z)*COS(TETA1Y)
      D21=-SIN(TETA1Z)*COS(TETA1Y)
      D31=SIN(TETA1Y)
           D121=COS(TETA1X)*SIN(TETA1Z)
           D122=COS(TETA1Z)*SIN(TETA1Y)*SIN(TETA1X)
      D12=D121+D122
           D221=COS(TETA1Z)*COS(TETA1X)
           D222=-SIN(TETA1Z)*SIN(TETA1Y)*SIN(TETA1X)
      D22=D221+D222
      D32=-COS(TETA1Y)*SIN(TETA1X)
           D131=SIN(TETA1Z)*SIN(TETA1X)
           D132=-COS(TETA1Z)*SIN(TETA1Y)*COS(TETA1X)
      D13=D131+D132
           D231=COS(TETA1Z)*SIN(TETA1X)
           D232=SIN(TETA1Z)*SIN(TETA1Y)*COS(TETA1X)
      D23=D231+D232
      D33=COS(TETA1Y)*COS(TETA1X)
C      EQUATIONS (10)
C      *****
C      MATRIX PD=P X D
C
      PD11=P11*D11+P12*D21+P13*D31
      PD21=P21*D11+P22*D21+P23*D31
      PD31=P31*D11+P32*D21+P33*D31

C
      PD12=P11*D12+P12*D22+P13*D32
      PD22=P21*D12+P22*D22+P23*D32
      PD32=P31*D12+P32*D22+P33*D32

C
      PD13=P11*D13+P12*D23+P13*D33
      PD23=P21*D13+P22*D23+P23*D33
      PD33=P31*D13+P32*D23+P33*D33

C
      ROTX=PD11*C1+PD12*C2+PD13*C3
      ROTY=PD21*C1+PD22*C2+PD23*C3
      ROTZ=PD31*C1+PD32*C2+PD33*C3

C
      GAMA=ASIN(ROTY/ROTIF(I))
      TENTX=GAMA

C
      IF ROTZ IS APPROACHING ZERO THEN ATAN IS 90 DEGREES
      IF(ABS(ROTZ).LT.0.000001)GO TO 1000
      BETA=ATAN(ROTX/ROTZ)
      IF((ROTX.GE.0).AND.(ROTZ.GT.0))TENTY=BETA
      IF((ROTX.GE.0).AND.(ROTZ.LT.0))TENTY=3.14158+BETA
      IF((ROTX.LT.0).AND.(ROTZ.GT.0))TENTY=BETA
      IF((ROTX.LT.0).AND.(ROTZ.LT.0))TENTY=-(3.14158-BETA)

```

```

C      GAMA=ATAN(ROTY/ROTIP(I))
C      IF((ROTY.GE.0).AND.(ROTZ.GT.0))TENTX=GAMA
C      IF((ROTY.GE.0).AND.(ROTZ.LT.0))TENTX=3.14158+GAMA
C      IF((ROTY.LT.0).AND.(ROTZ.GT.0))TENTX=GAMA
C      IF((ROTY.LT.0).AND.(ROTZ.LT.0))TENTX=-(3.14158-GAMA)
      GO TO 2000
1000   CONTINUE
      IF(ROTX.GE.0)SIGN1=1
      IF(ROTX.LT.0)SIGN1=-1
      IF(ROTY.GE.0)SIGN2=1
      IF(ROTY.LT.0)SIGN2=-1
      TENTY=SIGN1*1.57
C      TENTX=SIGN2*1.57
2000   CONTINUE
      TENTYP(I)=TENTY
      IF(I.GT.1) GO TO 2001
      TENTY1=TENTY
2001   TENTYP(I) = TENTYP(I) - TENTY1
      TENTXP(I)=TENTX

C
C      EQUATION (14)
C      *****
C
      TET11Y=ASIN(ROTIXP(I)/ROTIP(I))
C
C      EQUATION (15)
C      *****
C
      TET11X=-TENTX
C
C      EQUATIONS (19)
C      *****
C
C      MATRIX RO
C
      R011=COS(TET11Y)
      R021=0.
      R031=SIN(TET11Y)
C
      R012=SIN(TET11Y)*SIN(TET11X)
      R022=COS(TET11X)
      R032=-COS(TET11Y)*SIN(TET11X)
C
      R013=-SIN(TET11Y)*COS(TET11X)
      R023=SIN(TET11X)
      R033=COS(TET11Y)*COS(TET11X)
C
C      MATRIX ROD = RO X D
C
      ROD11=R011*D11+R012*D21+R013*D31
      ROD21=R021*D11+R022*D21+R023*D31
      ROD31=R031*D11+R032*D21+R033*D31
C
      ROD12=R011*D12+R012*D22+R013*D32
      ROD22=R021*D12+R022*D22+R023*D32

```


ROD32=RO31*D12+RO32*D22+RO33*D32

ROD13=RO11*D13+RO12*D23+RO13*D33

ROD23=RO21*D13+RO22*D23+RO23*D33

ROD33=RO31*D13+RO32*D23+RO33*D33

TOXO=ROD11*TOXLP(I)+ROD12*TOYLP(I)+ROD13*TOZLP(I)

TOYO=ROD21*TOXLP(I)+ROD22*TOYLP(I)+ROD23*TOZLP(I)

TOZO=ROD31*TOXLP(I)+ROD32*TOYLP(I)+ROD33*TOZLP(I)

TOXOP(I)=TOXO

TOYOP(I)=TOYO

TOZOP(I)=TOZO

EQUATIONS (20)

FOXO=ROD11*FOXLP(I)+ROD12*FOYLP(I)+ROD13*FOZLP(I)

FOYO=ROD21*FOXLP(I)+ROD22*FOYLP(I)+ROD23*FOZLP(I)

FOZO=ROD31*FOXLP(I)+ROD32*FOYLP(I)+ROD33*FOZLP(I)

FOXOP(I)=FOXO

FOYOP(I)=FOYO

FOZOP(I)=FOZO

T1XLP(I)= TOXLP(I) + ROTIYP(I)*FOZLP(I) - ROTIZP(I)*FOYLP(I)

T1YLP(I)= TOYLP(I) - ROTIXP(I)*FOZLP(I) + ROTIZP(I)*FOXLP(I)

T1ZLP(I)= TOZLP(I) + ROTIXP(I)*FOYLP(I) - ROTIYP(I)*FOXLP(I)

T1XTP(I)= PD11*T1XLP(I)+PD12*T1YLP(I)+PD13*T1ZLP(I)

T1YTP(I)= PD21*T1XLP(I)+PD22*T1YLP(I)+PD23*T1ZLP(I)

T1ZTP(I)= PD31*T1XLP(I)+PD32*T1YLP(I)+PD33*T1ZLP(I)

EQUATIONS (17)

MATRIX R

R11=COS(TET11Y)

R21=0.

R31=SIN(TET11Y)

R12=SIN(TET11Y)*SIN(TET11X)

R22=COS(TET11X)

R32=-COS(TET11Y)*SIN(TET11X)

R13=-SIN(TET11Y)*COS(TET11X)

R23=SIN(TET11X)

R33=COS(TET11Y)*COS(TET11X)

MATRIX F

F1=COS(TETAZ)*COS(TETAY)

F21=COS(TETAX)*SIN(TETAZ)

F22=COS(TETAZ)*SIN(TETAY)*SIN(TETAX)

F2=F21+F22

F31=SIN(TETAZ)*SIN(TETAX)

F32=-COS(TETAZ)*SIN(TETAY)*COS(TETAX)


```

F3=F31+F32
C
C
C
MATRIX RD=R X PD
C
RD11=R11*PD11+R12*PD21+R13*PD31
RD21=R21*PD11+R22*PD21+R23*PD31
RD31=R31*PD11+R32*PD21+R33*PD31
C
RD12=R11*PD12+R12*PD22+R13*PD32
RD22=R21*PD12+R22*PD22+R23*PD32
RD32=R31*PD12+R32*PD22+R33*PD32
C
RD13=R11*PD13+R12*PD23+R13*PD33
RD23=R21*PD13+R22*PD23+R23*PD33
RD33=R31*PD13+R32*PD23+R33*PD33
C
E1NCX=RD11*F1+RD12*F2+RD13*F3
E1NCY=RD21*F1+RD22*F2+RD23*F3
E1NCZ=RD31*F1+RD32*F2+RD33*F3
C
C
IF E1NCX IS APPROACHING ZERO THEN ATAN IS 90 DEGREES
IF(ABS(E1NCX).LT.0.000001)GO TO 1101
BETA=ATAN(E1NCY/E1NCX)
IF((E1NCY.GE.0).AND.(E1NCX.GT.0))TETHNC=BETA
IF((E1NCY.GE.0).AND.(E1NCX.LT.0))TETHNC=3.14158+BETA
IF((E1NCY.LT.0).AND.(E1NCX.GT.0))TETHNC=BETA
IF((E1NCY.LT.0).AND.(E1NCX.LT.0))TETHNC=-(3.14158-BETA)
GO TO 2201
1101
CONTINUE
IF(E1NCY.GE.0)SIGN1=1.
IF(E1NCY.LT.0)SIGN1=-1.
TETHNC=SIGN1*1.57
2201
CONTINUE
TETHNP(I)=TETHNC - TETHNP(1)
C
C
C
MATRIX RH INVERSE
C
RHI11=COS(TETAZ)*COS(TETAY)
RHI12=-SIN(TETAZ)*COS(TETAY)
RHI13=SIN(TETAY)
C
RHI211=COS(TETAX)*SIN(TETAZ)
RHI212=COS(TETAZ)*SIN(TETAY)*SIN(TETAX)
RHI21=RHI211+RHI212
RHI221=COS(TETAZ)*COS(TETAX)
RHI222=-SIN(TETAZ)*SIN(TETAY)*SIN(TETAX)
RHI22=RHI221+RHI222
RHI23=-COS(TETAY)*SIN(TETAX)
C
RHI311=SIN(TETAZ)*SIN(TETAX)
RHI312=-COS(TETAZ)*SIN(TETAY)*COS(TETAX)
RHI31=RHI311+RHI312
RHI321=COS(TETAZ)*SIN(TETAX)
RHI322=SIN(TETAZ)*SIN(TETAY)*COS(TETAX)
RHI32=RHI321+RHI322

```

```

RHI33=COS(TETAY)*COS(TETAX)
C
C
C
MATRIX PD x RHI
RIDP11=PD11*RHI11+PD12*RHI21+PD13*RHI31
RIDP12=PD11*RHI12+PD12*RHI22+PD13*RHI32
RIDP13=PD11*RHI13+PD12*RHI23+PD13*RHI33
C
C
IF RIDP11 IS APPROACHING ZERO THEN ATAN IS 90 DEGREES
IF(ABS(RIDP11).LT.0.000001) GO TO 2500
BETA=ATAN(RIDP12/RIDP11)
IF((RIDP12.GE.0).AND.(RIDP11.GT.0))PSIP=BETA
IF((RIDP12.GE.0).AND.(RIDP11.LT.0))PSIP=3.14158+BETA
IF((RIDP12.LT.0).AND.(RIDP11.GT.0))PSIP= BETA
IF((RIDP12.LT.0).AND.(RIDP11.LT.0))PSIP=-(3.14158-BETA)
GO TO 2600
2500 CONTINUE
IF(RIDP12.GE.0)SIGN1=1.
IF(RIDP12.LT.0)SIGN1=-1.
PSIP=SIGN1*1.57
2600 CONTINUE
TETHNP(I)=1.5708+PSIP
IF(I.GT.1) GO TO 2601
TETHN1=TETHNP(1)
PSI1=PSI(1)
2601 TETHNP(I)=TETHNP(I)-TETHN1
PSI(I)=PSI(I)-PSI1
GO TO 10
100 CONTINUE
C
CALL FILEO(NAMTMP(7),RUNTMP,1,NUM,NERROR,RATIP)
CALL FILEO(NAMTMP(8),RUNTMP,1,NUM,NERROR,ROTIP)
CALL FILEO(NAMTMP(9),RUNTMP,5,NUM,NERROR,TENTYP)
CALL FILEO(NAMTMP(10),RUNTMP,5,NUM,NERROR,TENTXP)
CALL FILEO(NAMTMP(11),RUNTMP,5,NUM,NERROR,TETHNP)
CALL FILEO(NAMTMP(12),RUNTMP,5,NUM,NERROR,PSI)
CALL FILEO(NAMTMP(13),RUNTMP,6,NUM,NERROR,TOXOF)
CALL FILEO(NAMTMP(14),RUNTMP,6,NUM,NERROR,TOYOF)
CALL FILEO(NAMTMP(15),RUNTMP,6,NUM,NERROR,TOZOF)
CALL FILEO(NAMTMP(16),RUNTMP,10,NUM,NERROR,FOXOF)
CALL FILEO(NAMTMP(17),RUNTMP,10,NUM,NERROR,FYOOF)
CALL FILEO(NAMTMP(18),RUNTMP,10,NUM,NERROR,FZZOF)
CALL FILEO(NAMTMP(19),RUNTMP,6,NUM,NERROR,T1XLP)
CALL FILEO(NAMTMP(20),RUNTMP,6,NUM,NERROR,T1YLP)
CALL FILEO(NAMTMP(21),RUNTMP,6,NUM,NERROR,T1ZLP)
CALL FILEO(NAMTMP(22),RUNTMP,6,NUM,NERROR,T1XTP)
CALL FILEO(NAMTMP(23),RUNTMP,6,NUM,NERROR,T1YTP)
CALL FILEO(NAMTMP(24),RUNTMP,6,NUM,NERROR,T1ZTP)
RETURN
END
*****
*****
SUBROUTINE FILEO(NAMTMP,RUNTMP,UNTTMP,NUMBER,NERROR,ARRAY)
C
C

```

```

C      BYTE UNITS(100)
C      INTEGER*2 NUMB(100)
C      CHARACTER*6 NAMTMP,RUNTMP,NAME(100),RUN(100)
C      INTEGER UNTTMP,NUMBER,NERROR,NVAR
C      REAL ARRAY(NUMBER),MIN(100),MAX(100)
C
C      READ(1,REC=1)NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
C      NVAR=NVAR+1
C
C      MAX(NVAR)=-99999999.99
C      MIN(NVAR)=99999999.99
C
C      DO 1 I=2,NUMBER
C      TMPMAX=AMAX1(ARRAY(I-1),ARRAY(I))
C
C      MAX(NVAR)=AMAX1(MAX(NVAR),TMPMAX)
C
C      TMPMIN=AMIN1(ARRAY(I-1),ARRAY(I))
C
C      MIN(NVAR)=AMIN1(MIN(NVAR),TMPMIN)
C      1 CONTINUE
C
C      NAME(NVAR)=NAMTMP
C      RUN(NVAR)=RUNTMP
C      UNITS(NVAR)=UNTTMP
C      NUMB(NVAR)=NUMBER
C
C      WRITE(1,REC=1,ERR=900)NVAR,NAME,RUN,MAX,MIN,UNITS,NUMB
C
C      WRITE(1,REC=(NVAR+1),ERR=900)(ARRAY(I),I=1,NUMBER)
C
C      RETURN
900  NERROR=1
C      RETURN
C      END

```

SUBROUTINE TRQPHOR (HEAD)


```

C      TRGPHO. FOR
C
C      7/12/83. J.B. VARIABLE ANXXOS=ANXOP IS
C      IMPLEMENTED/11 CHANGES
C
      BYTE UNITS(100)
      INTEGER*2 NUMB(100)
      INTEGER RECLEN, MREC, NVAR, NP(18), NERROR, RECNM(18), TYPE(2)
      REAL AAXXOS(600), AAYXOS(600), AAZXOS(600), PHAEXP(600),
&      PHB02P(600), PHC03P(600), QHA0XS(600), QHB0XS(600), QHC0XS(600),
&      RHA0XS(600), RHBOXS(600), RHC0XS(600), PNAEXP(600), PNB02P(600),
&      PNC03P(600), ANXXOS(600), MIN(100), MAX(100), TARRAY(600),
&      VNXXOS(600)
      CHARACTER*6 NAME(100), RUN(100), VRBLS(18), FILNM, NAMTMP

      PARAMETER (MREC=101)
      PARAMETER (RECLEN=598)

      COMMON/INDATA/TARRAY, PHAEXP, PHB02P, PHC03P, RHA0XS, RHBOXS, RHC0XS,
&      QHA0XS, QHB0XS, QHC0XS, AAXXOS, AAYXOS, AAZXOS, PNAEXP, PNB02P,
&      PNC03P, ANXXOS, VNXXOS
C
      DATA VRBLS/'PHAEXP', 'PHB02P', 'PHC03P', 'RHA0XS', 'RHBOXS',
&      'RHC0XS', 'QHA0XS', 'QHB0XS', 'QHC0XS', 'AAXXOS', 'AAYXOS',
&      'AAZXOS', 'PNAEXP', 'PNB02P', 'PNC03P', 'TIME', 'ANXXOS',
&      'VNXXOS'/
C
      DATA TYPE/'OPEN', 'READ'/
C
C      STEP 1: OPEN INPUT FILE
C
      OPEN(UNIT=1, FILE='SCRATCH', RECL=RECLEN, STATUS='OLD', ERR=999,
&      FORM='UNFORMATTED', ORGANIZATION='RELATIVE', ACCESS='DIRECT')
C
C      STEP 2: READ IN DIRECTORY
C
      READ(1, REC=1) NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
C
C      STEP 3: TEST FOR EXISTANCE OF VARIABLES
C
      DO 1 I=1, 18
      DO 2 N=1, NVAR
      IF(NAME(N).NE. VRBLS(I))GO TO 3
      NP(I)=NUMB(N)
      RECNM(I)=N+1
      GO TO 1
      3 IF(N.EQ. NVAR)GO TO 900
      2 CONTINUE
      1 CONTINUE
C
C      STEP 4: READ APPROPRIATE RECORD
C

```



```

C      READ(1,REC=RECNM(1))(PHADXP(K),K=1,NP(1))
      READ(1,REC=RECNM(2))(PHBO2P(K),K=1,NP(2))
      READ(1,REC=RECNM(3))(PHCO3P(K),K=1,NP(3))
      READ(1,REC=RECNM(4))(RHA0XS(K),K=1,NP(4))
      READ(1,REC=RECNM(5))(RHBOXS(K),K=1,NP(5))
      READ(1,REC=RECNM(6))(RHCOXS(K),K=1,NP(6))
      READ(1,REC=RECNM(7))(QHA0XS(K),K=1,NP(7))
      READ(1,REC=RECNM(8))(QHBOXS(K),K=1,NP(8))
      READ(1,REC=RECNM(9))(QHCOXS(K),K=1,NP(9))
      READ(1,REC=RECNM(10))(AAXXOS(K),K=1,NP(10))
      READ(1,REC=RECNM(11))(AAYXOS(K),K=1,NP(11))
      READ(1,REC=RECNM(12))(AAZXOS(K),K=1,NP(12))
      READ(1,REC=RECNM(13))(PNA0XP(K),K=1,NP(13))
      READ(1,REC=RECNM(14))(PNBO2P(K),K=1,NP(14))
      READ(1,REC=RECNM(15))(PNC03P(K),K=1,NP(15))
      READ(1,REC=RECNM(16))(TARRAY(K),K=1,NP(16))
      READ(1,REC=RECNM(17))(ANXXOS(K),K=1,NP(17))
      READ(1,REC=RECNM(18))(VNXXOS(K),K=1,NP(18))

C
10    CONTINUE
      NERROR=0

C
C      NAMTMP=RUN(RECNM(1)-1)
      NUM=NP(16)
      CALL TORQP(NERROR,NAMTMP,NUM)

C      IF(NERROR.NE.0)GO TO 999
      GO TO 1000

C
C
C
C
C
C
C
C      ERROR MESSAGES
900    WRITE(6,901)VRBLS(I)
901    FORMAT(1X,'VARIABLE',1X,A10,1X,'IS NOT IN THE INPUT FILE',/,
+          1X,'YOU ARE ABOUT TO BE RETURNED TO MONITOR LEVEL TO ',/,
+          1X,'TRY AND RECTIFY THE PROBLEM',///)

C
C
C      GO TO 1000

C
C
C
999    WRITE(6,902)TYPE(NERROR)
C
902    FORMAT(1X,A5,'ERROR ENCOUNTERED',/,
+          1X,'PROGRAM HALT',///)

C
1000  CONTINUE
C
      CLOSE(UNIT=1)
      END

```

```

*****
*****

```

```

C      SUBROUTINE TORQP(NERROR,RUNTMP,NUM)
C
C      COMMON DATA FOR THE HEAD TORQUE PROGRAM (PHOTOGRAPHIC DATA)
C
C      REAL AAXXOS(600),AAYXOS(600),AAZXOS(600),PHAOXP(600),
&      PHBO2P(600),PHCO3P(600),GHAOXS(600),QHBOXS(600),GHCOXS(600),
&      RHAOXS(600),RHBOXS(600),RHCOXS(600),PNAOXP(600),PNBO2P(600),
&      PNCO3P(600),ANXXOS(600),TARRAY(600),VNXXOS(600)
C      COMMON/INDATA/TARRAY,PHAOXP,PHBO2P,PHCO3P,RHAOXS,RHBOXS,RHCOXS,
&      GHAOXS,QHBOXS,GHCOXS,AAXXOS,AAYXOS,AAZXOS,PNAOXP,PNBO2P,
&      PNCO3P,ANXXOS,VNXXOS
C
C      4TH EDITION OF 2/22/83
C      FILE: TORQP3.FOR
C
C      COMPUTATION OF MOMENTS AND FORCES AT THE OCCIPITAL CONDYLES
C      DUE TO HEAD DECELERATION AND GRAVITY AS DERIVED FROM
C      PHOTOGRAPHIC DATA
C
C      PROGRAM CONSTANTS -- DIFFERENT FOR EACH SUBJECT #
C
C      MH=MASS OF HEAD
C      G=ACCELERATION OF GRAVITY AT NBDL
C      RGAX = THE COMPONENT OF LINEAR POSITION OF THE
C            HEAD CENTER OF GRAVITY ALONG THE X-AXIS
C            OF THE HEAD ANATOMICAL COORDINATE SYSTEM.
C      RGAZ = SAME AS ABOVE EXCEPT FOR THE Z-AXIS.
C      RGOX = THE COMPONENT OF LINEAR POSITION OF THE
C            HEAD CENTER OF GRAVITY ALONG THE X-AXIS
C            OF THE HEAD ANATOMICAL COORDINATE SYSTEM MEASURED
C            FROM THE OCCIPITAL CONDYLES.
C      RGOZ = SAME AS ABOVE EXCEPT FOR THE Z-AXIS.
C      IX,IY,IZ = THE COMPONENT OF CENTROIDAL MASS MOMENT
C                OF INERTIA OF THE INSTRUMENTED HEAD ABOUT AN
C                AXIS PARALLEL TO THE X, Y, Z-AXIS OF THE
C                HEAD ANATOMICAL SYSTEM, RESPECTIVELY.
C      PXY = THE COMPONENT OF CENTROIDAL MASS PRODUCT OF INERTIA
C            OF THE INSTRUMENTED HEAD ABOUT AN AXIS PARALLEL
C            TO EITHER THE X OR Y AXIS OF THE HEAD
C            ANATOMICAL COORD. SYSTEM AND DEFINED BY AN
C            INTEGRAL OF XYD(MH).
C      PXZ,PYX,PYZ,PZX,PZY = SAME AS ABOVE EXCEPT FOR
C            THE RESPECTIVE AXES.
C
C      PROGRAM VARIABLES (ARRAYS)
C
C      PHAOXP=ANGLE ROTATION OF THE HEAD ABOUT THE X AXIS OF
C            THE HEAD ANATOMICAL COORD. SYSTEM AS DERIVED FROM
C            PHOTOGRAPHIC DATA
C      PHBO2P=SAME AS ABOVE EXCEPT FOR THE Y AXIS
C      PHCO3P=SAME AS ABOVE EXCEPT FOR THE Z AXIS
C      RHAOXS=ANGULAR VELOCITY OF THE HEAD ABOUT THE
C            X AXIS OF THE HEAD ANATOMICAL COORD.
C            SYSTEM AS DERIVED FROM ACCELEROMETER
C            DATA
C      RHBOXS=SAME AS ABOVE EXCEPT FOR THE Y AXIS
C      RHCOXS=SAME AS ABOVE EXCEPT FOR THE Z AXIS
C      GHAOXS=ANGULAR ACCELERATION OF THE HEAD
C            ABOUT THE X AXIS OF HEAD ANATOMICAL
C            COORD. SYSTEM AS DERIVED FROM

```

C ACCELEROMETER DATA
 C GHBOXS=SAME AS ABOVE EXCEPT FOR THE Y AXIS
 C GHCOXS=SAME AS ABOVE EXCEPT FOR THE Z AXIS
 C AAXXOS=THE X COMPONENT OF ACCELERATION OF
 C THE HEAD ANATOMICAL ORIGIN (THE
 C LABORATORY COORD. SYSTEM) WITH
 C RESPECT TO THE FIXED LABORATORY
 C COORD. SYSTEM AS DERIVED FROM
 C ACCELEROMETER DATA
 C AAYXOS=SAME AS ABOVE EXCEPT ABOUT THE
 C Y AXIS
 C AAZXOS=SAME AS ABOVE EXCEPT ABOUT THE
 C Z AXIS
 C PNAOXP=ANGLE OF ROTATION OF THE HEAD ABOUT THE
 C X AXIS OF THE HEAD ANATOMICAL COORD.
 C SYSTEM (INITIALLY ALIGNED WITH THE LABORATORY
 C COORD. SYSTEM) AS DERIVED FROM ACCELEROMETER
 C DATA
 C PNBO2P=SAME AS ABOVE EXCEPT ABOUT THE CARRIED X AXIS
 C PNCO3P=SAME AS ABOVE EXCEPT ABOUT THE CARRIED Z AXIS
 C TARRAY=TIME MARKS OF DATA POINTS RECORDING
 C ANXXOS=THE COMPONENT OF LINEAR ACCELERATION
 C OF THE T1 ANATOMICAL ORIGIN ALONG THE
 C X-AXIS OF THE LABORATORY COORDINATE
 C SYSTEM WITH RESPECT TO THE FIXED
 C LABORATORY COORDINATE SYSTEM AS DERIVED
 C FROM T1 MOUNT ACCELEROMETER DATA
 C VNXXOS=THE COMPONENT OF LINEAR VELOCITY OF THE
 C T1 ANATOMICAL ORIGIN ALONG THE
 C X-AXIS OF THE LABORATORY COORDINATE SYSTEM
 C WITH RESPECT TO THE FIXED LABORATORY COORDINATE
 C SYSTEM AS DERIVED FROM T1 MOUNT ACCELEROMETER
 C DATA.
 C
 C OUTPUT VARIABLES (ARRAYS)
 C
 C AGXP=X-COMPONENT OF ACCELERATION OF THE HEAD C.G. (THE HEAD
 C ANATOMICAL C.S.) WRT. THE LABORATORY COORD. SYSTEM
 C AS DERIVED FROM PHOTOGRAPHIC DATA
 C AGYP, AGZP=Y- AND Z-COORDINATES OF THE ABOVE
 C TOXP=THE COMPONENT OF MOMENT APPLIED BY THE NECK TO THE
 C HEAD ABOUT AN AXIS PARALLEL TO THE X AXIS OF THE
 C HEAD ANATOMICAL COORD. SYSTEM AS DERIVED FROM
 C PHOTOGRAPHIC DATA
 C TOYP, TOZP=SAME ABOUT THE Y- AND Z-AXES
 C FOXP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
 C HEAD AT THE OCCIPITAL CONDYLE PARALLEL TO
 C THE X AXIS OF HEAD ANATOMICAL COORD.
 C SYSTEM AS DERIVED FROM PHOTOGRAPHIC DATA
 C FOYP, FOZP=SAME ABOUT THE Y AND Z AXES
 C THTIYP=THE ANGLE OF ROTATION OF A PLANE FORMED
 C BY THE Y AXIS OF THE T1 ANATOMICAL
 C COORD. SYSTEM AND A UNIT VECTOR ALONG
 C THE Z AXIS OF THE HEAD ANATOMICAL COORD.
 C SYSTEM WITH RESPECT TO THE PLANE FORMED
 C BY THE Y AND Z AXES OF THE T1 ANATOMICAL
 C COORD. SYSTEM
 C THTIXP=THE ANGLE OF ROTATION OF A PLANE FORMED
 C BY THE X-AXIS OF THE T1 ANATOMICAL COORD.
 C SYSTEM AND A UNIT VECTOR ALONG THE Z


```

C      AXIS OF THE HEAD ANATOMICAL COORD. SYSTEM
C      WITH RESPECT TO THE PLANE FORMED BY THE
C      X AND Z AXES OF THE T1 ANATOMICAL COORD.
C      SYSTEM
C      TOXLP=THE COMPONENT OF MOMENT APPLIED BY THE NECK
C      TO THE HEAD ABOUT AN AXIS PARALLEL TO THE
C      LABORATORY X-AXIS AND PASSING THROUGH THE ORIGIN
C      OF THE OCCIPITAL COORDINATE SYSTEM
C      TOYLP=THE COMPONENT OF MOMENT APPLIED BY THE NECK TO THE
C      HEAD ABOUT AN AXIS PARALLEL TO THE LABORATORY
C      Y-AXIS AND PASSING THROUGH THE ORIGIN OF THE
C      OCCIPITAL COORDINATE SYSTEM
C      TOZLP=THE COMPONENT OF MOMENT APPLIED BY THE NECK
C      TO THE HEAD ABOUT AN AXIS PARALLEL TO THE LABORATORY
C      Z-AXIS AND PASSING THROUGH THE ORIGIN OF THE NECK
C      CHORD COORDINATE SYSTEM
C      FOXLP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD PARALLEL TO THE LABORATORY X-AXIS AND PASSING
C      THROUGH THE ORIGIN OF THE OCCIPITAL COORDINATE
C      SYSTEM
C      FOYLP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD PARALLEL TO THE LABORATORY Y-AXIS AND PASSING
C      THROUGH THE ORIGIN OF THE OCCIPITAL COORDINATE
C      SYSTEM
C      FOZLP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD PARALLEL TO THE LABORATORY Z-AXIS AND
C      PASSING THROUGH THE ORIGIN OF THE OCCIPITAL
C      COORDINATE SYSTEM
C      TOXTP=THE COMPONENT OF MOMENT APPLIED BY THE
C      NECK TO THE HEAD ABOUT THE X-AXIS OF THE T10
C      COORDINATE SYSTEM
C      TOYTP=THE COMPONENT OF MOMENT APPLIED BY THE NECK TO THE
C      HEAD ABOUT THE Y-AXIS BY THE T10 COORDINATE
C      SYSTEM
C      TOZTP=THE COMPONENT OF MOMENT APPLIED BY THE NECK TO THE
C      HEAD ABOUT THE Z-AXIS OF THE T10 COORDINATE
C      SYSTEM
C      FOXTP=THE COMPONENT OF FORCE APPLIED BY NECK TO THE
C      HEAD ALONG THE X-AXIS OF THE T10 COORDINATE
C      SYSTEM
C      FOYTP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO
C      HEAD ALONG THE Y-AXIS OF THE T10 COORDINATE
C      SYSTEM
C      FOZTP=THE COMPONENT OF FORCE APPLIED BY THE NECK TO THE
C      HEAD ALONG THE Z-AXIS OF THE T10 COORDINATE SYSTEM
C      ANXOP=ANXXOS
C      VNXOP=VNXXOS
C
C      REAL AGXP(600),AGYP(600),AGZP(600),TOXP(600),TOYP(600),
&      TOZP(600),FOXP(600),FOYP(600),FOZP(600),THTIYP(600),
&      THTIXP(600),TOXLP(600),TOYLP(600),TOZLP(600),FOXLP(600),
&      FOYLP(600),FOZLP(600),TOXTP(600),TOYTP(600),TOZTP(600),
&      FOXTP(600),FOYTP(600),FOZTP(600),ANXOP(600),VNXOP(600)
C      CHARACTER*6 NAMTMP(25),RUNTMP
C      INTEGER NERROR
C      REAL IX,IY,IZ,MH
C
C      DATA NAMTMP/'TOXP','TOYP','TOZP','THTIYP','THTIXP','AGXP',
&      'AGYP','AGZP','FOXP','FOYP','FOZP','TOXLP','TOYLP','TOZLP',
&      'FOXLP','FOYLP','FOZLP','TOXTP','TOYTP','TOZTP','FOXTP',

```

```

      &      'FOYTP', 'FOZTP', 'ANXOP', 'VNXOP' /
C
C
C      SUBJECT NUMBER SELECTION
1700      CONTINUE
          READ(5,*)NJCT
          WRITE(6,1755)NJCT
1755      FORMAT(5X, 'SUBJECT NUMBER=', 15)
          IF(NJCT.EQ.1)GO TO 1001
          IF(NJCT.EQ.83)GO TO 1083
          IF(NJCT.EQ.93)GO TO 1093
          IF(NJCT.EQ.96)GO TO 1096
          IF(NJCT.EQ.44)GOTO 1044
          IF(NJCT.EQ.64)GOTO 1064
          IF(NJCT.EQ.65)GOTO 1065
          IF(NJCT.EQ.67)GOTO 1067
1701      CONTINUE
          WRITE(6,1702)
1702      FORMAT(1X, 'INCORRECT SUBJECT NUMBER')
          STOP
C
1001      CONTINUE
          MH=4. 6
          RGAX=0. 012
          RGAZ=0. 029
          RGOX=0. 0234
          RGOZ=0. 055
          IX=0. 0215
          IY=0. 0278
          IZ=0. 0179
          PXY=-0. 000
          PYX=-0. 000
          PXZ=-0. 0057
          PZX=-0. 0057
          PYZ=0. 000
          PZY=0. 000
          RGOY=0. 0
          GO TO 999
C
1083      CONTINUE
          MH=4. 532
          RGAX=0. 012
          RGAZ=0. 029
          RGOX=0. 023
          RGOZ=0. 055
          IX=0. 0211
          IY=0. 0261
          IZ=0. 0174
          PXY=0
          PYX=0.
          PXZ=-. 0056
          PZX=-. 0056
          PYZ=0.
          PZY=0.
          RGOY=0. 0
          GO TO 999
C
1093      CONTINUE
          MH=4. 03
          RGAX=0. 012

```


RGZ=0. 029
RGX=0. 023
RGZ=0. 055
IX=0. 0174
IY=0. 0215
IZ=0. 0142
PXY=0.
PYX=0.
PXZ=-0. 0049
PZX=-0. 0049
PYZ=0.
PZY=0.
RGY=0.
GO TO 999

C
1044

CONTINUE
MH=4. 37
RGAX=0. 012
RGZ=. 029
RGX=. 023
RGZ=. 055
IX=. 0200
IY=. 0258
IZ=. 0166
PXY=0. 0
PYX=0. 0
PXZ=-. 0053
PZX=-. 0053
PYZ=0. 0
PZY=0. 0
RGY=0. 0
GO TO 999

C
1064

CONTINUE
MH=4. 90
RGAX=. 012
RGZ=. 029
RGX=. 023
RGY=0.
RGZ=. 055
IX=. 0236
IY=. 0306
IZ=. 0198
PXY=0.
PYX=0.
PXZ=-. 0058
PZX=-. 0058
PYZ=0.
PZY=0.
GOTO 999

C
1065

CONTINUE
MH=5. 11
RGAX=. 012
RGZ=. 029
RGX=. 023
RGY=0.
RGZ=. 055
IX=. 0250
IY=. 0335

IZ=. 0211
PXY=0.
PYX=0.
PXZ=-. 0060
PZX=-. 0060
PYZ=0.
PZY=0.
GOTO 999

C
1067

CONTINUE
MH=4. 66
RGAX=. 012
RGAZ=. 029
RGDX=. 023
RGDY=0.
RGDZ=. 055
IX=. 0220
IY=. 0290
IZ=. 0184
PXY=0.
PYX=0.
PXZ=-. 0057
PZX=-. 0057
PYZ=0.
PZY=0.
GOTO 999

C
1096

CONTINUE
MH=0.
RGAX=0. 012
RGAZ=0. 029
RGDX=0. 023
RGDZ=0. 055
IX=0
IY=0.
IZ=0.
PXY=0.
PYX=0.
PXZ=0.
PZX=0.
PYZ=0.
PZY=0.
RGDY=0.
GO TO 999

C
1725

CONTINUE

C
999

CONTINUE
DELT=0. 0005
G=9. 81

C

TPMAX=TARRAY(NUM)
TSMAX=DELT*598
IF(TPMAX.LE. TSMAX)GO TO 55
DO 11 K=1, NUM
K1=K
TAR=TARRAY(K1)
IF(TAR. LE. TSMAX)GO TO 11
KC=K
KMAX=KC-1

```

      GO TO 22
C
  11  CONTINUE
  22  CONTINUE
C
      NUM=KMAX
C
  55  CONTINUE
C
      TET1X0=PNAOXP(1)
      TET1Y0=PNB02P(1)
      TET1Z0=PNC03P(1)
C
C      MATRIX P -- FOR EQUATIONS (19)
C
      P11=cos(TET1Z0)*cos(TET1Y0)
      P211=cos(TET1X0)*sin(TET1Z0)
      P212=cos(TET1Z0)*sin(TET1Y0)*sin(TET1X0)
      P21=P211+P212
      P311=sin(TET1Z0)*sin(TET1X0)
      P312=-cos(TET1Z0)*sin(TET1Y0)*cos(TET1X0)
      P31=P311+P312
      P12=-sin(TET1Z0)*cos(TET1Y0)
      P221=cos(TET1Z0)*cos(TET1X0)
      P222=-sin(TET1Z0)*sin(TET1Y0)*sin(TET1X0)
      P22=P221+P222
      P321=cos(TET1Z0)*sin(TET1X0)
      P322=sin(TET1Z0)*sin(TET1Y0)*cos(TET1X0)
      P32=P321+P322
      P13=sin(TET1Y0)
      P23=-cos(TET1Y0)*sin(TET1X0)
      P33=cos(TET1Y0)*cos(TET1X0)
C
C
      I=0
C
  10  CONTINUE
      I=I+1
      IF(I.EQ.(NUM+1))GO TO 100
      TAR=TARRAY(I)
      DO 33 J=1,598
        JCOPY=J
        TIME=DELT*JCOPY
        IF(TIME.LT.TAR)GO TO 33
C
C
C
C
      I2=JCOPY
      GO TO 44
  33  CONTINUE
  44  CONTINUE
      I1=I2-1
      CALCULATION OF THE NEEDED VARIABLES
      THROUGH INTERPOLATION OF ACCELEROMETER
      DATA
C
      TAR=TARRAY(I)
      CF=(TAR-DELT*I1)/DELT
      FC=1.-CF

```

```

TETAX=PHAOXP(I)
TETAY=PHBO2P(I)
TETAZ=PHCO3P(I)
ALFX=FC*QHAOXS(I1)+CF*QHAOXS(I2)
ALFY=FC*QHBOXS(I1)+CF*QHBOXS(I2)
ALFZ=FC*QHCOXS(I1)+CF*QHCOXS(I2)
AACX=FC*AAXXOS(I1)+CF*AAXXOS(I2)
AACY=FC*AAYXOS(I1)+CF*AAYXOS(I2)
AACZ=FC*AAZXOS(I1)+CF*AAZXOS(I2)
WX=FC*RHAOXS(I1)+CF*RHAOXS(I2)
WY=FC*RHBOXS(I1)+CF*RHBOXS(I2)
WZ=FC*RHCOXS(I1)+CF*RHCOXS(I2)
ANXOP(I)=FC*ANXXOS(I1)+CF*ANXXOS(I2)
VNXOP(I)=FC*VNXXOS(I1)+CF*VNXXOS(I2)

```

```

EQUATIONS (13)

```

```

*****

```

```

      Q11=-SIN(TETAZ)*SIN(TETAX)
      Q12=COS(TETAZ)*SIN(TETAY)*COS(TETAX)
GX=(Q11+Q12)*G
      Q21=-COS(TETAZ)*SIN(TETAX)
Q22=-SIN(TETAZ)*SIN(TETAY)*COS(TETAX)
GY=(Q21+Q22)*G
QZ=(-COS(TETAY)*COS(TETAX))*G

```

```

EQUATIONS (17)

```

```

*****

```

```

A11=COS(TETAZ)*COS(TETAY)
      A121=COS(TETAX)*SIN(TETAZ)
      A122=COS(TETAZ)*SIN(TETAY)*SIN(TETAX)
A12=A121+A122
      A131=SIN(TETAZ)*SIN(TETAX)
      A132=-COS(TETAZ)*SIN(TETAY)*COS(TETAX)
A13=A131+A132
A21=-SIN(TETAZ)*COS(TETAY)
      A221=COS(TETAZ)*COS(TETAX)
      A222=-SIN(TETAZ)*SIN(TETAY)*SIN(TETAX)
A22=A221+A222
      A231=COS(TETAZ)*SIN(TETAX)
      A232=SIN(TETAZ)*SIN(TETAY)*COS(TETAX)
A23=A231+A232
A31=SIN(TETAY)
A32=-COS(TETAY)*SIN(TETAX)
A33=COS(TETAY)*COS(TETAX)
AAX=A11*AACX+A12*AACY+A13*AACZ
AAY=A21*AACX+A22*AACY+A23*AACZ
AAZ=A31*AACX+A32*AACY+A33*AACZ

```

```

EQUATIONS (18)

```

```

*****

```

```

      B11=-(WZ**2+WY**2)*RGAX
      B12=WZ*WZ*RGAX
B1=B11+B12
      B21=WZ*WZ*RGAX
      B22=WY*WZ*RGAX
B2=B21+B22
      B31=WZ*WZ*RGAX

```

B32=-(WX**2+WY**2)*RGAZ
 B3=B31+B32
 C1=RGAZ*ALFY
 C21=RGAX*ALFZ
 C22=-RGAX*ALFX
 C2=C21+C22
 C3=-RGAX*ALFY
 AGX=AAX+B1+C1
 AGY=AAZ+B2+C2
 AGZ=AAZ+B3+C3

C
 C
 C
 C

EQUATIONS (15)

T11=IX*ALFX
 T12=IY*ALFY
 T13=IZ*ALFZ
 T21=(IZ-IY)*WY*WZ
 T22=(IX-IZ)*WX*WZ
 T23=(IY-IX)*WX*WY
 T311=MH*RGDZ*(GY-AGY)
 T312=-MH*RGDY*(GY-AGZ)
 T31=T311+T312
 T321=-MH*RGDZ*(GX-AGX)
 T322=MH*RGDX*(GZ-AGZ)
 T32=T321+T322
 T331=-MH*RGDX*(GY-AGY)
 T332=MH*RGDY*(GX-AGX)
 T33=T331+T332
 T41=-PXY*ALFY-PXZ*ALFZ
 T42=-PYX*ALFX-PYZ*ALFZ
 T43=-PZX*ALFX-PZY*ALFY
 T511=PYX*WX*WZ
 T512=PYZ*(WZ**2)
 T513=-PZX*WX*WY
 T514=-PZY*(WY**2)
 T51=T511+T512+T513+T514
 T521=-PXY*WY*WZ
 T522=-PXZ*(WZ**2)
 T523=PZX*(WX**2)
 T524=PZY*WX*WY
 T52=T521+T522+T523+T524
 T531=PXY*(WY**2)
 T532=PXZ*WY*WZ
 T533=-PYX*(WX**2)
 T534=-PYZ*WX*WZ
 T53=T531+T532+T533+T534
 TOX=T11+T21+T31+T41+T51
 TOY=T12+T22+T32+T42+T52
 TOZ=T13+T23+T33+T43+T53

C
 C
 C
 C

EQUATIONS (16)

FOX=MH*(AGX-GX)
 FOY=MH*(AGY-GY)
 FOZ=MH*(AGZ-GZ)

C
 C
 C

EQUATIONS (22)

```

C      TOXL=TOX*A11+TOY*A21+TOZ*A31
      TOYL=TOX*A12+TOY*A22+TOZ*A32
      TOZL=TOX*A13+TOY*A23+TOZ*A33

C
C      EQUATIONS (23)
C      *****
C
      FOXL=FOX*A11+FOY*A21+FOZ*A31
      FOYL=FOX*A12+FOY*A22+FOZ*A32
      FOZL=FOX*A13+FOY*A23+FOZ*A33
C      OUTPUT VARIABLES (ARRAYS)
C
      AGXP(I)=AGX
      AGYP(I)=AGY
      AGZP(I)=AGZ
      TOXP(I)=TOX
      TOYP(I)=TOY
      TOZP(I)=TOZ
      FOXP(I)=FOX
      FOYP(I)=FOY
      FOZP(I)=FOZ
      TOXLP(I)=TOXL
      TOYLP(I)=TOYL
      TOZLP(I)=TOZL
      FOXLP(I)=FOXL
      FOYLP(I)=FOYL
      FOZLP(I)=FOZL
C      EQUATIONS (19)
C      *****
C
      TETA1X=PNA0XP(I)
      TETA1Y=PNB02P(I)
      TETA1Z=PNC03P(I)

C
      D11=COS(TETA1Z)*COS(TETA1Y)
      D21=-SIN(TETA1Z)*COS(TETA1Y)
      D31=SIN(TETA1Y)
           D121=COS(TETA1X)*SIN(TETA1Z)
           D122=COS(TETA1Z)*SIN(TETA1Y)*SIN(TETA1X)
      D12=D121+D122
           D221=COS(TETA1Z)*COS(TETA1X)
           D222=-SIN(TETA1Z)*SIN(TETA1Y)*SIN(TETA1X)
      D22=D221+D222
      D32=-COS(TETA1Y)*SIN(TETA1X)
           D131=SIN(TETA1Z)*SIN(TETA1X)
           D132=-COS(TETA1Z)*SIN(TETA1Y)*COS(TETA1X)
      D13=D131+D132
           D231=COS(TETA1Z)*SIN(TETA1X)
           D232=SIN(TETA1Z)*SIN(TETA1Y)*COS(TETA1X)
      D23=D231+D232
      D33=COS(TETA1Y)*COS(TETA1X)

C
      F1=SIN(TETAY)
      F2=-COS(TETAY)*SIN(TETAX)
      F3=COS(TETAY)*COS(TETAX)

C
C      MATRIX PD=P X D
C
      PD11=(P11*D11)+(P12*D21)+(P13*D31)

```

```

MIN(NVAR)=99999999.99
C
DO 1 I=2, NUMBER
TMPMAX=AMAX1 (ARRAY(I-1), ARRAY(I))
C
MAX(NVAR)=AMAX1 (MAX(NVAR), TMPMAX)
C
C
TMPMIN=AMIN1 (ARRAY(I-1), ARRAY(I))
C
MIN(NVAR)=AMIN1 (MIN(NVAR), TMPMIN)
1 CONTINUE
C
C
NAME(NVAR)=NAMTMP
RUN(NVAR)=RUNTMP
UNITS(NVAR)=UNTTMP
NUMB(NVAR)=NUMBER
C
C
WRITE(1, REC=1, ERR=900) NVAR, NAME, RUN, MAX, MIN, UNITS, NUMB
WRITE(1, REC=(NVAR+1), ERR=900) (ARRAY(I), I=1, NUMBER)
C
RETURN
900 NERROR=1
RETURN
END

```

HE 19.3 1A
NHTSA-B4

Spenny, Cl

Analysis of
torso acc

Form DOT F 172
FORMERLY FORM D

Postage and Fees Paid
Research and Special
Programs Administration
DOI 513**Postage and Fees Paid
Research and Special
Programs Administration
DOT 513****Postage and Fees Paid
Research and Special
Programs Administration
DOT 513****Postage and Fees Paid
Research and Special
Programs Administration
DOT 513**